

Quantum using EcoStruxure™ Control Expert

140 NOC 77100 EtherNet/IP
Communication Module
User Manual

Original instructions

09/2020

The information provided in this documentation contains general descriptions and/or technical characteristics of the performance of the products contained herein. This documentation is not intended as a substitute for and is not to be used for determining suitability or reliability of these products for specific user applications. It is the duty of any such user or integrator to perform the appropriate and complete risk analysis, evaluation and testing of the products with respect to the relevant specific application or use thereof. Neither Schneider Electric nor any of its affiliates or subsidiaries shall be responsible or liable for misuse of the information contained herein. If you have any suggestions for improvements or amendments or have found errors in this publication, please notify us.

You agree not to reproduce, other than for your own personal, noncommercial use, all or part of this document on any medium whatsoever without permission of Schneider Electric, given in writing. You also agree not to establish any hypertext links to this document or its content. Schneider Electric does not grant any right or license for the personal and noncommercial use of the document or its content, except for a non-exclusive license to consult it on an "as is" basis, at your own risk. All other rights are reserved.

All pertinent state, regional, and local safety regulations must be observed when installing and using this product. For reasons of safety and to help ensure compliance with documented system data, only the manufacturer should perform repairs to components.

When devices are used for applications with technical safety requirements, the relevant instructions must be followed.

Failure to use Schneider Electric software or approved software with our hardware products may result in injury, harm, or improper operating results.

Failure to observe this information can result in injury or equipment damage.

© 2020 Schneider Electric. All rights reserved.

Table of Contents



	Safety Information	7
	About the Book	11
Chapter 1	Installation	13
	Hardware Installation	14
	Module Specifications	17
Chapter 2	Configuring the 140 NOC 771 00	19
2.1	Creating a Project in Control Expert	20
	Creating a Project in Control Expert	21
	Configuring the 140 NOC 771 00 Ethernet/IP Communication Module	23
2.2	Using the Control Expert EtherNet/IP Configuration Tool	31
	EtherNet/IP Configuration Tool User Interface	32
	Devices Window	36
	Configuring Properties in the Devices Window	37
2.3	Configuring Network Channel Properties	39
	Configuring Channel Properties: The General page	40
	Configuring Channel Properties: The Ethernet page	43
	Configuring Channel Properties: The EtherNet/IP page	44
	Configuring Channel Properties: The Module Information page	46
2.4	Configuring the TCP/IP Address Settings	52
	TCP/IP Properties: The General Page	53
	TCP/IP Properties: Configuring the SNMP Agent	55
	TCP/IP Properties: Configuring the DHCP Server	57
2.5	Configuring the EtherNet/IP Communication Module as an I/O Adapter	60
	Identifying the Local Slave	61
	Local Slave Inputs and Outputs	62
	Configuring Local Slave Properties: The General page	64
Chapter 3	Adding Devices to an EtherNet/IP Network	67
3.1	Adding Devices to an EtherNet/IP Network	68
	Effect of Device Position on Input and Output %MW Memory Addresses	68

3.2	Adding and Configuring Remote Devices	72
	Device Library	73
	Add an EDS File to the Device Library	75
	Adding A Remote Device	78
	Configuring Remote Device Properties	80
	Managing Project Files	85
3.3	Configuring the STB NIC 2212	87
	Setting Up Your Network	88
	Automatically Detect and Add the STB NIC 2212	90
	Configuring STB NIC 2212 Properties	91
	Connecting to the Advantys STB Island	95
	Configuring I/O Items	99
3.4	Connecting to Third Party Devices	114
	Adding a Third Party Device to the Sample Network	115
	Add an EDS File	116
	Automatically Detect and Add the 1734-AENT PointIO Adapter	119
	Configuring 1734-AENT PointIO Adapter Properties	120
	Viewing 1734-AENT PointIO Adapter I/O Addresses	124
Chapter 4	Optimizing Performance	127
4.1	Selecting a Switch	128
	Role of a Switch in an Ethernet Network	129
	Transmission Speed, Duplex and Auto-Negotiation	130
	Quality of Service (QoS)	131
	IGMP Snooping	132
	Rapid Spanning Tree Protocol (RSTP)	133
	Virtual Local Area Network (VLAN)	134
	Port Mirroring	136
	Virtual Local Area Network (VLAN)	137
	Simple Network Management Protocol (SNMP) Agent	138
4.2	Control Application Design	139
	Message Types	140
	TCP Connections	142
	CIP Connections and Messages	143
	Messaging Performance	144
4.3	Projecting Ethernet Network Performance	145
	Allocating Network Bandwidth	146
	Network Load and Bandwidth Calculation Example	148

Chapter 5	Explicit Messaging in Control Expert	153
	Explicit Messaging Services	154
	Configuring Explicit Messaging Using MBP_MSTR	156
	MBP_MSTR Example - Get_Attributes_Single	159
	MBP_MSTR Example - Reset	164
	Explicit Messaging Error Codes	169
	Explicit Messaging - Online Action: Get_Attributes_Single	172
	Explicit Messaging - Online Action: Reset	174
Chapter 6	CIP Objects.	177
	Adapter Diagnostic Object	178
	Assembly Object	183
	Connection Manager Object	185
	Ethernet Link Object	187
	Identity Object	191
	Module Diagnostic Object	193
	Scanner Diagnostic Object	195
	TCP/IP Interface Object	200
Chapter 7	Diagnostics	203
	LED Indicators for the 140 NOC 771 00 EtherNet/IP Communication Module	204
	Diagnostic Testing Using the Control Expert EtherNet/IP Software . .	206
	Ping a Network Device	208
	Viewing Output Messages in the Control Expert EtherNet/IP Configuration Tool	209
Chapter 8	Replacing the EtherNet/IP Communication Module	211
	Replacing the EtherNet/IP Communication Module	211
Appendices	213
Appendix A	Error Codes	215
	TCP/IP Ethernet Error Codes	215
Glossary	219
Index	221

Safety Information



Important Information

NOTICE

Read these instructions carefully, and look at the equipment to become familiar with the device before trying to install, operate, service, or maintain it. The following special messages may appear throughout this documentation or on the equipment to warn of potential hazards or to call attention to information that clarifies or simplifies a procedure.



The addition of this symbol to a “Danger” or “Warning” safety label indicates that an electrical hazard exists which will result in personal injury if the instructions are not followed.



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

DANGER

DANGER indicates a hazardous situation which, if not avoided, **will result in death** or serious injury.

WARNING

WARNING indicates a hazardous situation which, if not avoided, **could result in death** or serious injury.

CAUTION

CAUTION indicates a hazardous situation which, if not avoided, **could result** in minor or moderate injury.

NOTICE

NOTICE is used to address practices not related to physical injury.

PLEASE NOTE

Electrical equipment should be installed, operated, serviced, and maintained only by qualified personnel. No responsibility is assumed by Schneider Electric for any consequences arising out of the use of this material.

A qualified person is one who has skills and knowledge related to the construction and operation of electrical equipment and its installation, and has received safety training to recognize and avoid the hazards involved.

BEFORE YOU BEGIN

Do not use this product on machinery lacking effective point-of-operation guarding. Lack of effective point-of-operation guarding on a machine can result in serious injury to the operator of that machine.

WARNING

UNGUARDED EQUIPMENT

- Do not use this software and related automation equipment on equipment which does not have point-of-operation protection.
- Do not reach into machinery during operation.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

This automation equipment and related software is used to control a variety of industrial processes. The type or model of automation equipment suitable for each application will vary depending on factors such as the control function required, degree of protection required, production methods, unusual conditions, government regulations, etc. In some applications, more than one processor may be required, as when backup redundancy is needed.

Only you, the user, machine builder or system integrator can be aware of all the conditions and factors present during setup, operation, and maintenance of the machine and, therefore, can determine the automation equipment and the related safeties and interlocks which can be properly used. When selecting automation and control equipment and related software for a particular application, you should refer to the applicable local and national standards and regulations. The National Safety Council's Accident Prevention Manual (nationally recognized in the United States of America) also provides much useful information.

In some applications, such as packaging machinery, additional operator protection such as point-of-operation guarding must be provided. This is necessary if the operator's hands and other parts of the body are free to enter the pinch points or other hazardous areas and serious injury can occur. Software products alone cannot protect an operator from injury. For this reason the software cannot be substituted for or take the place of point-of-operation protection.

Ensure that appropriate safeties and mechanical/electrical interlocks related to point-of-operation protection have been installed and are operational before placing the equipment into service. All interlocks and safeties related to point-of-operation protection must be coordinated with the related automation equipment and software programming.

NOTE: Coordination of safeties and mechanical/electrical interlocks for point-of-operation protection is outside the scope of the Function Block Library, System User Guide, or other implementation referenced in this documentation.

START-UP AND TEST

Before using electrical control and automation equipment for regular operation after installation, the system should be given a start-up test by qualified personnel to verify correct operation of the equipment. It is important that arrangements for such a check be made and that enough time is allowed to perform complete and satisfactory testing.

WARNING

EQUIPMENT OPERATION HAZARD

- Verify that all installation and set up procedures have been completed.
- Before operational tests are performed, remove all blocks or other temporary holding means used for shipment from all component devices.
- Remove tools, meters, and debris from equipment.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

Follow all start-up tests recommended in the equipment documentation. Store all equipment documentation for future references.

Software testing must be done in both simulated and real environments.

Verify that the completed system is free from all short circuits and temporary grounds that are not installed according to local regulations (according to the National Electrical Code in the U.S.A, for instance). If high-potential voltage testing is necessary, follow recommendations in equipment documentation to prevent accidental equipment damage.

Before energizing equipment:

- Remove tools, meters, and debris from equipment.
- Close the equipment enclosure door.
- Remove all temporary grounds from incoming power lines.
- Perform all start-up tests recommended by the manufacturer.

OPERATION AND ADJUSTMENTS

The following precautions are from the NEMA Standards Publication ICS 7.1-1995 (English version prevails):

- Regardless of the care exercised in the design and manufacture of equipment or in the selection and ratings of components, there are hazards that can be encountered if such equipment is improperly operated.
- It is sometimes possible to misadjust the equipment and thus produce unsatisfactory or unsafe operation. Always use the manufacturer's instructions as a guide for functional adjustments. Personnel who have access to these adjustments should be familiar with the equipment manufacturer's instructions and the machinery used with the electrical equipment.
- Only those operational adjustments actually required by the operator should be accessible to the operator. Access to other controls should be restricted to prevent unauthorized changes in operating characteristics.

About the Book



At a Glance

Document Scope

This manual describes the use of the Quantum 140 NOC 771 00 EtherNet/IP communication module. This manual presents a continuing sample configuration. The features of the module are described as they are encountered in the course of this continuing sample configuration.

The specific configuration settings contained in this manual are intended to be used for instructional purposes only. The settings required for your specific EtherNet/IP configuration may, and probably will, differ from the examples presented in this manual.

Validity Note

This document is valid for EcoStruxure™ Control Expert 15.0 or later.

The technical characteristics of the devices described in the present document also appear online. To access the information online:

Step	Action
1	Go to the Schneider Electric home page www.schneider-electric.com .
2	In the Search box type the reference of a product or the name of a product range. <ul style="list-style-type: none">• Do not include blank spaces in the reference or product range.• To get information on grouping similar modules, use asterisks (*).
3	If you entered a reference, go to the Product Datasheets search results and click on the reference that interests you. If you entered the name of a product range, go to the Product Ranges search results and click on the product range that interests you.
4	If more than one reference appears in the Products search results, click on the reference that interests you.
5	Depending on the size of your screen, you may need to scroll down to see the datasheet.
6	To save or print a datasheet as a .pdf file, click Download XXX product datasheet .

The characteristics that are described in the present document should be the same as those characteristics that appear online. In line with our policy of constant improvement, we may revise content over time to improve clarity and accuracy. If you see a difference between the document and online information, use the online information as your reference.

Related Documents

For additional information, you can also refer to the online help files for both the:

- Control Expert software
- Control Expert EtherNet/IP Configuration Tool software

Title of Documentation	Reference Number
Advantys STB EtherNet/IP Network Interface Applications Guide	31008204

You can download these technical publications and other technical information from our website at <https://www.se.com/ww/en/download/> .

Chapter 1

Installation

Overview

The 140 NOC 771 00 communication module serves as the interface between a Quantum PLC (CPU) and an EtherNet/IP network. This chapter shows you how to install the module by:

- inserting it into a Quantum backplane, and
- connecting it to an EtherNet/IP network

What Is in This Chapter?

This chapter contains the following topics:


Topic	Page
Hardware Installation	14
Module Specifications	17

Hardware Installation

Overview

The following information describes how to install the 140 NOC 771 00 EtherNet/IP communication module.

External Features



LEDs

The 140 NOC 771 00 EtherNet/IP module presents the following LED indicators:

- Active
- Module Status
- Network Status
- Ready
- Link
- Transmission Activity
- Reception Activity
- 100 Mb link
- Full Duplex/Collision

For a description of these LEDs, and how to use them to diagnose the module, refer to the topic LED Indicators for the 140 NOC 771 00 Communication Module (*see page 204*).

Locating a Backplane Slot

The 140 NOC 771 00 EtherNet/IP module is mounted in a Quantum PLC station. It can be installed in any available position in the Quantum backplane.


Selecting a Power Supply

When configuring the Quantum PLC station, be sure to add a power supply module that is capable of supplying power to all modules on the rack.

Tools Required

One medium-sized (size 2) Phillips-head screw driver.

Mounting the Module in the Backplane

Step	Action
1	<p>Holding the module at an angle, mount it on the two hooks located near the top of the backplane.</p> <p>The following figure shows the correct way to hold the module.</p> 
2	Swing the module down so the connector engages the backplane connector.
3	Use a Phillips-head screw driver to tighten the safety screw at the bottom of the module from 2 through 4 in-lbs or from .22 through .45 Newton meters of torque.

Wiring the Ethernet Connector

⚠ WARNING

HAZARD OF ELECTRICAL SHOCK OR BURN

Connect the ground wire to the protective earth (PE) terminal before you establish any further connections. When you remove connections, disconnect the ground wire last. The Ethernet cable shield must be connected to PE ground at the Ethernet switch.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

The 140 NOC 771 00 module communicates over an EtherNet/IP network through a single RJ45 connector located at the bottom of the module.



Module Specifications

Related Documentation

Refer to the Hardware Installation (*see page 14*) section of this chapter and the *Quantum Ethernet Modules* section in the *Quantum with Control Expert Hardware Reference Guide*, for more detailed information on the installation.

Specifications

Communication Ports	One auto-sensing 10/100Base-T shielded twisted pair (RJ-45 connector) port.
Bus Current Required	500 mA
Power Dissipation	2.5 W
Fuse	None
Operating Conditions	
Temperature	0...+60° C
Humidity	0...95% Rh non-condensing @ 60°C
Altitude	2000 m (6561.68 ft)
Vibration	10...57 Hz @ 0.0075 mm d.a
	57...150 Hz @ 1 g
Storage Conditions	
Temperature	-40...+85°C
Humidity	0...95% Rh non-condensing @ 60°C
Free Fall	1 m unpackaged
Shock	+/- 15 g, 11 ms, half sine wave

Software Compatibility

The 140 NOC 771 00 is compatible with Unity Pro XL programming software version 4.0 and later.

NOTE: Unity Pro is the former name of Control Expert for version 13.1 or earlier.

Standards

The 140 NOC 771 00 module complies with the following standards:

- UL 508
- CSA 22.2-142
- CE
- C-TICK
- ODVA

Communication Modules per Rack

The maximum number of communication modules, including but not limited to 140 NOC 771 00 EtherNet/IP communication modules, you can install in a single rack is determined by the CPU serving that rack:

CPU	Maximum Number of Communication Modules per Rack
140 CPU 311 10	2
140 CPU 434 12A	6
140 CPU 534 14A	6
140 CPU 651 50	6
140 CPU 651 60	6
140 CPU 652 60	6
140 CPU 671 60	6
140 CPU 672 60	6
140 CPU 672 61	6

Chapter 2

Configuring the 140 NOC 771 00

Overview

This chapter shows you how to use Control Expert programming software and the Control Expert EtherNet/IP configuration tool to select and configure the 140 NOC 771 00 EtherNet/IP communication module.

NOTE: The instructions presented in this chapter include specific choices made for a sample project. Your Control Expert project may include different choices that are appropriate for your specific configuration.

What Is in This Chapter?

This chapter contains the following sections:

Section	Topic	Page
2.1	Creating a Project in Control Expert	20
2.2	Using the Control Expert EtherNet/IP Configuration Tool	31
2.3	Configuring Network Channel Properties	39
2.4	Configuring the TCP/IP Address Settings	52
2.5	Configuring the EtherNet/IP Communication Module as an I/O Adapter	60

Section 2.1

Creating a Project in Control Expert

Overview

This section provides information about:

- selecting Quantum modules in Control Expert
- launching the Control Expert EtherNet/IP configuration tool


What Is in This Section?


This section contains the following topics:

Topic	Page
Creating a Project in Control Expert	21
Configuring the 140 NOC 771 00 Ethernet/IP Communication Module	23

Creating a Project in Control Expert

Use Control Expert to create a new project. The following steps describe a sample project created in Control Expert:

Step	Action
1	Open Control Expert.
2	In the Control Expert main menu, select File → New... . The New Project window opens displaying a list of Schneider-Electric controller types.
3	In the New Project window, open the Quantum sub-list and select a controller. In this example, the 140 CPU 651 60 controller is selected: 
4	Click OK . The Project Browser opens: 
5	In the Project Browser , double click Local Bus . Control Expert displays: <ul style="list-style-type: none"> • the Hardware catalog and • a Local Bus window with the selected CPU in the second position
6	In the Hardware catalog , do the following: <ul style="list-style-type: none"> • In the Supply section, use your mouse to select then drag a 140 CPS 114 10 115/230 VAC power supply to a position in the backplane—in this example, slot 1. • In the Communication section, drag a 140 NOC 771 00 EtherNet/IP communication module to a position in the backplane—in this example, slot 4.

Step	Action
7	<p>The modules that you have selected are now displayed in the backplane.</p>  <p>The screenshot shows a software window titled "Local Bus" with a dropdown menu set to "Bus: 1" and a filter "140 CPU 651 60 2.30". Below the menu is a backplane diagram with 16 slots. Slot 1 contains a CPS 511 00 module, slot 2 contains a CPU 651 60 module, and slot 4 contains a NOC 771 00 module. Slots 5 through 16 are empty. A yellow highlight is on slot 1, with a callout box containing the number "1".</p>
8	<p>To open the configuration window for the 140 NOC 771 00, do one of the following:</p> <ul style="list-style-type: none"> ● double click the left mouse button on the 140 NOC 771 00 module in the Local Bus window above, or ● click the right mouse button on the module, then select Open Module... in the popup menu <p>The module configuration window opens, where you can configure its properties.</p>

Configuring the 140 NOC 771 00 Ethernet/IP Communication Module

Overview


To configure properties for the 140 NOC 771 00, you need to:

- complete the Configuration page of the module properties window
- launch the Control Expert EtherNet/IP configuration tool, where you can complete the process of editing properties for EtherNet/IP modules and devices
- add the completed EtherNet/IP module and device edits to the Control Expert project configuration in the form of derived data types

The following steps present one example of how to configure the communication module. Your own configurations may differ.

Setting Input and Output Memory Addresses and Naming the Module

The Configuration page looks like this:



In the Configuration screen, perform the following steps to name the module, and to set addresses and sizes for both inputs and outputs:

Step	Action
1	<p>In the Project section, enter a name for your module in the Module name field. In this example, the name NOC1 is entered.</p> <p>Note: After the module name is entered and the EtherNet/IP configuration is validated (after clicking the Validate <input checked="" type="checkbox"/> button), the module name cannot be edited.</p>
2	<p>In the Input area and Output area type in the size and starting position of both the inputs and outputs. These values can later be edited. For this example, the following values are entered:</p> <p>In the Input area:</p> <ul style="list-style-type: none"> ● In the %MW index field, type in a starting address for inputs—in this example: 1. ● In the Max size field, type in the maximum number of 16-bit words dedicated to inputs—in this example: 100. <p>In the Output area:</p> <ul style="list-style-type: none"> ● In the %MW index field, type in a starting address for outputs—in this example: 101. ● In the Max size field, type in the maximum number of 16-bit words dedicated to outputs—in this example: 100. <p>Notes:</p> <ul style="list-style-type: none"> ● The inputs and outputs can be located at any available address and do not need to be located in adjacent areas. It is important only that the space allocated to inputs and outputs do not overlap. ● The specified %MW range for both inputs and outputs must be available in the CPU. For more information, refer to the Control Expert help file topic Processor Configuration Screen.
3	<p>In Control Expert select Edit → Validate (or click the Validate <input checked="" type="checkbox"/> button) to:</p> <ul style="list-style-type: none"> ● save the EtherNet/IP module name—which becomes a non-editable, read-only value ● save the address and size settings for inputs and outputs, and ● start up the EtherNet/IP configuration tool

Launching the EtherNet/IP Configuration Tool

After you have saved both the EtherNet/IP module name and the input and output settings, launch the EtherNet/IP configuration tool by clicking on the EtherNet/IP button:



The EtherNet/IP configuration tool opens for editing. If EtherNet/IP device configurations have previously been edited and saved, they will be displayed.


Use the EtherNet/IP configuration tool to configure:



- the EtherNet/IP module's:
 - channel properties (*see page 39*)
 - TCP/IP settings (*see page 52*)
 - local slave function (*see page 60*)
- remote EtherNet/IP devices, including:
 - the 140 NIC 2212 network interface module (*see page 87*)
 - third-party remote devices (*see page 114*)

NOTE: Only a single instance of the configuration tool can be open at any time.

Creating or Updating Derived Data Types

After all EtherNet/IP module edits have been saved in the EtherNet/IP configuration tool, add these edits to the Control Expert project, as follows:

Step	Action
1	<p>Return to the main screen in Control Expert and select the Configuration page of the EtherNet/IP configurable server module, below. Note that the Update application button is now enabled.</p> 
2	<p>Click the Update application button. Note: Every time you use the EtherNet/IP configuration tool to make edits, be sure to return to this screen and click the Update application button to save your edits to the Control Expert project.</p>


Step	Action																																																						
3	<p>The Control Expert software converts the EtherNet/IP configuration data to variables and derived data types, then prepares to import them into the Control Expert project. If any conflict exists between a newly created item and an existing one, Control Expert displays those conflicts in the Import Trouble Report, below:</p>  <table border="1" data-bbox="378 370 1039 570"> <thead> <tr> <th>Type</th> <th>Name</th> <th>New Name</th> <th>Keep</th> <th>Replace</th> <th>Rename</th> </tr> </thead> <tbody> <tr> <td>Duplicate DTT</td> <td>ST_NOC1_IN</td> <td>ST_NOC1_IN_0</td> <td></td> <td></td> <td>X</td> </tr> <tr> <td>Duplicate DTT</td> <td>ST_NOC1_IN_D...</td> <td>ST_NOC1_IN_D...</td> <td></td> <td></td> <td>X</td> </tr> <tr> <td>Duplicate DTT</td> <td>ST_NOC1_IN_D...</td> <td>ST_NOC1_IN_D...</td> <td></td> <td></td> <td>X</td> </tr> <tr> <td>Duplicate DTT</td> <td>ST_NOC1_OUT</td> <td>ST_NOC1_OUT_0</td> <td></td> <td></td> <td>X</td> </tr> <tr> <td>Duplicate DTT</td> <td>ST_NOC1_OUT...</td> <td>ST_NOC1_OUT...</td> <td></td> <td></td> <td>X</td> </tr> <tr> <td>Duplicate DTT</td> <td>ST_NOC1_OUT...</td> <td>ST_NOC1_OUT...</td> <td></td> <td></td> <td>X</td> </tr> <tr> <td>The variable exist...</td> <td>NOC1_IN</td> <td>NOC1_IN_0</td> <td></td> <td></td> <td>X</td> </tr> <tr> <td>The variable exist...</td> <td>NOC1_OUT</td> <td>NOC1_OUT_0</td> <td></td> <td></td> <td>X</td> </tr> </tbody> </table> <p>In this example, the Control Expert project configuration already includes the listed variables and derived data types.</p>	Type	Name	New Name	Keep	Replace	Rename	Duplicate DTT	ST_NOC1_IN	ST_NOC1_IN_0			X	Duplicate DTT	ST_NOC1_IN_D...	ST_NOC1_IN_D...			X	Duplicate DTT	ST_NOC1_IN_D...	ST_NOC1_IN_D...			X	Duplicate DTT	ST_NOC1_OUT	ST_NOC1_OUT_0			X	Duplicate DTT	ST_NOC1_OUT...	ST_NOC1_OUT...			X	Duplicate DTT	ST_NOC1_OUT...	ST_NOC1_OUT...			X	The variable exist...	NOC1_IN	NOC1_IN_0			X	The variable exist...	NOC1_OUT	NOC1_OUT_0			X
Type	Name	New Name	Keep	Replace	Rename																																																		
Duplicate DTT	ST_NOC1_IN	ST_NOC1_IN_0			X																																																		
Duplicate DTT	ST_NOC1_IN_D...	ST_NOC1_IN_D...			X																																																		
Duplicate DTT	ST_NOC1_IN_D...	ST_NOC1_IN_D...			X																																																		
Duplicate DTT	ST_NOC1_OUT	ST_NOC1_OUT_0			X																																																		
Duplicate DTT	ST_NOC1_OUT...	ST_NOC1_OUT...			X																																																		
Duplicate DTT	ST_NOC1_OUT...	ST_NOC1_OUT...			X																																																		
The variable exist...	NOC1_IN	NOC1_IN_0			X																																																		
The variable exist...	NOC1_OUT	NOC1_OUT_0			X																																																		
4	<p>If the Import Trouble Report opens, indicate how you want to treat each item. You can specify the following selections for each item, or for all items:</p> <ul style="list-style-type: none"> ● Keep: Keeps the component of the current project. ● Replace: Replaces the project component with the one from the import. ● Rename: Renames the imported component, allowing you to keep both components. 																																																						
5	<p>After you have determined how to treat each imported item, click OK.</p>																																																						
6	<p>After you click OK, the Project Browser displays the new or edited derived data types, below:</p> 																																																						



Viewing Derived Data Type Variables


When you clicked on the **Update application** button, Control Expert created a collection of derived data type variables. Use these variables to view the:

- status of all connections from the communication module to each remote device, where:
 - the status of all connections is displayed in an array of 16 bytes
 - each connection is represented by a single bit
 - a bit value of 1 indicates the connection is healthy
 - a bit value of 0 indicates the connection is lost, or the communication module can no longer communicate with the remote device
- value of input and output items you created using the Control Expert EtherNet/IP configuration tool
- value of attributes defined by the EDS file of a remote device
- amount of padding, representing the reserved input or output memory space for a remote device

To view these derived data type variables:

Step	Description
1	Return to the main screen in Control Expert.
2	<p>In the Project Browser open the branch Variables & FB Instances and double-click on the Derived Variables sub-branch.</p>  <p>The Data Editor window opens, displaying the Variables tab. A check mark appears in the DDT checkbox. (If not, select the DDT checkbox.)</p>

Step	Description																																																																																								
3	<p>The Status variable—describing the status of all connections—is found beneath the first device in the first position. To display the Status variable’s 16-byte array, expand the first device as depicted below</p>  <p>The screenshot shows the Data Editor window with the following table of variables:</p> <table border="1" data-bbox="381 412 1085 906"> <thead> <tr> <th>Name</th> <th>Type</th> <th>Address</th> <th>Value</th> </tr> </thead> <tbody> <tr> <td>NOC1_IN</td> <td>ST_NOC1_IN</td> <td>%MW1</td> <td></td> </tr> <tr> <td> Status</td> <td>ARRAY[0...15] OF BYTE</td> <td>%MW1</td> <td></td> </tr> <tr> <td> Status[0]</td> <td>BYTE</td> <td>%MW1</td> <td></td> </tr> <tr> <td> Status[1]</td> <td>BYTE</td> <td>%MW1</td> <td></td> </tr> <tr> <td> Status[2]</td> <td>BYTE</td> <td>%MW2</td> <td></td> </tr> <tr> <td> Status[3]</td> <td>BYTE</td> <td>%MW2</td> <td></td> </tr> <tr> <td> Status[4]</td> <td>BYTE</td> <td>%MW3</td> <td></td> </tr> <tr> <td> Status[5]</td> <td>BYTE</td> <td>%MW3</td> <td></td> </tr> <tr> <td> Status[6]</td> <td>BYTE</td> <td>%MW4</td> <td></td> </tr> <tr> <td> Status[7]</td> <td>BYTE</td> <td>%MW4</td> <td></td> </tr> <tr> <td> Status[8]</td> <td>BYTE</td> <td>%MW5</td> <td></td> </tr> <tr> <td> Status[9]</td> <td>BYTE</td> <td>%MW5</td> <td></td> </tr> <tr> <td> Status[10]</td> <td>BYTE</td> <td>%MW6</td> <td></td> </tr> <tr> <td> Status[11]</td> <td>BYTE</td> <td>%MW6</td> <td></td> </tr> <tr> <td> Status[12]</td> <td>BYTE</td> <td>%MW7</td> <td></td> </tr> <tr> <td> Status[13]</td> <td>BYTE</td> <td>%MW7</td> <td></td> </tr> <tr> <td> Status[14]</td> <td>BYTE</td> <td>%MW8</td> <td></td> </tr> <tr> <td> Status[15]</td> <td>BYTE</td> <td>%MW8</td> <td></td> </tr> <tr> <td> DEVICE_A</td> <td>ST_NOC1_IN_DEVICE_A</td> <td>%MW9</td> <td></td> </tr> <tr> <td> DEVICE_B</td> <td>ST_NOC1_IN_DEVICE_B</td> <td>%MW19</td> <td></td> </tr> <tr> <td>NOC1_OUT</td> <td>ST_NOC1_OUT</td> <td>%MW101</td> <td></td> </tr> </tbody> </table>	Name	Type	Address	Value	NOC1_IN	ST_NOC1_IN	%MW1		Status	ARRAY[0...15] OF BYTE	%MW1		Status[0]	BYTE	%MW1		Status[1]	BYTE	%MW1		Status[2]	BYTE	%MW2		Status[3]	BYTE	%MW2		Status[4]	BYTE	%MW3		Status[5]	BYTE	%MW3		Status[6]	BYTE	%MW4		Status[7]	BYTE	%MW4		Status[8]	BYTE	%MW5		Status[9]	BYTE	%MW5		Status[10]	BYTE	%MW6		Status[11]	BYTE	%MW6		Status[12]	BYTE	%MW7		Status[13]	BYTE	%MW7		Status[14]	BYTE	%MW8		Status[15]	BYTE	%MW8		DEVICE_A	ST_NOC1_IN_DEVICE_A	%MW9		DEVICE_B	ST_NOC1_IN_DEVICE_B	%MW19		NOC1_OUT	ST_NOC1_OUT	%MW101	
Name	Type	Address	Value																																																																																						
NOC1_IN	ST_NOC1_IN	%MW1																																																																																							
Status	ARRAY[0...15] OF BYTE	%MW1																																																																																							
Status[0]	BYTE	%MW1																																																																																							
Status[1]	BYTE	%MW1																																																																																							
Status[2]	BYTE	%MW2																																																																																							
Status[3]	BYTE	%MW2																																																																																							
Status[4]	BYTE	%MW3																																																																																							
Status[5]	BYTE	%MW3																																																																																							
Status[6]	BYTE	%MW4																																																																																							
Status[7]	BYTE	%MW4																																																																																							
Status[8]	BYTE	%MW5																																																																																							
Status[9]	BYTE	%MW5																																																																																							
Status[10]	BYTE	%MW6																																																																																							
Status[11]	BYTE	%MW6																																																																																							
Status[12]	BYTE	%MW7																																																																																							
Status[13]	BYTE	%MW7																																																																																							
Status[14]	BYTE	%MW8																																																																																							
Status[15]	BYTE	%MW8																																																																																							
DEVICE_A	ST_NOC1_IN_DEVICE_A	%MW9																																																																																							
DEVICE_B	ST_NOC1_IN_DEVICE_B	%MW19																																																																																							
NOC1_OUT	ST_NOC1_OUT	%MW101																																																																																							
4	<p>To determine which Status bit is mapped to a specific remote device:</p> <p>a In the Control Expert EtherNet/IP configuration tool, open the Properties window for a remote device.</p> <p>b Open the Connections page, and click on the General node, below:</p>  <p>The screenshot shows the 'Generic EDS' window with the 'Connections' tab selected. The 'Connections Parameters' table is as follows:</p> <table border="1" data-bbox="714 1208 1085 1344"> <thead> <tr> <th>Name</th> <th>Value</th> <th>Unit</th> <th>...</th> </tr> </thead> <tbody> <tr> <td>Connection Bit Health Offset</td> <td>1</td> <td></td> <td></td> </tr> <tr> <td>Request Packet Interval</td> <td>30</td> <td>ms</td> <td></td> </tr> <tr> <td>Time-out Multiplier</td> <td>x4</td> <td></td> <td></td> </tr> <tr> <td>Input T->O</td> <td></td> <td></td> <td></td> </tr> </tbody> </table> <p>c In the above example, the Connection Bit Health Offset value of 1 maps to the first bit in the first byte of the Status variable, which can be represented as <code>Status[0].1</code>.</p>	Name	Value	Unit	...	Connection Bit Health Offset	1			Request Packet Interval	30	ms		Time-out Multiplier	x4			Input T->O																																																																							
Name	Value	Unit	...																																																																																						
Connection Bit Health Offset	1																																																																																								
Request Packet Interval	30	ms																																																																																							
Time-out Multiplier	x4																																																																																								
Input T->O																																																																																									

Step	Description																																																																																					
5	<p>You can also use the Data Editor to display DDT variables. DDT variables are either:</p> <ul style="list-style-type: none"> ● input and output items you created using the Control Expert EtherNet/IP configuration tool, or ● attributes defined by the remote device's EDS file, or ● padding, representing the reserved but unused input or output memory space for a remote device <p>The Data Editor presents DDT variables in separate input and output groups, sorted by device, as shown below:</p>  <p>The screenshot shows the 'Data Editor' window with the following table of variables:</p> <table border="1" data-bbox="353 527 1075 899"> <thead> <tr> <th>Name</th> <th>Type</th> <th>Address</th> <th>Value</th> <th>Comment</th> </tr> </thead> <tbody> <tr> <td>NOC1_IN</td> <td>ST_NOC1_IN</td> <td>%MW1</td> <td></td> <td></td> </tr> <tr> <td> Status</td> <td>ARRAY[0...15] OF BYTE</td> <td>%MW1</td> <td></td> <td>Connection H...</td> </tr> <tr> <td> 1 DEVICE_A</td> <td>ST_NOC1_IN_DEVICE_A</td> <td>%MW9</td> <td></td> <td>Device DEV...</td> </tr> <tr> <td> 2 DEVICE_B</td> <td>ST_NOC1_IN_DEVICE_B</td> <td>%MW19</td> <td></td> <td>Device DEV...</td> </tr> <tr> <td> DeviceB_Health</td> <td>WORD</td> <td></td> <td></td> <td></td> </tr> <tr> <td> MotorSpeed1</td> <td>WORD</td> <td></td> <td></td> <td></td> </tr> <tr> <td> MotorSpeed2</td> <td>WORD</td> <td></td> <td></td> <td></td> </tr> <tr> <td> Padding0</td> <td>ARRAY[0...7] OF BYTE</td> <td></td> <td></td> <td>Padding</td> </tr> <tr> <td>NOC1_OUT</td> <td>ST_NOC1_OUT</td> <td>%MW101</td> <td></td> <td></td> </tr> <tr> <td> DEVICE_A</td> <td>ST_NOC1_OUT_DEVI...</td> <td>%MW101</td> <td></td> <td>Device DEV...</td> </tr> <tr> <td> DEVICE_B</td> <td>ST_NOC1_OUT_DEVI...</td> <td>%MW111</td> <td></td> <td>Device DEV...</td> </tr> <tr> <td> AnalogCH1</td> <td>WORD</td> <td>%MW111</td> <td></td> <td>Bit 0=Mod1_0...</td> </tr> <tr> <td> AnalogCH2</td> <td>WORD</td> <td>%MW112</td> <td></td> <td></td> </tr> <tr> <td> PressureVLV1</td> <td>WORD</td> <td>%MW113</td> <td></td> <td></td> </tr> <tr> <td> PressureVLV2</td> <td>WORD</td> <td>%MW114</td> <td></td> <td></td> </tr> <tr> <td> Padding0</td> <td>ARRAY[0...11] OF BYTE</td> <td>%MW115</td> <td></td> <td>Padding</td> </tr> </tbody> </table> <p>1 device names: user-created in the Control Expert EtherNet/IP configuration tool</p> <p>2 variable names: user-created as I/O items in the Control Expert EtherNet/IP configuration tool, or defined as a property by the EDS file of the remote device</p>	Name	Type	Address	Value	Comment	NOC1_IN	ST_NOC1_IN	%MW1			Status	ARRAY[0...15] OF BYTE	%MW1		Connection H...	1 DEVICE_A	ST_NOC1_IN_DEVICE_A	%MW9		Device DEV...	2 DEVICE_B	ST_NOC1_IN_DEVICE_B	%MW19		Device DEV...	DeviceB_Health	WORD				MotorSpeed1	WORD				MotorSpeed2	WORD				Padding0	ARRAY[0...7] OF BYTE			Padding	NOC1_OUT	ST_NOC1_OUT	%MW101			DEVICE_A	ST_NOC1_OUT_DEVI...	%MW101		Device DEV...	DEVICE_B	ST_NOC1_OUT_DEVI...	%MW111		Device DEV...	AnalogCH1	WORD	%MW111		Bit 0=Mod1_0...	AnalogCH2	WORD	%MW112			PressureVLV1	WORD	%MW113			PressureVLV2	WORD	%MW114			Padding0	ARRAY[0...11] OF BYTE	%MW115		Padding
Name	Type	Address	Value	Comment																																																																																		
NOC1_IN	ST_NOC1_IN	%MW1																																																																																				
Status	ARRAY[0...15] OF BYTE	%MW1		Connection H...																																																																																		
1 DEVICE_A	ST_NOC1_IN_DEVICE_A	%MW9		Device DEV...																																																																																		
2 DEVICE_B	ST_NOC1_IN_DEVICE_B	%MW19		Device DEV...																																																																																		
DeviceB_Health	WORD																																																																																					
MotorSpeed1	WORD																																																																																					
MotorSpeed2	WORD																																																																																					
Padding0	ARRAY[0...7] OF BYTE			Padding																																																																																		
NOC1_OUT	ST_NOC1_OUT	%MW101																																																																																				
DEVICE_A	ST_NOC1_OUT_DEVI...	%MW101		Device DEV...																																																																																		
DEVICE_B	ST_NOC1_OUT_DEVI...	%MW111		Device DEV...																																																																																		
AnalogCH1	WORD	%MW111		Bit 0=Mod1_0...																																																																																		
AnalogCH2	WORD	%MW112																																																																																				
PressureVLV1	WORD	%MW113																																																																																				
PressureVLV2	WORD	%MW114																																																																																				
Padding0	ARRAY[0...11] OF BYTE	%MW115		Padding																																																																																		

Section 2.2

Using the Control Expert EtherNet/IP Configuration Tool

Overview

This section describes the Control Expert EtherNet/IP configuration tool user interface. Use the configuration tool to enter settings for the EtherNet/IP communication module and for other devices connected to your EtherNet/IP network.

What Is in This Section?


This section contains the following topics:

Topic	Page
EtherNet/IP Configuration Tool User Interface	32
Devices Window	36
Configuring Properties in the Devices Window	37

EtherNet/IP Configuration Tool User Interface

Overview

The Control Expert EtherNet/IP configuration tool user interface presents the following parts:



- 1 Main menu
- 2 Description area
- 3 Workspace area
- 4 Devices window
- 5 I/O area
- 6 Output Message window

The parts of the EtherNet/IP user interface are briefly described below.

Main Menu

The Main menu area consists of:

- A main menubar with the following menu items and commands:

Menu item	Contains commands for...
File	<ul style="list-style-type: none"> • file management and printing • GUI display selections • online / offline operations
Library	managing EDS files in the Device Library
Network	<ul style="list-style-type: none"> • automatic detection of EtherNet/IP network devices • online actions, including: <ul style="list-style-type: none"> ○ explicit messaging ○ pinging network devices • commissioning devices via port configuration settings • working with automatically detected devices in the Network Detection area
Devices	working with devices in the Devices window, including: <ul style="list-style-type: none"> • displaying devices in the Devices window tree control • commissioning devices via port configuration settings • creating and configuring CIP connections for devices • diagnosing devices
Items	adding, deleting, and renaming inputs and outputs in the I/O area
Help	<ul style="list-style-type: none"> • displaying versioning information of the Control Expert EtherNet/IP configuration tool • online help

- 3 toolbars:

Toolbar	Contains commands that relate to...
Main toolbar	<ul style="list-style-type: none"> • file management and printing • GUI display selections
Devices toolbar	working with devices in the Devices window, including: <ul style="list-style-type: none"> • displaying devices in the Devices window tree control • commissioning devices • creating and configuring CIP connections for devices • diagnosing devices • online / offline operations
Items toolbar	adding, deleting, and renaming inputs and outputs in the I/O area

Description Area

The **Description** area describes the EtherNet/IP communication module and its IP address.

Workspace Area

The **Workspace** area consists of two tabs, containing the:

- Device Library, where you can:
 - view properties and EDS files for all available EtherNet/IP devices
 - add a new device and its EDS file to the Device Library
 - delete a device from the **Device Library**
 - manage the display of devices in the **Device Library** list
 - insert a selected device into the configuration in the **Devices** window
- Network Detection area, where you can:
 - automatically detect EtherNet/IP devices on the network
 - take online actions, including sending explicit messages and pinging network devices
 - view properties and EDS files for all available EtherNet/IP devices
 - insert a single selected device into the configuration in the **Devices** window
 - insert all detected device into the configuration in the **Devices** window, replacing all devices in the configuration

You can show or hide the workspace area using the **File** → **Preferences** → **Workspace** command.

Devices Window

The Devices window contains a tree control, containing all devices that have been added to your EtherNet/IP network configuration. In the **Devices** window, you can:

- display and edit the properties of selected EtherNet/IP devices, including:
 - EtherNet/IP communication modules
 - local slaves
 - remote devices
 - I/O modules
- commission devices
- create and configure CIP connections for devices
- open the I/O area and display individual inputs and outputs
- diagnose device connections

I/O Area

The I/O Area displays the configuration data for each input and output, including the:

- name
- data type
- offset within the device
- offset within the connection
- address where the I/O data is sent to, or sent from

The I/O area is displayed only when a device I/O connection is selected in the Devices window configuration.

Output Message Window


The **Output Message** window displays a sortable list of events. The Output Message window can be configured to show or hide each item's:

- date and time
- event level:
 - informational
 - warning
 - error

Devices Window

Overview

The **Devices** window is located in the center of the EtherNet/IP configuration tool's user interface and displays a node for each device in your network configuration. An example of the **Devices** window appears below:



Configurable Properties

The **Devices** window displays a node for each device—and for each device's configurable property group—in your network configuration. Each node is identified by an icon, as follows:

Node	Icon	This node is used to configure...
Channel		The properties of the EtherNet/IP module's communication channel.
TCP/IP		The EtherNet/IP communication module's IP addressing, SNMP and DHCP server settings.
Local slave		Properties related to the module's role as an I/O adapter to a remote device acting in the role of I/O scanner.
Device		The properties of any EtherNet/IP network device with an IP address, including both modular and non-modular devices.
Items collection		The name assigned to a group of I/O items.
Item		The properties of a CIP connection between the EtherNet/IP communication module and individual I/O items. If the type of connection is: <ul style="list-style-type: none"> ● rack optimized: click on the connection in the first position to display all rack optimized I/O items. ● direct: click on a connection for any position to display the I/O items for that connection.
Chassis		The properties of a chassis that is part of a modular device.
Module		The parameters of an I/O module that is part of a modular device.

Configuring Properties in the Devices Window

Overview

Use the **Devices** window, in the Control Expert EtherNet/IP configuration tool, to display and configure properties for the EtherNet/IP communication module and other devices on your EtherNet/IP network.

To configure properties, double-click on the Devices window node associated with the properties (*see page 36*) you want to configure.

For example, to configure the EtherNet/IP communication module network channel properties, double-click on the channel icon  to display the **Channel Properties** window. When the window first opens, it displays 2 tabbed pages:


- General (the default tab)
- Ethernet

Note that the Channel Properties window can also display 2 additional pages:

- Ethernet/IP, by operating in Advanced mode (**File** → **Preferences** → **Advanced**)
- Module Information, by operating online (**File** → **Go Online**)

Displaying Property Values

Most property windows let you display a description of a selected property. Select a property in the **Name** column to display a brief description of the selected property in the **Description** area at the bottom of the window:




Property Types

Properties can be either read/write or read-only, as indicated by its icon:

This icon...	Indicates the property is...
	Read-only. This property value is locked and cannot be edited.
	Read-write. This property value can be edited.

Editing Property Values

To edit a read-write property value, follow these steps:

Step	Action
1	Select a read-write property.
2	<p>There are two ways to perform an edit:</p> <ul style="list-style-type: none"> ● Double-click the left mouse button on the property name. ● Click the ellipsis (...) button located at the right of the list header bar, then select Properties in the popup menu. <p>A window opens—in this case for the Baud Rate property—where you can edit the parameter value:</p>  <p>Note: Some other properties are editable by typing in a value within a stated range.</p>
3	After completing your edits click OK to close the Properties window and save your edits.

Section 2.3

Configuring Network Channel Properties

Overview

This section describes how to configure network channel properties with the EtherNet/IP configuration tool.

What Is in This Section?

This section contains the following topics:

Topic	Page
Configuring Channel Properties: The General page	40
Configuring Channel Properties: The Ethernet page	43
Configuring Channel Properties: The EtherNet/IP page	44
Configuring Channel Properties: The Module Information page	46


Configuring Channel Properties: The General page

The General Page

The **General** page of the **Channel Properties** window displays read-only properties that describe the:

- EtherNet/IP communication module name
- size and location of inputs and outputs
- size of the EtherNet/IP configuration

The module's property values are set by the communication module's EDS file, the configuration design, and settings entered in the **Configuration** page of Control Expert for the EtherNet/IP communications module.



NOTE: Refer to the topic *Configuring Properties in the Devices Window* ([see page 37](#)) for information on how to display property descriptions and edit property values.

Properties

Name	Description	Value set by...
Module Name		
Module Name	The name of the EtherNet/IP module	Configuration page in Control Expert
Input		
Input Offset	The starting address for inputs (%MW index)	Configuration page in Control Expert
Input Reserved Size	The total number of words configured for inputs (Max size)	Configuration page in Control Expert
Input Current Size	The actual number of inputs used in the application	network design in the configuration tool's Devices window
Output		
Output Offset	The starting address for outputs (%MW index)	Configuration page in Control Expert
Output Reserved Size	The total number of words configured for outputs (Max size)	Configuration page in Control Expert
Output Current Size	The actual number of outputs used in the application	network design in the configuration tool's Devices window
Note: When configuring an offset and a reserved size for both inputs and outputs, be sure that inputs and outputs do not overlap.		
Configuration Size		
Maximum Number of Devices	The maximum number of devices that can be added to the configuration.	predefined
Current Number of Devices	The number of devices currently in the configuration.	network design in the configuration tool's Devices window
Maximum Number of Connections	The maximum number of connections that can be managed by the module.	predefined
Current Number of Connections	The number of connections in the configuration.	network design in the configuration tool's Devices window
Maximum Number of Packets	The maximum number of packets per second the module is able to manage.	predefined
Current Number of Packets	The number of packet/s that will be generated by the current configuration.	network design in the configuration tool's Devices window


Name	Description	Value set by...
PLC Scan Time		
Minimum PLC Scan Time	The estimated cycle time to process inputs and outputs, equal to the sum of estimates for communication over both the backplane and the network.	predefined
Module Exchange Time	The estimated additional time contributed by the EtherNet/IP module to perform the I/O management. This value is included in the "minimum PLC scan time" value.	predefined

Configuring Channel Properties: The Ethernet page

The Ethernet Page

Use the **Ethernet** page of the **Channel Properties** window to:

- view and edit the **Baud Rate**
- view the **Frame format**



NOTE: Refer to the topic [Configuring Properties in the Devices Window](#) (*see page 37*) for information on how to display property descriptions and edit property values.

Properties

Name	Description	Type
Baud Rate	<p>The transmission speed and duplex mode for the configuration. To change these settings, double-click on the field name and select one of the following:</p> <ul style="list-style-type: none"> • Auto 10/100 Mb (the default) • 10 Mb Half duplex • 10 Mb Full duplex • 100 Mb Half duplex • 100 Mb Full duplex <p>Note: The default setting—Auto 10/100 Mb—is recommended. It causes the connected devices to perform auto-negotiation and thereby determine the fastest common transmission rate and duplex mode.</p>	Read-Write
Frame Format	Ethernet II is the only frame format available for this module.	Read-Only

Configuring Channel Properties: The EtherNet/IP page


The EtherNet/IP Page

Use the **EtherNet/IP** page of the **Channel Properties** window to configure:

- properties that determine how the EtherNet/IP communication module, in its role as an I/O scanner, opens both implicit and explicit connections
- the frequency for transmitting produced data over implicit connections
- the timeout period for explicit connections
- the behavior of the module, in its role as an I/O scanner, when:
 - the application is stopped, or
 - the EtherNet/IP module receives a reset service request

NOTE: This page is displayed only when you are using Advanced Mode. Advanced mode properties are indicated by the  icon.

To turn on Advanced Mode, select: **File** → **Preferences** → **Advanced**



NOTE: Refer to the topic *Configuring Properties in the Devices Window* ([see page 37](#)) for information on how to display property descriptions and edit property values.

Configuring EtherNet/IP Properties

Note: Only an experienced developer of EtherNet/IP networks should edit any of the following read-write properties.

Name	Description
Timeout	
FW_Open IO Connection Timing	The amount of time the EtherNet/IP module waits for the Forward_Open IO messaging transaction to open an implicit messaging connection. Default = 5000 ms
FW_Open EM Connection Timing	The amount of time the EtherNet/IP module waits for the Forward_Open IO messaging transaction to open an explicit messaging connection. Default = 3000 ms
EM Connected RPI	The value used to set the T->O (target to originator) and O->T (originator to target) requested packet interval (RPI) for all explicit message connections. This value is used to calculate the lifetime of a connection. Default = 10000 ms.
EM Request Timeout	The amount of time the EtherNet/IP module waits between a request and reply of an explicit message. Default =10 s.
Output	
STOP Behavior	The state of the EtherNet/IP module when the CPU application goes into a STOP state: <ul style="list-style-type: none"> ● TRUE indicates that the module enters STOP state (implicit connections are closed). ● FALSE indicates that the module enters IDLE state (implicit connections are not closed). Default = FALSE
Allow Reset Explicit Message	The behavior of the EtherNet/IP module—as I/O scanner—when it receives a reset service request: <ul style="list-style-type: none"> ● TRUE indicates the module resets itself. ● FALSE indicates the module ignores the reset service request and continues uninterrupted operations. Default = FALSE

Configuring Channel Properties: The Module Information page

The Module Information Page


Use the **Module Information** page of the **Channel Properties** window to display properties obtained from the EtherNet/IP communication module. In this page you can:

- retrieve data from the module's EDS file
- display retrieved module data by a selected object group, including data relating to the module's:
 - Identity
 - Connection Manager
 - TCP/IP Interface
 - Ethernet Link
- refresh data

NOTE:

- This page is displayed only when the Control Expert EtherNet/IP configuration tool is operating online. To operate online, select **File** → **Go Online**.
- All object groups are displayed only when you are operating in Advance mode. To operate in Advance mode, select **File** → **Preferences** → **Advance**.

Displaying module information is a 3-step process, as described below:



NOTE: Refer to the topic [Configuring Properties in the Devices Window](#) (*see page 37*) for information on how to display property descriptions and edit property values.

Step 1	Select a property type in the Object list: <ul style="list-style-type: none"> ● identity ● Connection Manager ● TCP/IP Interface ● Ethernet Link
Step 2	Click the Get Information from Module button to populate property data.
Step 3	Periodically click the Refresh Module button to update property data.

Identity Properties and Status

After selecting **Identity**, the following information is displayed.

Property	Description
Identification	
Vendor ID	243
Device Type	12
Product Code	1025
Revision	The revision number of the device
Serial Number	The serial number of the device.
Product Name	140 NOC77100
Status	
Owned	A TRUE setting indicates that the device (or an object within the device) has an owner. The setting of this bit means that the Predefined Master/Slave Connection Set has been allocated to a master.
Configured	A TRUE setting indicates that the application of the device has been configured to do something different than the out-of-the-box default. This does not include configuration of the communications.
Extended Device Status	The vendor-specific or already defined status.
Major Unrecoverable Fault	A TRUE setting indicates the device detected a problem with itself, which caused the device to go into the Major Unrecoverable Fault state.
Major Recoverable Fault	A TRUE setting indicates the device detected a problem with itself, which caused the device to go into the Major Recoverable Fault state.
Minor Unrecoverable Fault	A TRUE setting indicates the device detected a problem with itself, which is thought to be unrecoverable. The problem does not cause the device to go into one of the faulted states.
Minor Recoverable Fault	A TRUE setting indicates the device detected a problem with itself, which is thought to be recoverable. The problem does not cause the device to go into one of the faulted states.

Connection Manager Properties

After selecting **Connection Manager**, the following information is displayed.

Property	Description
Open Counters	
Open Requests	The number of forward open service requests received.
Format Rejects	The number of forward open service requests which were rejected due to bad format.
Resource Rejects	The number of forward open service requests which were rejected due to lack of resources.
Other Rejects	The number of forward open service requests which were rejected for reasons other than bad format or lack of resources.
Close Counters	
Close Requests	The number of forward close service requests received.
Format Rejects	The number of forward close service requests which were rejected due to bad format.
Other Rejects	The number of forward close service requests which were rejected for reasons other than bad format.
Other Counters	
Connection TimeOuts	The total number of connection timeouts that have occurred in connections controlled by this Connection Manager
Numbers of Connection	The number of connections.

TCP/IP Interface Properties

After selecting **TCP/IP Interface**, the following information is displayed. Not all properties apply to the module.

Property	Description
Status	Indicates the status of the configuration: <ul style="list-style-type: none"> ● 0 = not configured ● 1 = a valid configuration acquired from BOOTP or nonvolatile storage
Configuration Capability	<ul style="list-style-type: none"> ● BOOTP Client Indicates that the device is capable of acquiring its network configuration via BOOTP. ● Configuration Settable Indicates that the configuration is settable.
Startup Configuration	Determines how the device acquires its initial configuration at startup. Note: If the device was previously configured, it uses the previously stored interface configuration values.
IP Address	The device IP address. A 0.0.0.0 address indicates an IP address has not been configured.
Network Mask	The device network mask. A 0.0.0.0 address indicates a network mask address has not been configured.
Gateway Address	The default gateway address. A 0.0.0.0 address indicates a gateway address has not been configured.
Primary Name Server Address	(not applicable)
Secondary Name Server Address	(not applicable)
Domain Name	(not applicable)
Host Name	(not applicable)
Safety Network Number	(not applicable)
TTL Value	The value that the device uses for the IP header's Time-to-Live field when sending packets via IP an multicast.
Multicast Address Allocation Control	This determines how the device shall allocate IP multicast addresses. If set to: <ul style="list-style-type: none"> 0 - Multicast addresses are generated using the default allocation algorithm. 1 - Multicast addresses are allocated according to the values specified in the two following parameters.
Number of IP Multicast Addresses Allocated	The number of IP multicast addresses that are allocated.
Starting Multicast IP Address	The starting multicast address from which allocation begins.

Ethernet Link Properties

After selecting **Ethernet Link**, the following information is displayed.

Property	Description
General	
Interface Speed	The interface speed currently in use. A 0 is shown if the speed has not been determined.
Link Status	Indicates whether or not the Ethernet communication interface is connected to an active network.
Duplex Mode	Indicates that duplex mode currently in use.
Negotiation Status	Indicates the status of link auto-negotiation. If set to: 0 - Auto-negotiation in progress. 1 - Auto-negotiation and speed detection has failed. Default values for speed and duplex are being used. 2 - Auto negotiation has failed but the speed has been detected. Duplex was defaulted. The default value is product-dependent; recommended default is half duplex. 3 - Successfully negotiated speed and duplex. 4 - Auto-negotiation was not attempted. Speed and duplex has been forced.
Manual Setting Requires Reset	If set to: 0 - The interface can activate changes to link parameters (auto-negotiate, duplex mode, interface speed) automatically. 1 - The device requires a reset service be issued to its Identity Object in order for the changes to take effect.
Local hardware Fault	A local hardware fault.
Physical Address	The MAC layer address.
Input	
Octets	The number of octets received on the interface.
Ucast Packets	The number of subnetwork-unicast packets delivered to a higher-layer protocol.
NUcast Packets	The number of non-unicast packets delivered to a higher-layer protocol.
Discards	The number of inbound packets which were chosen to be discarded even though no errors had been detected to prevent their being deliverable to a higher-layer protocol.
Errors	The number of inbound packets that contained errors preventing them from being deliverable to a higher-layer protocol.
In Unknown Protocols	The number of packets received via the interface which were discarded because of an unknown or unsupported protocol.

Property	Description
Output	
Octets	The number of octets sent on the interface.
Ucast Packets	The total number of packets that higher-level protocols requested be transmitted to a subnetwork-unicast address.
NUcast Packets	The total number of packets that higher-level protocols requested be transmitted to a non-unicast address.
Discards	The number of outbound packets which were chosen to be discarded even though no errors had been detected to prevent their being transmitted.
Errors	The number of outbound packets that could not be transmitted because of errors.
Error Counters	
Alignment Errors	The number of frames received on this interface that are not an integral number of octets in length and do not pass the FCS check.
FCS Errors	The number of frames received on this interface that are an integral number of octets in length but do not pass the FCS check.
Single Collisions	The number of successfully-transmitted frames on this interface for which transmission is inhibited by exactly one collision.
Multiple Collisions	The number of successfully-transmitted frames on this interface for which transmission is inhibited by more than one collision.
SQE Test Errors	The number of times a SQE test error message has been generated.
Deferred Transmissions	The number of frames for which the first transmission attempt on this interface has been delayed because the medium is busy.
Late Collisions	The number of times a collision is detected later than 512 bit-times into the transmission of a packet.
Excessive Collisions	The number of frames for which transmission on this interface has failed due to excessive collisions.
MAC Transmit Errors	The number of frames for which transmission on this interface has failed due to an internal MAC sublayer transmit error.
Carrier Sense Errors	The number of times that the carrier sense condition was lost or never asserted when attempting to transmit a frame on this interface.
Frame Too Long	The number of frames received on this interface that exceeded the maximum permitted frame size.
MAC Receive Errors	The number of frames for which reception on the interface has failed due to an internal MAC sublayer receive error.

Section 2.4

Configuring the TCP/IP Address Settings

Overview

This section provides information about how to configure the TCP/IP address settings for the EtherNet/IP communication module.

What Is in This Section?

This section contains the following topics:


Topic	Page
TCP/IP Properties: The General Page	53
TCP/IP Properties: Configuring the SNMP Agent	55
TCP/IP Properties: Configuring the DHCP Server	57

TCP/IP Properties: The General Page

The General Page

Use the **General** page of the **TCP/IP** properties window to configure the IP address of the EtherNet/IP communication module.

Open the **TCP/IP** properties window by clicking on the TCP/IP  icon in the **Devices** window.



NOTE: Refer to the topic [Configuring Properties in the Devices Window](#) (*see page 37*) for information on how to display property descriptions and edit property values.

Selecting a Configuration Mode

Use the **Configuration** list to specify a configuration mode. The configuration mode setting determines how the module obtains its IP address at startup. Choices are:

Configuration Mode	Description
Static	The module uses the module IP address, gateway IP address, and sub-network mask configured in this page.
Flash Memory	The module uses the IP address configured via the TCP/IP object and stored flash memory. An IP address configured by this process survives a warm re-start (during which power to the device is continuously maintained), but is lost in the case of a cold re-start (where power to the device is turned off for a time).
BOOTP	The module uses an IP address assigned by a BOOTP server.

Setting the Module Addresses in Static Mode

Three IP address properties need to be configured for the EtherNet/IP communication module in static configuration mode:

Property	Description
Module IP Address	The 32-bit identifier—consisting of both a network address and a host address—assigned to a device connected to a TCP/IP Internet network using the Internet Protocol (IP).
Gateway Address	The address of a device, if any, that serves as a gateway to the EtherNet/IP module.
Sub-Net Mask	The 32-bit value used to hide (or mask) the network portion of the IP address and thereby reveal the host address of a device on a network using the IP protocol.

Default Address Configurations

The module uses a default address configuration when it is not configured or when a duplicate IP address is detected. The default address is based on the MAC address of the module and makes it possible for several Schneider devices to use their default network configuration on the same network.

The module uses the following default address configurations.

- Default IP Address
This default address starts with 10.10 and uses the last two bytes of the MAC address. As an example, a device with the MAC address of 00:00:54:10:8A:05 has a default IP address of 10.10.138.5 (0x8A=138, 0x05=5).
- Default Subnet Mask
The default address is 255.0.0.0 (a class A mask).
- Default Gateway Address
The default gateway address is identical to the default IP address.

Duplicate Address Checking

Before going online, the module sends out at least four ARP (Address Resolution Protocol) messages with a proposed IP address.

- If an answer is returned
 - There is a device already using the IP address.
 - The module will not use the proposed IP address and uses the default IP address.
- If an answer is not returned
 - The module uses the IP address (along with the associated network parameters.)

TCP/IP Properties: Configuring the SNMP Agent


The SNMP page

Use the SNMP page of the TCP/IP properties window to configure the SNMP agent (*see page 138*) in the EtherNet/IP communication module. An SNMP agent is a software component that reports management data about the module to another device acting as an SNMP manager.

The SNMP agent can connect to and communicate with up to 2 SNMP managers as part of an SNMP service. The SNMP service includes:

- authentication checking, by the EtherNet/IP communication module, of any SNMP manager that sends SNMP requests
- management of event, or trap, reporting by the module

Click on the SNMP tab to access the SNMP agent window:



NOTE: Refer to the topic *Configuring Properties in the Devices Window* (*see page 37*) for information on how to display property descriptions and edit property values.

Viewing and Configuring SNMP Properties

The following properties can be viewed and edited in the SNMP page:

Property	Description
Manager IP Addresses:	
IP Address of the Manager 1	The IP address of the first SNMP manager to which the EtherNet/IP module's SNMP agent sends notices of traps.
IP Address of the Manager 2	The IP address of the second SNMP manager to which the module's SNMP agent sends notices of traps.
Agent:	
SNMP Manager	Select either: <ul style="list-style-type: none"> ● TRUE: the Location and Contact information is provided by a network management tool ● FALSE: Location and Contact settings are made in this window
Location	The device location (32 characters maximum)
Contact	Information describing the person to contact for device maintenance (32 characters maximum)
Community Names:	
Get	Password required by a MIB-II SNMP agent authorizing read commands from an SNMP manager. Default = Public .
Set	Password required by a MIB-II SNMP agent authorized write commands from an SNMP manager. Default = Public
Trap	Password a MIB-II SNMP manager requires from an SNMP agent causing the SNMP manager to accept trap notices from the SNMP agent. Default = Public
Security:	
Authorize Trap on Authentication Error	Causes the SNMP agent to send a trap notice to the SNMP manager if an unauthorized manager sends a Get or Set command to the agent. Default = FALSE .

TCP/IP Properties: Configuring the DHCP Server

The DHCP Client List Page

The EtherNet/IP communication module can be configured to perform the function of DHCP server. Connected network devices can subscribe to this DHCP service and obtain their IP parameters from the module.


Use this page to:

- enable and disable the DHCP service, and
- view a list of all network devices indicating whether each connected network device does—or does not—subscribe to the DHCP service

NOTE: The DHCP service is not enabled or disabled for a specific network device in this page. See the topic [Enabling the DHCP Service \(see page 58\)](#), below, for information on how to enable the DHCP service for a specific device.

Viewing the DHCP Client List

The **DHCP Client List** includes a row for each networked EtherNet/IP device, identifying the devices that have subscribed to the DHCP service:





The list contains the following information for each networked device:

Property	Description
Number	The number assigned to the device in the EtherNet/IP configuration tool.
IP Address	The device IP address associated with the device.
Enable DHCP	TRUE indicates that the device subscribes to the DHCP service.
Identifier Type	Indicates the mechanism used by the server to recognize the client (MAC address or DHCP device name).
Identifier	The actual MAC address or DHCP device name.

Enabling the DHCP Service

The DHCP service for an EtherNet/IP device is not enabled in this page. Instead it is enabled and disabled in the remote EtherNet/IP device configuration. To turn on the DHCP service for a specific device, follow these steps:

Step	Action
1	<p>In the Control Expert EtherNet/IP configuration tool, select the DHCP client device in the Devices window. In this example, the selected client is an STB_NIC_2212:</p> 
2	<p>Select Devices → Properties. The General page of the Properties window opens for the selected device, indicating the DHCP client service is disabled (the default setting).</p> 

Step	Action								
3	In the Network Properties area, under the heading DHCP Relation , configure the following properties:								
	<table border="1"><thead><tr><th data-bbox="360 264 679 297">Property:</th><th data-bbox="679 264 1245 297">Action:</th></tr></thead><tbody><tr><td data-bbox="360 297 679 329">Enable DHCP</td><td data-bbox="679 297 1245 329">Select TRUE.</td></tr><tr><td data-bbox="360 329 679 427">DHCP Client Identifier</td><td data-bbox="679 329 1245 427">Select either:<ul style="list-style-type: none">● MAC Address, or● Device Name</td></tr><tr><td data-bbox="360 427 679 492">Mac Address/Device Name</td><td data-bbox="679 427 1245 492">Enter a value for either the device name or the MAC Address.</td></tr></tbody></table>	Property:	Action:	Enable DHCP	Select TRUE .	DHCP Client Identifier	Select either: <ul style="list-style-type: none">● MAC Address, or● Device Name	Mac Address/Device Name	Enter a value for either the device name or the MAC Address.
	Property:	Action:							
	Enable DHCP	Select TRUE .							
DHCP Client Identifier	Select either: <ul style="list-style-type: none">● MAC Address, or● Device Name								
Mac Address/Device Name	Enter a value for either the device name or the MAC Address.								
Select TRUE .									
Select either: <ul style="list-style-type: none">● MAC Address, or● Device Name									
Enter a value for either the device name or the MAC Address.									
4	Click OK to close the device's Properties window and save your edits.								

Section 2.5

Configuring the EtherNet/IP Communication Module as an I/O Adapter

Overview

This section describes how to configure the EtherNet/IP communication module as an I/O adapter (local slave). In this role, the module initiates no messages. Instead, it responds to:

- implicit messaging requests from a remote device for periodic data, at the established RPI rate, and
- explicit messaging requests from other EtherNet/IP devices on the network

What Is in This Section?


This section contains the following topics:

Topic	Page
Identifying the Local Slave	61
Local Slave Inputs and Outputs	62
Configuring Local Slave Properties: The General page	64

Identifying the Local Slave

Overview

When the Control Expert EtherNet/IP configuration tool first opens, it automatically includes a Local Slave node in the **Devices** window:



Key Features

Features	Description
Types of connection	<ul style="list-style-type: none"> • Multicast Point to point is supported in both directions: O->T (Originator to Target) and T->O (Target to Originator) • Real time format 32 bit run/idle header, zero data length, none and heartbeat • Trigger T->O (Target to Originator) cyclic
Sizes	<ul style="list-style-type: none"> • Input sizes From 1 to 505 bytes • Output sizes From 1 to 509 bytes • Configuration size 0 words (read-only)

Local Slave Inputs and Outputs


The EtherNet/IP communication module can be used as an I/O adapter. To enable this functionality, select **Active Configuration** in the **Local Slave** properties window (*see page 64*).

When the local slave function of an EtherNet/IP communication module is enabled, the module's CIP objects (*see page 177*) are exposed to, and can be accessed by, other EtherNet/IP devices.

The I/O data exchange, between the remote device and the local slave, is configured as part of the remote scanning module's configuration settings.


In the following example:

- module A acts as both:
 - an I/O scanner of the Advantys STB I/O adapter, and
 - an I/O adapter, with its CIP objects accessible to remote EtherNet/IP devices
- module B acts as an I/O scanner of the local slave function of module A. Module B can access the exposed CIP objects of module A. The I/O data exchange between module B and module A is configured in the settings for module B.



Configuring the Connection

The I/O data exchange between module B (in its role as an I/O scanner) and module A (in its role as an I/O adapter) is configured in the settings for module B. Do this in the **Connections** page of the remote EtherNet/IP communication module—here, module B—**Properties window**:



Configuring the I/O Items

You can configure input and output items in groups of 1 or more single bits, 8-bit bytes, 16-bit words, 32-bit dwords, or 32-bit IEEE floating values. The number of items you create depends upon the data type and size of each item.

The process for creating and defining I/O items for the local slave are the same as for any I/O adapter, and depend upon the type of item you wish to create.

For an I/O configuration example, see the how the following I/O items were configured for the STB NIC 2212 network interface module:

- discrete input items ([see page 102](#))
- numeric input items ([see page 108](#))
- discrete output items ([see page 105](#))
- numeric output items ([see page 111](#))

Configuring Local Slave Properties: The General page

The General Page


Use the **General** page to configure the EtherNet/IP communication module to serve as an I/O adapter to a remote device.

The following steps describe a sample configuration of the local slave function. Your configuration may be different.

Configuring the Local Slave

To configure the local slave function, follow these steps:

Step	Action
1	<p>In the Devices window, right click on the EtherNet/IP Local Slave icon, then select Properties in the popup menu.</p>  <p>The General page of the Local Slave properties window opens.</p>

Step	Action
2	<p>Enter settings (refer to the table below) for the following parameters to configure local slave functionality for the EtherNet/IP module.</p>  <p>Note: When using explicit messaging to read the EtherNet/IP module's assembly object, be sure to allocate sufficient room for the response, because the size of the response will equal the sum of: the size of the assembly + Reply service (1 byte) + General Status (1 byte) Local slave properties are described, below.</p>
3	The next task is to configure slave inputs and outputs.

Local Slave Properties

The following property settings have been made in this example.:

Setting	Description
Device Designation section:	
Active Configuration	<ul style="list-style-type: none"> ● A selected checkbox indicates the local slave service is enabled. ● A de-selected checkbox indicates the local slave service is disabled and the current local slave service settings are saved. <p>In this example, this setting is selected.</p>
Device Name	Assign the local slave a unique name, consisting of up to 32 characters, including numbers, letters, and the underscore character. In this example, the auto-generated name DEVICE_A is accepted.
Number	The unique number—or identifier—assigned to the device. In this example, select the number 001 .
Comment	User-defined free text comment area. 80 characters maximum. In this example, leave blank.
Connection Health Bit Offset	Auto-generated integer (0...127) indicating the offset of the connection's health bit in the status byte array of the input area. Note: This setting is auto-generated only when the local slave settings are input and the network configuration is saved.
Assembly Instances section:	
<ul style="list-style-type: none"> ● O indicates the originator—or I/O scanner—device ● T indicates the target—or I/O adapter—device 	
Outputs T -> O Instance	A read-only value always set to 101.
Outputs T -> O Size	The maximum size reserved for local slave outputs, in bytes. An integer from 0...509. In this example, accept the default of 256 .
Inputs O -> T Instance	A read-only value always set to 102.
Inputs O -> T Size	The maximum size reserved for local slave inputs, in bytes. An integer from 0...509. In this example, accept the default of 256 .
Configuration Instance	A read-only value always set to 103 .
Configuration Size	A read-only value always set to 0 .

Chapter 3

Adding Devices to an EtherNet/IP Network

Overview

This chapter presents examples of how to add devices to, and how to configure these device for operations on, your EtherNet/IP network.

What Is in This Chapter?

This chapter contains the following sections:

Section	Topic	Page
3.1	Adding Devices to an EtherNet/IP Network	68
3.2	Adding and Configuring Remote Devices	72
3.3	Configuring the STB NIC 2212	87
3.4	Connecting to Third Party Devices	114

Section 3.1

Adding Devices to an EtherNet/IP Network

Effect of Device Position on Input and Output %MW Memory Addresses

Introduction

The Control Expert EtherNet/IP configuration tool assigns a %MW memory address to the Inputs and outputs of a remote device, or a local slave, when it is activated.

By default:

- a remote EtherNet/IP device is activated when it is added to an EtherNet/IP network, but
- the EtherNet/IP communication module's local slave function is not activated when it is automatically added to a newly created network; instead, it must be manually activated

This topic describes:

- the effect of activating the local slave on the %MW memory address assignment for inputs and outputs of previously configured EtherNet/IP network
- recommended practices to follow for consistent %MW memory address assignment to remote device inputs and outputs

Activating the Local Slave

When a new network is created, the Control Expert EtherNet/IP configuration tool adds a local slave node and—by default—assigns it the device **Number** of 000. Because the local slave function is not yet activated, the local slave's inputs and outputs are not initially assigned a %MW memory address.

The following example describes the effect of activating the EtherNet/IP communication module's local slave function after another remote device has already been configured and added to the network.


The sample EtherNet/IP network consists only of two nodes:

- the de-activated local slave at position 000
- a single, activated remote device at position 000


The sample EtherNet/IP network has been configured as follows:

- Total EtherNet/IP network inputs and outputs are set in the **Configuration** page of the EtherNet/IP communication module in Control Expert:
 - 100 input words are reserved, beginning at %MW01
 - 100 output words are reserved, beginning at %MW101
- Local Slave inputs and outputs:
 - 130 input bytes (65 words) are reserved
 - 130 output bytes (65 words) are reserved
- Remote device inputs and outputs:
 - 40 input bytes (20 words) are reserved
 - 40 output bytes (20 words) are reserved

The **Devices** window of the Control Expert EtherNet/IP configuration tool displays the network, as follows:




When you select the I/O Items node for the remote device, as indicated above, you display its previously configured input and output items—revealing their %MW memory address assignments:



Input Item Name	Data Type	Offset/Device	Offset/Connection	Position in Byte	Address
NICstatus_Ix0	Input bit	0	0	0	%MW1.0
NICstatus_Ix1	Input bit	0	0	1	%MW1.1
NICstatus_Ix2	Input bit	0	0	2	%MW1.2
NICstatus_Ix3	Input bit	0	0	3	%MW1.3
NICstatus_Ix4	Input bit	0	0	4	%MW1.4
NICstatus_Ix5	Input bit	0	0	5	%MW1.5
NICstatus_Ix6	Input bit	0	0	6	%MW1.6

Output Item Name	Data Type	Offset/Device	Offset/Connection	Position in Byte	Address
DDO9200_outputdata_QX0	Output bit	0	0	0	%MW101.0
DDO9200_outputdata_QX1	Output bit	0	0	1	%MW101.1
DDO9410_outputdata_QX2	Output bit	0	0	2	%MW101.2
DDO9410_outputdata_QX3	Output bit	0	0	3	%MW101.3
DDO9410_outputdata_QX4	Output bit	0	0	4	%MW101.4
DDO9410_outputdata_QX5	Output bit	0	0	5	%MW101.5
DDO9600_outputdata_QX8	Output bit	1	1	0	%MW101.8
DDO9600_outputdata_QX9	Output bit	1	1	1	%MW101.9
DDO9600_outputdata_QX10	Output bit	1	1	2	%MW101.10
DDO9600_outputdata_QX11	Output bit	1	1	3	%MW101.11
DDO9600_outputdata_QX12	Output bit	1	1	4	%MW101.12
DDO9600_outputdata_QX13	Output bit	1	1	5	%MW101.13
AVO1250_CH1_outputdata_	Output word	2	2		%MW102
AVO1250_CH2_outputdata_	Output word	4	4		%MW103

If you next activate the local slave function, by selecting **Active Configuration** in the **General** page of its **Properties** window, then re-open the I/O items node for the remote device, you will see that the %MW memory address assignments have changed—because they now are located behind the local slave’s inputs and outputs:



Input Item Name	Data Type	Offset/Device	Offset/Connection	Position in Byte	Address
NICstatus_Ix0	Input bit	0	0	0	%MW65.0
NICstatus_Ix1	Input bit	0	0	1	%MW65.1
NICstatus_Ix2	Input bit	0	0	2	%MW65.2
NICstatus_Ix3	Input bit	0	0	3	%MW65.3
NICstatus_Ix4	Input bit	0	0	4	%MW65.4
NICstatus_Ix5	Input bit	0	0	5	%MW65.5
NICstatus_Ix6	Input bit	0	0	6	%MW65.6

Output Item Name	Data Type	Offset/Device	Offset/Connection	Position in Byte	Address
DDO9200_outputdata_QX0	Output bit	0	0	0	%MW165.0
DDO9200_outputdata_QX1	Output bit	0	0	1	%MW165.1
DDO9410_outputdata_QX2	Output bit	0	0	2	%MW165.2
DDO9410_outputdata_QX3	Output bit	0	0	3	%MW165.3
DDO9410_outputdata_QX4	Output bit	0	0	4	%MW165.4
DDO9410_outputdata_QX5	Output bit	0	0	5	%MW165.5
DDO9600_outputdata_QX8	Output bit	1	1	0	%MW165.8
DDO9600_outputdata_QX9	Output bit	1	1	1	%MW165.9
DDO9600_outputdata_QX10	Output bit	1	1	2	%MW165.10
DDO9600_outputdata_QX11	Output bit	1	1	3	%MW165.11
DDO9600_outputdata_QX12	Output bit	1	1	4	%MW165.12
DDO9600_outputdata_QX13	Output bit	1	1	5	%MW165.13
AVO1250_CH1_outputdata_	Output word	2	2		%MW166
AVO1250_CH2_outputdata_	Output word	4	4		%MW167

This shift of %MW input and output memory address assignments occurs because the assignment of a remote device's, or a local slave's, I/O to a specific %MW memory address depends upon the node's relative position among active nodes in the EtherNet/IP network.

You can avoid this shift in input and output %MW memory addresses. When you activate the local slave function, be sure to change the local slave's device **Number** from the default value of 000 to a value larger than the device number of the last device in the network.

In this example, setting the local slave's device **Number** to **002** would preserve the remote device's original %MW input and output memory address assignments.

Recommended Practices

To avoid the problem of shifting input and output %MW memory address assignments, consider the following recommended practices when developing your application:

- As described above, when activating the local slave function of an EtherNet/IP communication module, change the local slave device **Number** from its default value of 000 to a value larger than the device number for the last device in your network.
- When adding a new remote device to your EtherNet/IP network, always add it to the end of the device list and assign it a device **Number** larger than any other device number on your network.
- When configuring function blocks in Control Expert, do not directly assign input and output pins to a specific %MW memory address. Instead, assign input and output pins to the derived data types and variables automatically created by Control Expert.

Section 3.2

Adding and Configuring Remote Devices

Overview

This section describes how to:

- add a generic device to your EtherNet/IP network
- configure properties for the generic device
- save, transfer and re-use Control Expert project files that include EtherNet/IP module settings

What Is in This Section?


This section contains the following topics:

Topic	Page
Device Library	73
Add an EDS File to the Device Library	75
Adding A Remote Device	78
Configuring Remote Device Properties	80
Managing Project Files	85

Device Library

Overview

The Control Expert EtherNet/IP configuration tool includes a **Device Library**, located in the lower left part of the configuration tool's main window. The **Device Library** is a repository of both generic and device-specific EDS files. Each EDS file defines a device, chassis, or module that you can add to your EtherNet/IP network configuration.



Both the Generic EDS node and the EtherNet/IP Local Slave node describe generic devices and cannot be deleted.

Click on the  icon to expand the device list and display the items of the selected type.

Functions

Use the **Device Library's** toolbar controls to perform the following tasks:

Function	Icon	Description
Add an EDS File		Opens the Add an EDS File wizard (<i>see page 75</i>), which steps you through the process of adding a new EDS file to the Device Library .
Delete a device from the Device Library list		Deletes the selected device, chassis, or module from the Device Library list, but retains the associated EDS File in your PC's EDS File folder. You can use the Add an EDS File button  to restore the deleted device to the list. Notes: <ul style="list-style-type: none"> Do not delete a device that has been added to your EtherNet/IP network. You can delete only device-specific devices; you cannot delete a generic device.
Display device properties		Opens the properties window for the selected device. In the properties window, click the View or Print EDS File... button to display the EDS File in a text file window. In the text file window, select File → Print to print the contents of the EDS file.

Function	Icon	Description
Insert a device into your EtherNet/IP configuration		<p>Inserts the selected device to the last position in your EtherNet/IP design.</p> <p>Note: You cannot manually insert a chassis or module into the configuration. These are added during the configuration of modular devices.</p>
Sort the Device Library list		<p>Opens the Sort Device Library window, where you can select a sort order for the devices, chassis, and modules displayed in the Device Library.</p>
Filter the Device Library list	List	<p>Click inside the drop-down list to display and select one of the following filtering options:</p> <ul style="list-style-type: none"> ● Display Devices: displays only devices—module and chassis entries are filtered out ● Display Modules and Chassis: displays both chassis and for modules—devices are filtered out ● Display all Nodes: displays devices, modules and chassis.

Add an EDS File to the Device Library

Overview

The Control Expert EtherNet/IP configuration tool includes an **EDS Management** wizard that you can use to add one or more EDS files to the **Device Library**. The wizard presents a series of instruction screens that:


- simplify the process of adding EDS files to the **Device Library**, and
- provide a redundancy check in case you attempt to add duplicate EDS files to the **Device Library**


Select **Devices** → **Options...** to open the **Display Options** window, where you can enable/disable messages indicating the EDS file you are adding is a duplicate, or a different version, of an existing EDS file.

NOTE: The Control Expert EtherNet/IP configuration tool contains a library of EDS files registered with the ODVA. This library includes EDS files for products not manufactured or sold by Schneider Electric. The non-Schneider Electric EDS files are identified in the Control Expert EtherNet/IP Configuration Tool library. Please contact the identified device's manufacturer for inquiries regarding the corresponding non-Schneider Electric EDS files.

Adding EDS Files

To add one or more EDS files to the **Device Library**:

Step	Action
1	<p>Do one of the following:</p> <ul style="list-style-type: none"> • in the Device Library, click the Add button , or • select Library → Add <p>Page 1 of the wizard opens.</p>
2	<p>Click Next. Page 2 of the wizard opens:</p>  <p>The EDS files usable are registered in the EDS Library. Select the location of the file(s) and click on Next button to insert the EDS files in the base.</p> <p>EDS DTM New Naming Convention</p> <p><input checked="" type="checkbox"/> New Naming Convention</p> <p>Checked : Generic EDS DTM name creation is based on Product name and Revision Number and naming is consistent across PCs (Backward Compatibility is not supported). By default, new naming rule is used to create new application.</p> <p>Unchecked : Generic EDS DTM name creation is based on Legacy naming rule. This naming convention to be used when an application produced with previous Unity Pro version to be compatible with Control Expert version.</p>
3	<p>In the Select the Location of the EDS File(s) section, select either:</p> <ul style="list-style-type: none"> • Add File(s), to add one or more EDS files you will individually select, or • Add all the EDS Files from the Directory, to add all files from a folder you will select. <ul style="list-style-type: none"> ○ Select Look in Subfolders to also add EDS files in subfolders beneath the folder you select

Step	Action
4	<p>Click the Browse button. The Open dialog opens:</p>  <p>The screenshot shows an 'Open' dialog box with the title bar 'Open'. The 'Look in:' field shows 'ETHERNETIP_IP_EDS'. The file list contains a 'temp' folder and several .eds files with names like '004D00800010101.eds', '0001000A000A0101.eds', etc. The 'File name:' and 'Files of type:' fields are empty. 'Open' and 'Cancel' buttons are at the bottom right.</p>
5	<p>Use the Open dialog to navigate to and select:</p> <ul style="list-style-type: none"> ● one or more EDS files, or ● a folder containing EDS files
6	<p>After you have made your selections), click Open. The dialog closes and your selection appears in the Directory or File Name field.</p>
7	<p>Choose the naming convention rule for the EDS DTM name creation. The new naming convention is based on Model Name / Product Name and Revision. A random character is automatically suffixed when Model Name / Product Name and Revision of an EDS file of the library are identical. The new naming convention is irrespective of the order in which EDS files are added to device library. By default, the Naming Convention check box is selected and the new naming rule applies. NOTE: To keep backward compatibility with Control Expert versions, unchecked the Naming Convention check box and the naming rule is based on Model Name / Product Name.</p>
8	<p>Click Next. The wizard compares the selected EDS files against existing files in the Device Library.</p>
9	<p>(Conditional) If one or more selected EDS files are duplicates and if notice of redundant files is enabled in the Display Options dialog, a File Already Exists message displays. Close the message.</p>
10	<p>Page 3 of the wizard opens indicating the Status of each device you attempted to add:</p> <ul style="list-style-type: none"> ● a green check mark indicates the EDS file can be added ● a blue informational icon indicates a redundant file ● a red check mark indicates an invalid EDS file <p>(Optional) Select a file in the list, then click View Selected File to open it.</p>
11	<p>Click Next to add the non-duplicate files. Page 4 of the wizard opens, indicating the action is complete.</p>
12	<p>Click Finish to close the wizard. The device(s) you added can now be inserted into your EtherNet/IP configuration.</p>

Adding A Remote Device

Overview

The Device Library consists of two types of entries:

Entry	Defined by
generic	A device without an associated EDS File. In the Device Library, generic devices include: <ul style="list-style-type: none">● Generic EDS● EtherNet/IP Local Slave
EDS File specific	A device, module, or chassis defined by a unique vendor-created EDS File. In the Device Library, these devices appear beneath the branches: <ul style="list-style-type: none">● EtherNet/IP Devices● Chassis and modules

You can add both generic devices or devices with a specific EDS File to your EtherNet/IP network.


When you add:

- a device that is associated with a specific EDS File, the Control Expert EtherNet/IP configuration tool recognizes the device and automatically performs much of the device configuration for you
- a generic device, you need to manually perform all device configuration

In the following example, a generic device is added to an EtherNet/IP network.

Adding a Generic Remote Device

To add a generic remote device to your EtherNet/IP network, follow these steps:

Step	Action
1	<p>In the Device Library, select Generic EDS (see below):</p>  <p>The screenshot shows a software window titled 'Device Library'. At the top, there are several icons and a dropdown menu set to 'Display all Nodes'. Below this is a tree view with the following items: 'Generic EDS' (highlighted in blue), 'EtherNet/IP Local Slave', 'EtherNet/IP Devices', and 'Chassis and modules'. At the bottom of the window, there are two buttons: 'Device Library' and 'Network Detection'.</p>
2	<p>Click the Insert ➞ button.</p> <p>Two things occur simultaneously:</p> <ul style="list-style-type: none"> ● a new generic device is added to the end of the EtherNet/IP network configuration, and ● the Generic EDS properties window opens for editing.
3	<p>Refer to the topic Configuring a Generic Remote Device (<i>see page 80</i>) for additional instructions on configuring the generic device.</p>

Configuring Remote Device Properties


Overview

When a generic device is added to an EtherNet/IP network, the Control Expert EtherNet/IP configuration tool automatically opens its properties window for immediate configuration. When operating offline, the properties window consists of the following 5 pages. Only the first two of these pages need to be configured:

In this page...	Do the following...
General	Enter configuration settings, as described below.
Connections	Enter configuration settings, as described below.
Online Parameters	Not accessible offline. No configuration required.
Port Configuration	Not accessible offline. No configuration required.
EDS File	(Read-only page - no configuration required)

Configuring the General Page



To configure the **General** page:

Step	Action																		
1	<p>Click on the General page:</p>  <p>The screenshot shows the 'Generic EDS' dialog box with the 'General' tab selected. The 'Device Designation' section includes a 'Device Name' field containing 'DEVICE_B', a 'Number' dropdown set to '001', and an 'Active Configuration' checkbox which is checked. Below this is a 'Comment' field. The 'Network Properties' section contains a table with the following data:</p> <table border="1" data-bbox="514 602 1053 760"> <thead> <tr> <th>Name</th> <th>Value</th> <th>Unit</th> </tr> </thead> <tbody> <tr> <td>IP Address</td> <td>000.000.000.000</td> <td></td> </tr> <tr> <td>DHCP Relation</td> <td></td> <td></td> </tr> <tr> <td>Enable DHCP</td> <td>FALSE</td> <td></td> </tr> <tr> <td>DHCP Client Identifier</td> <td>Mac Address</td> <td></td> </tr> <tr> <td>Mac Address</td> <td>00-00-00-00-00-00</td> <td></td> </tr> </tbody> </table> <p>At the bottom of the dialog are 'OK', 'Cancel', and 'Help' buttons. The 'Ping' section has a 'Ping' button and a 'Ping Result' text area, with checkboxes for 'Loop' and 'Stop on Error', and a 'Clear' button.</p>	Name	Value	Unit	IP Address	000.000.000.000		DHCP Relation			Enable DHCP	FALSE		DHCP Client Identifier	Mac Address		Mac Address	00-00-00-00-00-00	
Name	Value	Unit																	
IP Address	000.000.000.000																		
DHCP Relation																			
Enable DHCP	FALSE																		
DHCP Client Identifier	Mac Address																		
Mac Address	00-00-00-00-00-00																		

Step	Action																
2	<p>In the General page, edit the following settings:</p> <table border="1" data-bbox="310 233 1226 1258"> <tr> <td data-bbox="310 233 491 354">Device Name</td> <td data-bbox="491 233 1226 354"> The label for the remote device in the EtherNet/IP device list. Either: <ul style="list-style-type: none"> ● type in a unique name using letters, numbers and the underscore character (_), or ● accept the auto-generated name (DEVICE_N) </td> </tr> <tr> <td data-bbox="310 354 491 444">Number</td> <td data-bbox="491 354 1226 444"> The relative position in the EtherNet/IP device list. Either: <ul style="list-style-type: none"> ● accept the default (i.e. the next available number), or ● select a different number from the drop-down list </td> </tr> <tr> <td data-bbox="310 444 491 604">Link Parameters</td> <td data-bbox="491 444 1226 604"> Select this setting to: <ul style="list-style-type: none"> ● lock the IP Address setting, and ● set the last octet of the IP Address equal to the value selected in the Number parameter De-select this setting to unlock the IP Address setting. </td> </tr> <tr> <td data-bbox="310 604 491 717">Active Configuration</td> <td data-bbox="491 604 1226 717"> Select this setting to include this remote device in EtherNet/IP network communications. De-select this setting to exclude this device from network communications, but save the device's configuration settings. </td> </tr> <tr> <td data-bbox="310 717 491 964">IP Address</td> <td data-bbox="491 717 1226 964"> The IP Address of this remote device. This setting is: <ul style="list-style-type: none"> ● editable, when the Link Parameters field is de-selected ● locked, when the Link Parameters field is selected By default: <ul style="list-style-type: none"> ● the first 3 octet values equal the first 3 octet values of the EtherNet/IP module's IP address ● when the Link Parameters field is selected, the last octet value equals the value selected in the Number parameter </td> </tr> <tr> <td data-bbox="310 964 491 1052">Enable DHCP</td> <td data-bbox="491 964 1226 1052"> TRUE activates the DHCP client in this remote device. On startup, this device requests its IP address from a DHCP server. Note: the EtherNet/IP module can be configured to act as a DHCP server. </td> </tr> <tr> <td data-bbox="310 1052 491 1172">DHCP Client Identifier</td> <td data-bbox="491 1052 1226 1172"> If the DHCP client is enabled, select the identifier the DHCP server will use to recognize this remote device: <ul style="list-style-type: none"> ● MAC Address ● Device Name </td> </tr> <tr> <td data-bbox="310 1172 491 1258">Mac Address/Device Name</td> <td data-bbox="491 1172 1226 1258"> Type in the value of the DHCP client identifier. Note: The Device Name referenced here is not the same as the Device Name described in the first row of this table. </td> </tr> </table>	Device Name	The label for the remote device in the EtherNet/IP device list. Either: <ul style="list-style-type: none"> ● type in a unique name using letters, numbers and the underscore character (_), or ● accept the auto-generated name (DEVICE_N) 	Number	The relative position in the EtherNet/IP device list. Either: <ul style="list-style-type: none"> ● accept the default (i.e. the next available number), or ● select a different number from the drop-down list 	Link Parameters	Select this setting to: <ul style="list-style-type: none"> ● lock the IP Address setting, and ● set the last octet of the IP Address equal to the value selected in the Number parameter De-select this setting to unlock the IP Address setting.	Active Configuration	Select this setting to include this remote device in EtherNet/IP network communications. De-select this setting to exclude this device from network communications, but save the device's configuration settings.	IP Address	The IP Address of this remote device. This setting is: <ul style="list-style-type: none"> ● editable, when the Link Parameters field is de-selected ● locked, when the Link Parameters field is selected By default: <ul style="list-style-type: none"> ● the first 3 octet values equal the first 3 octet values of the EtherNet/IP module's IP address ● when the Link Parameters field is selected, the last octet value equals the value selected in the Number parameter 	Enable DHCP	TRUE activates the DHCP client in this remote device. On startup, this device requests its IP address from a DHCP server. Note: the EtherNet/IP module can be configured to act as a DHCP server.	DHCP Client Identifier	If the DHCP client is enabled, select the identifier the DHCP server will use to recognize this remote device: <ul style="list-style-type: none"> ● MAC Address ● Device Name 	Mac Address/Device Name	Type in the value of the DHCP client identifier. Note: The Device Name referenced here is not the same as the Device Name described in the first row of this table.
Device Name	The label for the remote device in the EtherNet/IP device list. Either: <ul style="list-style-type: none"> ● type in a unique name using letters, numbers and the underscore character (_), or ● accept the auto-generated name (DEVICE_N) 																
Number	The relative position in the EtherNet/IP device list. Either: <ul style="list-style-type: none"> ● accept the default (i.e. the next available number), or ● select a different number from the drop-down list 																
Link Parameters	Select this setting to: <ul style="list-style-type: none"> ● lock the IP Address setting, and ● set the last octet of the IP Address equal to the value selected in the Number parameter De-select this setting to unlock the IP Address setting.																
Active Configuration	Select this setting to include this remote device in EtherNet/IP network communications. De-select this setting to exclude this device from network communications, but save the device's configuration settings.																
IP Address	The IP Address of this remote device. This setting is: <ul style="list-style-type: none"> ● editable, when the Link Parameters field is de-selected ● locked, when the Link Parameters field is selected By default: <ul style="list-style-type: none"> ● the first 3 octet values equal the first 3 octet values of the EtherNet/IP module's IP address ● when the Link Parameters field is selected, the last octet value equals the value selected in the Number parameter 																
Enable DHCP	TRUE activates the DHCP client in this remote device. On startup, this device requests its IP address from a DHCP server. Note: the EtherNet/IP module can be configured to act as a DHCP server.																
DHCP Client Identifier	If the DHCP client is enabled, select the identifier the DHCP server will use to recognize this remote device: <ul style="list-style-type: none"> ● MAC Address ● Device Name 																
Mac Address/Device Name	Type in the value of the DHCP client identifier. Note: The Device Name referenced here is not the same as the Device Name described in the first row of this table.																

Configuring the Connections Page

To configure the Connections page:

Step	Action																																																
1	<p>Click on the Connections page:</p> 																																																
2	<p>In the Configured Connections list, click on General to display the general connection settings in the Connection Parameters list, shown below:</p>  <table border="1" data-bbox="673 943 1081 1219"> <thead> <tr> <th>Name</th> <th>Value</th> <th>Unit</th> <th>...</th> </tr> </thead> <tbody> <tr> <td>Connection Bit Health Offset</td> <td>###</td> <td></td> <td></td> </tr> <tr> <td>Request Packet Interval (RPI)</td> <td>30</td> <td>ms</td> <td></td> </tr> <tr> <td>Time-out Multiplier</td> <td>x4</td> <td></td> <td></td> </tr> <tr> <td colspan="4">Input T -> O</td> </tr> <tr> <td>Input Size</td> <td>1</td> <td>bytes</td> <td></td> </tr> <tr> <td>Input Instance</td> <td>0</td> <td></td> <td></td> </tr> <tr> <td colspan="4">Output O -> T</td> </tr> <tr> <td>Output Size</td> <td>1</td> <td>bytes</td> <td></td> </tr> <tr> <td>Output Instance</td> <td>0</td> <td></td> <td></td> </tr> <tr> <td colspan="4">Configuration</td> </tr> <tr> <td>Configuration Instance</td> <td>0</td> <td></td> <td></td> </tr> </tbody> </table>	Name	Value	Unit	...	Connection Bit Health Offset	###			Request Packet Interval (RPI)	30	ms		Time-out Multiplier	x4			Input T -> O				Input Size	1	bytes		Input Instance	0			Output O -> T				Output Size	1	bytes		Output Instance	0			Configuration				Configuration Instance	0		
Name	Value	Unit	...																																														
Connection Bit Health Offset	###																																																
Request Packet Interval (RPI)	30	ms																																															
Time-out Multiplier	x4																																																
Input T -> O																																																	
Input Size	1	bytes																																															
Input Instance	0																																																
Output O -> T																																																	
Output Size	1	bytes																																															
Output Instance	0																																																
Configuration																																																	
Configuration Instance	0																																																

Step	Action																
3	<p>In the Connections page, edit the following general connection settings:</p> <table border="1" data-bbox="326 233 1226 764"> <tr> <td data-bbox="326 233 669 266">Connection Health Bit Offset</td> <td data-bbox="669 233 1226 266">(read-only)</td> </tr> <tr> <td data-bbox="326 266 669 358">Request Packet Interval (RPI)</td> <td data-bbox="669 266 1226 358">The refresh period for this I/O connection. Value range: 2...65535 ms Default = 30 ms</td> </tr> <tr> <td data-bbox="326 358 669 472">Time-out Multiplier</td> <td data-bbox="669 358 1226 472">The value, multiplied against the RPI rate, which triggers an inactivity timeout. Value list: 4, 8, 16, 32, 64, 128, 256, 512 Default: 4</td> </tr> <tr> <td data-bbox="326 472 669 565">Input Size (in bytes)</td> <td data-bbox="669 472 1226 565">The number of bytes reserved for input data, in bytes. Value range: 1...509 Default: 1</td> </tr> <tr> <td data-bbox="326 565 669 597">Input Instance</td> <td data-bbox="669 565 1226 597">The instance identifier for inputs: 101.</td> </tr> <tr> <td data-bbox="326 597 669 690">Output Size (in bytes)</td> <td data-bbox="669 597 1226 690">The number of bytes reserved for output data, in bytes. Value range: 1...505 Default: 1</td> </tr> <tr> <td data-bbox="326 690 669 722">Output Instance</td> <td data-bbox="669 690 1226 722">The instance identifier for outputs: 102.</td> </tr> <tr> <td data-bbox="326 722 669 764">Configuration Instance</td> <td data-bbox="669 722 1226 764">The instance identifier for configuration data: 103.</td> </tr> </table> <p>Note: The Input Size and Output Size parameter settings are determined by the size—in bytes—of the input data and output data sections of your specific application.</p>	Connection Health Bit Offset	(read-only)	Request Packet Interval (RPI)	The refresh period for this I/O connection. Value range: 2...65535 ms Default = 30 ms	Time-out Multiplier	The value, multiplied against the RPI rate, which triggers an inactivity timeout. Value list: 4, 8, 16, 32, 64, 128, 256, 512 Default: 4	Input Size (in bytes)	The number of bytes reserved for input data, in bytes. Value range: 1...509 Default: 1	Input Instance	The instance identifier for inputs: 101 .	Output Size (in bytes)	The number of bytes reserved for output data, in bytes. Value range: 1...505 Default: 1	Output Instance	The instance identifier for outputs: 102 .	Configuration Instance	The instance identifier for configuration data: 103 .
Connection Health Bit Offset	(read-only)																
Request Packet Interval (RPI)	The refresh period for this I/O connection. Value range: 2...65535 ms Default = 30 ms																
Time-out Multiplier	The value, multiplied against the RPI rate, which triggers an inactivity timeout. Value list: 4, 8, 16, 32, 64, 128, 256, 512 Default: 4																
Input Size (in bytes)	The number of bytes reserved for input data, in bytes. Value range: 1...509 Default: 1																
Input Instance	The instance identifier for inputs: 101 .																
Output Size (in bytes)	The number of bytes reserved for output data, in bytes. Value range: 1...505 Default: 1																
Output Instance	The instance identifier for outputs: 102 .																
Configuration Instance	The instance identifier for configuration data: 103 .																
4	<p>Click OK to save your settings and close the Properties window. The next step is to configure I/O settings. For an example of I/O configuration for a generic remote device, see how the following I/O items were configured:</p> <ul style="list-style-type: none"> ● discrete input items (<i>see page 102</i>) ● discrete output items (<i>see page 105</i>) ● numeric input items (<i>see page 108</i>) ● numeric output items (<i>see page 111</i>) 																

Managing Project Files

Overview

Managing Control Expert project files that contain EtherNet/IP module settings includes:

- saving project files as either:
 - Control Expert Archived Application Files (*.STA)
 - Control Expert project files (*.STU)
- opening saved project files
- transferring files

NOTE: To transfer Control Expert project files, follow the steps set forth below.

Do not use the following Control Expert commands to transfer a Control Expert project file that contains EtherNet/IP settings:

- project transfer command: **PLC → Transfer Project from PLC**
- export project command: **File → Export Project...**

Creating Control Expert Archive (*.STA) Files

Control Expert project files, containing EtherNet/IP module settings, can be transferred within the Control Expert application only as Control Expert Archived Application Files (*.STA). To save a Control Expert project file as a Control Expert Archived Application File (*.STA) suitable for transfer and reuse, follow these steps:

Step	Action
1	Build the Control Expert project. Select: Build → Rebuild All Project.
2	Download the rebuilt Control Expert project file to the PLC. Select: PLC → Transfer Project to PLC. The taskbar should indicate EQUAL .
3	Go offline. Select: PLC → Disconnect.
4	Select File → Save Archive... The Save Archive window opens.
5	In the Save Archive window: <ul style="list-style-type: none"> ● type a File name ● navigate to a location to store the archived project file ● click Save. Control Expert creates a Control Expert Archived Application File (*.STA).

Opening a Control Expert Archive (*.STA) File

After a Control Expert Archived Application File has been saved, you can transfer it (like any file), then re-open it in the same version of Control Expert. To re-open an archived project file:

Step	Action
1	Select File → Open . The Open dialog opens.
2	In the Open dialog, select Control Expert Archived Application Files (*.STA) as the Files of type .
3	In the Look in drop down box, navigate to the location of the archived Control Expert archive file that you want to open.
4	Select the file and click Open . Control Expert opens the archived Control Expert project file.

Transferring Control Expert Project (.STU) Files

You can copy, paste, and transfer a Control Expert project (*.STU) file as you would any file, using the tools and commands available in Windows Explorer.

A saved Control Expert project (*.STU) file can be re-opened only by the same version of Control Expert software that saved it.

Section 3.3

Configuring the STB NIC 2212

Overview

This section presents a sample configuration of an STB NIC 2212 EtherNet/IP network interface module, and adds it to a Control Expert project.

NOTE: The instructions in this chapter describe a single, specific device configuration example. Refer to the Control Expert EtherNet/IP configuration tool help file for additional information about alternative configuration choices.

The following example extends the sample configuration of the EtherNet/IP communications network described in the previous chapter where you:

- created a project
- added a power supply module, CPU and EtherNet/IP communication module to the project
- configured the EtherNet/IP communication module

What Is in This Section?

This section contains the following topics:

Topic	Page
Setting Up Your Network	88
Automatically Detect and Add the STB NIC 2212	90
Configuring STB NIC 2212 Properties	91
Connecting to the Advantys STB Island	95
Configuring I/O Items	99

Setting Up Your Network


Overview

This sample network includes the following hardware and software:

- a controller rack with:
 - 140 CPS 114 10, 115/230 VAC power supply
 - 140 CPU 651 60 controller
 - 140 NOC 771 00, EtherNet/IP communication module
- a remote STB Advantys island with:
 - STB NIC 2212 Ethernet network interface module
 - STB PDT 3100 power distribution module
 - STB DDI 3230 2 pt digital input module
 - STB DDO 3200 2 pt digital output module
 - STB DDI 3420 4 pt digital input module
 - STB DDO 3410 4 pt digital output module
 - STB DDI 3610 6 pt digital input module
 - STB DDO 3600 6 pt digital output module
 - STB AVI 1270 2 pt analog input module
 - STB AVO 1250 2 pt analog output module
- a PC running both Unity Pro (version 4.0 or later) and Advantys configuration software (version 4.0 or later)
NOTE: Unity Pro is the former name of Control Expert for version 13.1 or earlier.
- an Ethernet switch connected to the above EtherNet/IP devices with twisted pair Ethernet cable and RJ45 connectors (It is strongly recommended that you use a managed switch that supports the IGMP protocol.)

Network Topology

The network example topology looks like this:



To re-create this example, be sure to:

- use the IP addresses for your own configuration's:
 - PC
 - 140 NOC 771 00 EtherNet/IP communication module
 - STB NIC 2212 network interface module
- check all wiring

NOTE: Control Expert software running in the PC is used to configure the CPU 651 60 controller. In this example, the PC is indirectly wired to the CPU's Ethernet port via the Ethernet switch. Alternatively, you could bypass the switch and directly wire the PC to either the CPU's Modbus or USB ports.

Automatically Detect and Add the STB NIC 2212


Overview

Use the Control Expert EtherNet/IP configuration tool to automatically detect the STB NIC 2212 module, then add it to your project.

NOTE: The STB NIC 2212 module must be active online with a valid IP address before you can detect it then add it to your project. You can assign an IP address using a DHCP or BOOTP server, or use the MAC-generated (default) IP address.

Detecting and Adding Network Devices

To automatically detect the STB NIC 2212, then add it to your project, follow these steps:

Step	Action
1	Launch the configuration tool from the Configuration page of the EtherNet/IP communication module's Properties window.
2	In the configuration tool, begin on-line operations by clicking the Go Online button  .
3	Click on the Network Detection tab to enable automatic network detection: 
4	Click the Read Network Configuration toolbar button  . The configuration tool searches the network for EtherNet/IP devices, classifies them using the device EDS file, then lists the EtherNet/IP devices it detects. 
5	Select the STB NIC 2212 in Network Detection window.
6	Click the Insert in Configuration button  . The properties window opens, where you can configure the STB NIC 2212.

Configuring STB NIC 2212 Properties


Overview



The STB NIC 2212 network interface module properties window presents the following tabbed pages. Only some of these pages need to be edited for this example:

In this page...	Do the following...
General	<ul style="list-style-type: none">● input device name● configure IP address● add the device to the project configuration
Connections	<ul style="list-style-type: none">● configure the requested packet interval (RPI)● specify the size and location of inputs and outputs
Online Parameters	Accept the default settings, if any.
Module Informations	(Read-only page - no configuration required)
Port Configuration	(Read-only page - no configuration required)
EDS File	(Read-only page - no configuration required)

Configuring the STB NIC 2212

The following settings are used in this sample configuration. Be sure to use settings that are appropriate for your actual application:

Step	Action								
1	<p>Click on the General page:</p> 								
2	<p>In the General page, edit the following settings:</p> <table border="1" data-bbox="318 1193 1064 1416"> <tbody> <tr> <td data-bbox="318 1193 761 1226">Device Name</td> <td data-bbox="766 1193 1064 1226">STBNIC2212</td> </tr> <tr> <td data-bbox="318 1232 761 1315">Number</td> <td data-bbox="766 1232 1064 1315">The relative position in the EtherNet/IP device list. For this example, select 001.</td> </tr> <tr> <td data-bbox="318 1321 761 1380">Active Configuration</td> <td data-bbox="766 1321 1064 1380">Be sure this checkbox is selected.</td> </tr> <tr> <td data-bbox="318 1386 761 1416">IP Address</td> <td data-bbox="766 1386 1064 1416">192.168.001.006</td> </tr> </tbody> </table>	Device Name	STBNIC2212	Number	The relative position in the EtherNet/IP device list. For this example, select 001 .	Active Configuration	Be sure this checkbox is selected.	IP Address	192.168.001.006
Device Name	STBNIC2212								
Number	The relative position in the EtherNet/IP device list. For this example, select 001 .								
Active Configuration	Be sure this checkbox is selected.								
IP Address	192.168.001.006								

Step	Action																																																												
3	<p>Click on the Connections page:</p> 																																																												
4	<p>In the Configured Connections list, click on General to display the general connection settings in the Connection Parameters list, shown below:</p>  <table border="1" data-bbox="683 862 1093 1219"> <thead> <tr> <th>Name</th> <th>Value</th> <th>Unit</th> <th>...</th> </tr> </thead> <tbody> <tr> <td>Connection Bit Health Offset</td> <td>0</td> <td></td> <td></td> </tr> <tr> <td>Requested Packet Interval</td> <td>30</td> <td>ms</td> <td></td> </tr> <tr> <td>Time-out Multiplier</td> <td>x4</td> <td></td> <td></td> </tr> <tr> <td colspan="4">Input T -> O</td> </tr> <tr> <td>Input Size</td> <td>19</td> <td>bytes</td> <td></td> </tr> <tr> <td>Input Mode</td> <td>Multicast</td> <td></td> <td></td> </tr> <tr> <td>Input Type</td> <td>Fixed</td> <td></td> <td></td> </tr> <tr> <td>Priority</td> <td>Scheduled</td> <td></td> <td></td> </tr> <tr> <td>Trigger Type</td> <td>Cyclic</td> <td></td> <td></td> </tr> <tr> <td colspan="4">Output O -> T</td> </tr> <tr> <td>Output Size</td> <td>6</td> <td>bytes</td> <td></td> </tr> <tr> <td>Output Mode</td> <td>Point to Point</td> <td></td> <td></td> </tr> <tr> <td>Output Type</td> <td>Fixed</td> <td></td> <td></td> </tr> <tr> <td>Priority</td> <td>Scheduled</td> <td></td> <td></td> </tr> </tbody> </table>	Name	Value	Unit	...	Connection Bit Health Offset	0			Requested Packet Interval	30	ms		Time-out Multiplier	x4			Input T -> O				Input Size	19	bytes		Input Mode	Multicast			Input Type	Fixed			Priority	Scheduled			Trigger Type	Cyclic			Output O -> T				Output Size	6	bytes		Output Mode	Point to Point			Output Type	Fixed			Priority	Scheduled		
Name	Value	Unit	...																																																										
Connection Bit Health Offset	0																																																												
Requested Packet Interval	30	ms																																																											
Time-out Multiplier	x4																																																												
Input T -> O																																																													
Input Size	19	bytes																																																											
Input Mode	Multicast																																																												
Input Type	Fixed																																																												
Priority	Scheduled																																																												
Trigger Type	Cyclic																																																												
Output O -> T																																																													
Output Size	6	bytes																																																											
Output Mode	Point to Point																																																												
Output Type	Fixed																																																												
Priority	Scheduled																																																												

Step	Action										
5	<p>In the Connections page, edit the following general connection settings:</p> <table border="1" data-bbox="321 233 1070 415"> <tr> <td>Request Packet Interval</td> <td>30 ms</td> </tr> <tr> <td>Input Size (in bytes)</td> <td>19 bytes</td> </tr> <tr> <td>Input Instance</td> <td>101</td> </tr> <tr> <td>Output Size (in bytes)</td> <td>6 bytes</td> </tr> <tr> <td>Output Instance</td> <td>102</td> </tr> </table> <p>Note: The Input Size and Output Size parameter settings are determined by the size—in bytes—of the input data and output data sections of the Advantys island's Fieldbus Image.</p>	Request Packet Interval	30 ms	Input Size (in bytes)	19 bytes	Input Instance	101	Output Size (in bytes)	6 bytes	Output Instance	102
Request Packet Interval	30 ms										
Input Size (in bytes)	19 bytes										
Input Instance	101										
Output Size (in bytes)	6 bytes										
Output Instance	102										
6	<p>Click OK to save your settings and close the Properties window. A node is added to the project configuration in the Devices window, below:</p>  <p>The next step is to configure I/O settings.</p>										

Connecting to the Advantys STB Island

Overview

In this example, you will use the Advantys configuration software running on your PC to:

- connect the Advantys configuration software to the STB NIC 2212 and the 8 I/O modules that comprise the Advantys STB island
- upload Advantys STB island configuration to the Advantys configuration software in your PC
- display a fieldbus image for the Advantys STB island showing the relative location of:
 - status information
 - input data
 - output data


Using the data presented in the fieldbus image, you can use the Control Expert EtherNet/IP configuration tool to create input and output items that map to specific status, input, output, and output echo data.



NOTE: Before proceeding with the following instructions, be sure you have auto-configured the Advantys STB island by pressing the **RST** button on the front of the STB NIC 2212 module.



Making the Connection


To connect to the STB NIC 2212 and I/O modules using the Advantys configuration software:

Step	Action
1	Startup the Advantys configuration software on your PC. A dialog opens displaying available project types.
2	Select STB . A choice of language dialog opens.
3	Select your choice of language.
4	Select File → New Workspace . The New Workspace window opens (below).
5	<p>For this example, type in the following field values:</p> <ul style="list-style-type: none"> ● for the field Workspace File type in Advantys ● for the field Island File type in Advantys_01



Step	Action
6	Click OK . The Advantys configuration software displays an empty DIN rail in the center of the screen.
7	Select Online → Connection Settings . The Connection Settings window opens (below).
8	<p>In the Connection Settings window, accept the Modbus Node ID default setting of 1, select TCP/IP, and click the Settings... button:</p>  <p>The TCP/IP Parameters dialog opens (below).</p>
9	<p>In the Remote IP Address field, type in the IP address for the STB NIC 2212, in this example: 192.168.1.6.</p>  <p>Note: Use the mouse to move between octets, and do not type in any leading zeroes. For example, do not type in 192.168.001.006.</p>
10	Click OK to close the TCP/IP Parameters dialog, and click OK again to close the Connection Settings dialog.

Step	Action
11	<p>Select Online → Connect. The Data Transfer dialog opens (below):</p> 
12	<p>Select Upload in the Data Transfer dialog. The island workspace is populated with island data and shows the STB NIC 2212 and all island modules (below):</p>  <p>Note: A box appears beneath each module containing one or two integers—for example 3/1. These integers serve the following purpose:</p> <ul style="list-style-type: none"> • The left-side integer (3 in this example) identifies the module's physical position—left to right—among all modules in the rack. • The right-side integer (1 in this example) identifies the module's relative position—left to right—among only data producing/receiving modules. If the module is not a data producing/receiving module (e.g. a power supply, or end of segment module) no right-side integer appears.

Step	Action
13	<p>Select Island → I/O Image Overview. The I/O Image window opens to the Fieldbus Image page:</p>  <p>Each table cell contains one of the following alpha-numeric indicators:</p> <ul style="list-style-type: none"> ● S indicates a status bit for the STB NIC 2212 network interface module ● an integer identifies the relative position—from left to right—of a data producing/receiving module with input or output data in that cell. For example: <ul style="list-style-type: none"> ○ the STB DDI 3230 input module is the first data producing or receiving module in the rack; its data is designated by the integer 1 in bits 0 - 3 of word 2 in the Input Data table ○ the STB DDO 3600 output module is the sixth data producing module in the rack; its status and output echo data is designated by the integer 6 in bits 8 - 13 of word 4 and in bits 0 - 5 of word 5 in the Input Data table; its output data is designated by the integer 6 in bits 8 - 13 of word 1 in the Output Data table <p>Notes: Select a cell in either the Input Data or Output Data tables to display—in the middle of the page—a description of the cell data and its source module. Convert the size of the Input Data table and the Output Data table from words to bytes (i.e. divide by 2), then use that data as the values for the Input Size (19) and Output Size (6) parameters when configuring the remote device's general connection properties (<i>see page 92</i>).</p>

Configuring I/O Items

Overview

The final task in this example is to add I/O items to the configuration of the STB NIC 2212 and its 8 I/O modules. To accomplish this:

- use the Advantys configuration software to identify the relative position of each I/O module's inputs and outputs
- use the Control Expert EtherNet/IP configuration tool to create input and output items, defining each item's:
 - name
 - data type
- identify the address assigned to each new input and output item using the Control Expert EtherNet/IP configuration software

I/O Item Types and Sizes

The goal is to create a collection of input items and output items that equal the input size and output size specified in the STB NIC 2212 Connection properties page. In this example, items need to be created for:

- 19 bytes of inputs
- 6 bytes of outputs

The Control Expert EtherNet/IP configuration tool provides great flexibility in creating input and output items. You can create input and output items in groups of 1 or more single bits, 8-bit bytes, 16-bit words, 32-bit dwords, or 32-bit IEEE floating values. The number of items you create depends upon the data type and size of each item.

In the sample project, the following items were created:

- discrete bits for digital inputs and outputs
- 8-bit bytes or 16-bit words for analog inputs and outputs

Mapping Input and Output Items

Use the **Fieldbus Image** page of the **I/O Image Overview** window in the Advantys configuration software to identify the number and type of I/O items you need to create, as follows:

Step	Action
1	In the Advantys configuration software, select Island → I/O Image Overview . The I/O Image window opens to the Fieldbus Image page.
2	Select the first cell (word 1, cell 0) in the Input Data table, to display in the middle of the page, a description of the cell data and its source module.
3	Make a note of the word, bit(s), module and item information for that cell.
4	Repeat steps 2 and 3 for each cell containing either an S or an integer.

NOTE: The Fieldbus Image presents input and output data in the form of 16-bit words (starting with word 1). You need to rearrange this data for the Control Expert EtherNet/IP configuration tool, which presents the same data in the form of 8-bit bytes (starting with byte 0).

This process yields the following tables of input and output data:

Input Data:

Advantys Fieldbus Image		Control Expert EIP Items		STB Module	Description
Word	Bit(s)	Byte	Bit(s)		
1	0-15	0	0-7	NIC 2212	NIC status
		1	0-7		
2	0-1	2	0-1	DDI 3230	input data
	2-3		2-3	DDI 3230	input status
	4-5		4-5	DDO 3200	output data echo
	6-7		6-7	DDO 3200	output status
	8-11	3	0-3	DDI 3420	input data
	12-15		4-7	DDI 3420	input status
3	0-3	4	0-3	DDO 3410	output data echo
	4-7		4-7	DDO 3410	output status
	8-13	5	0-5	DDI 3610	input data
	14-15		6-7	NA	not used
4	0-5	6	0-5	DDI 3610	input status
	6-7		6-7	NA	not used
	8-13	7	0-5	DDO 3600	output data echo
	14-15		6-7	NA	not used

Advantys Fieldbus Image		Control Expert EIP Items		STB Module	Description
Word	Bit(s)	Byte	Bit(s)		
5	0-5	8	0-5	DDO 3600	output status
	6-15	8	6-7	NA	not used
		9	0-7		
6	0-15	10	0-7	AVI 1270	input data ch 1
		11	0-7		
7	0-7	12	0-7	AVI 1270	input status ch 1
	8-15	13	0-7	NA	not used
8	0-15	14	0-7	AVI 1270	input data ch 2
		15	0-7		
9	0-7	16	0-7	AVI 1270	input status ch 2
	8-15	17	0-7	AVO 1250	output status ch 1
10	0-7	18	0-7	AVO 1250	output status ch 2
	8-15	NA	NA	NA	not used

Output Data:

Advantys Fieldbus Image		Control Expert EIP Items		Module	Description
Word	Bit(s)	Byte	Bit(s)		
1	0-1	0	0-1	DDO 3200	output data
	2-5		2-5	DDO 3410	output data
	6-7		6-7	NA	not used
	8-13	1	0-5	DDO 3600	output data
	14-15		6-7	NA	not used
2	0-15	2	0-7	AVO 1250	output data ch 1
		3	0-7		
3	0-15	4	0-7	AVO 1250	output data ch 2
		5	0-7		



For this example, you need to create input items for the 19 input bytes and output items for the 6 output bytes using the Control Expert EtherNet/IP configuration tool. These input and output items include:



- discrete input and output items made up of 1 or more bits for the digital I/O modules, and
- numeric input and output items made up of either an 8-bit byte or a 16-bit word for the analog I/O modules


The following examples show you how to create each kind of item.

Creating Discrete Input Items

To create discrete input items for the STB NIC 2212 example, beginning with 16 discrete inputs for NIC status:


Step	Action																																																																																
1	<p>In the Devices window of the Control Expert EtherNet/IP configuration tool, navigate to and select the connection item at Position 000, as shown below:</p>  <p>The screenshot shows a tree view with the following structure:</p> <ul style="list-style-type: none"> Module NOC1 : Auto 10/100 Mb - In%MW8 - Out%MW0 <ul style="list-style-type: none"> TCP/IP: Static - 192.168.001.004 <ul style="list-style-type: none"> [000] EtherNet/IP Local Slave <ul style="list-style-type: none"> [001] 192.168.001.006 STB_NIC_2212 <ul style="list-style-type: none"> Item Configuration Device Name: STB_NIC_2212 <ul style="list-style-type: none"> Position: 000 Read Input / Write Output Data (highlighted) 																																																																																
2	<p>Select Devices → Properties. The Items Declaration window opens:</p>  <p>The screenshot shows the 'Items Declaration' dialog box with the following details:</p> <ul style="list-style-type: none"> Tab: Discrete Input Items Table: <table border="1"> <thead> <tr> <th>Offset/Device</th> <th>Offset/Connection</th> <th>Position in the Byte</th> <th>Item Name</th> </tr> </thead> <tbody> <tr><td>0</td><td>0</td><td>0</td><td>C</td></tr> <tr><td>0</td><td>0</td><td>1</td><td></td></tr> <tr><td>0</td><td>0</td><td>2</td><td></td></tr> <tr><td>0</td><td>0</td><td>3</td><td></td></tr> <tr><td>0</td><td>0</td><td>4</td><td></td></tr> <tr><td>0</td><td>0</td><td>5</td><td></td></tr> <tr><td>0</td><td>0</td><td>6</td><td></td></tr> <tr><td>0</td><td>0</td><td>7</td><td></td></tr> <tr><td>1</td><td>1</td><td>C</td><td></td></tr> <tr><td>1</td><td>1</td><td>1</td><td></td></tr> <tr><td>1</td><td>1</td><td>2</td><td></td></tr> <tr><td>1</td><td>1</td><td>3</td><td></td></tr> <tr><td>1</td><td>1</td><td>4</td><td></td></tr> <tr><td>1</td><td>1</td><td>5</td><td></td></tr> <tr><td>1</td><td>1</td><td>6</td><td></td></tr> <tr><td>1</td><td>1</td><td>7</td><td></td></tr> <tr><td>2</td><td>2</td><td>C</td><td></td></tr> <tr><td>2</td><td>2</td><td>1</td><td></td></tr> <tr><td>2</td><td>2</td><td>2</td><td></td></tr> </tbody> </table> Default Items Name Root: BLOCKA Buttons: Define Item(s), Delete Item(s), OK, Cancel, Help 	Offset/Device	Offset/Connection	Position in the Byte	Item Name	0	0	0	C	0	0	1		0	0	2		0	0	3		0	0	4		0	0	5		0	0	6		0	0	7		1	1	C		1	1	1		1	1	2		1	1	3		1	1	4		1	1	5		1	1	6		1	1	7		2	2	C		2	2	1		2	2	2	
Offset/Device	Offset/Connection	Position in the Byte	Item Name																																																																														
0	0	0	C																																																																														
0	0	1																																																																															
0	0	2																																																																															
0	0	3																																																																															
0	0	4																																																																															
0	0	5																																																																															
0	0	6																																																																															
0	0	7																																																																															
1	1	C																																																																															
1	1	1																																																																															
1	1	2																																																																															
1	1	3																																																																															
1	1	4																																																																															
1	1	5																																																																															
1	1	6																																																																															
1	1	7																																																																															
2	2	C																																																																															
2	2	1																																																																															
2	2	2																																																																															
3	<p>In the Default Items Named Root input box type: NICstatus.</p>																																																																																



Step	Action																																																																																
4	<p>In the Items List, select the rows that correspond to bits 0-7 in bytes 0 and 1—i.e., the first 16 rows:</p>  <p>Items Declaration</p> <p>Discrete Input Items Discrete Output Items Numeric Input Items Numeric Output Items</p> <table border="1"> <thead> <tr> <th>Offset/Device</th> <th>Offset/Connection</th> <th>Position in the Byte</th> <th>Item Name</th> </tr> </thead> <tbody> <tr><td>0</td><td>0</td><td>0</td><td></td></tr> <tr><td>0</td><td>0</td><td>1</td><td></td></tr> <tr><td>0</td><td>0</td><td>2</td><td></td></tr> <tr><td>0</td><td>0</td><td>3</td><td></td></tr> <tr><td>0</td><td>0</td><td>4</td><td></td></tr> <tr><td>0</td><td>0</td><td>5</td><td></td></tr> <tr><td>0</td><td>0</td><td>6</td><td></td></tr> <tr><td>0</td><td>0</td><td>7</td><td></td></tr> <tr><td>1</td><td>1</td><td>0</td><td></td></tr> <tr><td>1</td><td>1</td><td>1</td><td></td></tr> <tr><td>1</td><td>1</td><td>2</td><td></td></tr> <tr><td>1</td><td>1</td><td>3</td><td></td></tr> <tr><td>1</td><td>1</td><td>4</td><td></td></tr> <tr><td>1</td><td>1</td><td>5</td><td></td></tr> <tr><td>1</td><td>1</td><td>6</td><td></td></tr> <tr><td>1</td><td>1</td><td>7</td><td></td></tr> <tr><td>2</td><td>2</td><td>0</td><td></td></tr> <tr><td>2</td><td>2</td><td>1</td><td></td></tr> <tr><td>2</td><td>2</td><td>2</td><td></td></tr> </tbody> </table> <p>Default Items Name Root: NICstatus</p> <p>Define Item(s)</p> <p>Delete Item(s)</p> <p>Select a zone and click on the "Define Item(s)" button to create: - One or several items - an array</p> <p>OK Cancel Help</p>	Offset/Device	Offset/Connection	Position in the Byte	Item Name	0	0	0		0	0	1		0	0	2		0	0	3		0	0	4		0	0	5		0	0	6		0	0	7		1	1	0		1	1	1		1	1	2		1	1	3		1	1	4		1	1	5		1	1	6		1	1	7		2	2	0		2	2	1		2	2	2	
Offset/Device	Offset/Connection	Position in the Byte	Item Name																																																																														
0	0	0																																																																															
0	0	1																																																																															
0	0	2																																																																															
0	0	3																																																																															
0	0	4																																																																															
0	0	5																																																																															
0	0	6																																																																															
0	0	7																																																																															
1	1	0																																																																															
1	1	1																																																																															
1	1	2																																																																															
1	1	3																																																																															
1	1	4																																																																															
1	1	5																																																																															
1	1	6																																																																															
1	1	7																																																																															
2	2	0																																																																															
2	2	1																																																																															
2	2	2																																																																															
5	<p>Click the Define Item(s) button. The Item Name Definition dialog opens:</p>  <p>Item Name Definition</p> <p>Define Selected Area As One or Several Single Item(s)</p> <p>Item Name (32 char max): NICstatus_IX*</p> <p>OK Cancel Help</p> <p>Note: The asterisk (*) indicates a series of discrete items with the same root name will be created.</p>																																																																																


Step	Action																																																																																
6	<p>Accept the default Item Name and click OK. 16 discrete input items are created:</p>  <p>The screenshot shows the 'Items Declaration' dialog box with the following table of items:</p> <table border="1" data-bbox="356 316 843 738"> <thead> <tr> <th>Offset/Device</th> <th>Offset/Connection</th> <th>Position in the Byte</th> <th>Item Name</th> </tr> </thead> <tbody> <tr><td>0</td><td>0</td><td>0</td><td>NICstatus_IJ0</td></tr> <tr><td>0</td><td>0</td><td>1</td><td>NICstatus_IJ1</td></tr> <tr><td>0</td><td>0</td><td>2</td><td>NICstatus_IJ2</td></tr> <tr><td>0</td><td>0</td><td>3</td><td>NICstatus_IJ3</td></tr> <tr><td>0</td><td>0</td><td>4</td><td>NICstatus_IJ4</td></tr> <tr><td>0</td><td>0</td><td>5</td><td>NICstatus_IJ5</td></tr> <tr><td>0</td><td>0</td><td>6</td><td>NICstatus_IJ6</td></tr> <tr><td>0</td><td>0</td><td>7</td><td>NICstatus_IJ7</td></tr> <tr><td>1</td><td>1</td><td>0</td><td>NICstatus_IJ0</td></tr> <tr><td>1</td><td>1</td><td>1</td><td>NICstatus_IJ1</td></tr> <tr><td>1</td><td>1</td><td>2</td><td>NICstatus_IJ2</td></tr> <tr><td>1</td><td>1</td><td>3</td><td>NICstatus_IJ3</td></tr> <tr><td>1</td><td>1</td><td>4</td><td>NICstatus_IJ4</td></tr> <tr><td>1</td><td>1</td><td>5</td><td>NICstatus_IJ5</td></tr> <tr><td>1</td><td>1</td><td>6</td><td>NICstatus_IJ6</td></tr> <tr><td>1</td><td>1</td><td>7</td><td>NICstatus_IJ7</td></tr> <tr><td>2</td><td>2</td><td>0</td><td></td></tr> <tr><td>2</td><td>2</td><td>1</td><td></td></tr> <tr><td>2</td><td>2</td><td>2</td><td></td></tr> </tbody> </table>	Offset/Device	Offset/Connection	Position in the Byte	Item Name	0	0	0	NICstatus_IJ0	0	0	1	NICstatus_IJ1	0	0	2	NICstatus_IJ2	0	0	3	NICstatus_IJ3	0	0	4	NICstatus_IJ4	0	0	5	NICstatus_IJ5	0	0	6	NICstatus_IJ6	0	0	7	NICstatus_IJ7	1	1	0	NICstatus_IJ0	1	1	1	NICstatus_IJ1	1	1	2	NICstatus_IJ2	1	1	3	NICstatus_IJ3	1	1	4	NICstatus_IJ4	1	1	5	NICstatus_IJ5	1	1	6	NICstatus_IJ6	1	1	7	NICstatus_IJ7	2	2	0		2	2	1		2	2	2	
Offset/Device	Offset/Connection	Position in the Byte	Item Name																																																																														
0	0	0	NICstatus_IJ0																																																																														
0	0	1	NICstatus_IJ1																																																																														
0	0	2	NICstatus_IJ2																																																																														
0	0	3	NICstatus_IJ3																																																																														
0	0	4	NICstatus_IJ4																																																																														
0	0	5	NICstatus_IJ5																																																																														
0	0	6	NICstatus_IJ6																																																																														
0	0	7	NICstatus_IJ7																																																																														
1	1	0	NICstatus_IJ0																																																																														
1	1	1	NICstatus_IJ1																																																																														
1	1	2	NICstatus_IJ2																																																																														
1	1	3	NICstatus_IJ3																																																																														
1	1	4	NICstatus_IJ4																																																																														
1	1	5	NICstatus_IJ5																																																																														
1	1	6	NICstatus_IJ6																																																																														
1	1	7	NICstatus_IJ7																																																																														
2	2	0																																																																															
2	2	1																																																																															
2	2	2																																																																															
7	<p>Repeat steps 3 - 6 for each group of discrete input items you need to create. In this example, that includes items for each of the following groups:</p> <ul style="list-style-type: none"> ● Byte: 2, Bits: 0-1, Default Items Name Root: DDI3230_inputdata ● Byte: 2, Bits: 2-3, Default Items Name Root: DDI3230_inputstatus ● Byte: 2, Bits: 4-5, Default Items Name Root: DDO3200_outputdataecho ● Byte: 2, Bits: 6-7, Default Items Name Root: DDO3200_outputstatus ● Byte: 3, Bits: 0-3, Default Items Name Root: DDI3420_inputdata ● Byte: 3, Bits: 4-7, Default Items Name Root: DDI3420_inputstatus ● Byte: 4, Bits: 0-3, Default Items Name Root: DDO3410_outputdataecho ● Byte: 4, Bits: 4-7, Default Items Name Root: DDO3410_outputstatus ● Byte: 5, Bits: 0-5, Default Items Name Root: DDI3610_inputdata ● Byte: 6, Bits: 0-5, Default Items Name Root: DDI3610_inputstatus ● Byte: 7, Bits: 0-5, Default Items Name Root: DDO3600_outputdataecho ● Byte: 8, Bits: 0-5, Default Items Name Root: DDO3600_outputstatus 																																																																																
8	<p>Click on the Discrete Output Items tab to open that page.</p>																																																																																

Creating Discrete Output Items

To create discrete output items for the STB NIC 2212 example, beginning with 2 discrete outputs for the STB DDO3200 module:


Step	Action
1	<p>The Discrete Output Items page looks like this:</p>  <p>Note: Again, both the Offset/Device and Offset/Connector columns represent the byte address of the discrete output, while the Position in the Byte column indicates the bit position of the discrete output item.</p>
2	In the Default Items Name Root input box type: <code>DDO3200_outputdata</code> .



Step	Action
3	<p>In the Items List, select the rows that correspond to bits 0-1 in byte 0—i.e., the first 2 rows:</p> 
4	<p>Click the Define Item(s) button. The Item Name Definition opens:</p>  <p>Note: The asterisk (*) indicates a series of discrete items with the same root name will be created.</p>


Step	Action
5	<p>Accept the default Item Name and click OK. 2 discrete input items are created:</p> 
6	<p>Repeat steps 2 - 5 for each group of discrete output items you need to create. In this example, that includes items for each of the following groups:</p> <ul style="list-style-type: none"> ● Byte: 0, Bits: 2-5, Default Items Name Root: DDO3410_outputdata ● Byte: 1, Bits: 0-5, Default Items Name Root: DDO3600_outputdata
7	<p>Click on the Numeric Input Items tab to open that page.</p>

Creating Numeric Input Items

To create numeric input items for the STB NIC 2212 example, beginning with a channel 1 input data word for the STB AVI 1270 module:


Step	Action
1	<p>The Numeric Input Items page looks like this:</p>  <p>Note: In this example, both the Offset/Device and Offset/Connection columns represent the byte address. All items you create will be either an 8-bit byte or a 16-bit word.</p>
2	<p>In the Default Items Name Root input box type: AVI1270_CH1_inputdata.</p>



Step	Action																																																												
3	<p>In the Items List, select bytes (or rows) 10 and 11:</p>  <p>The screenshot shows the 'Items Declaration' dialog box with the following table:</p> <table border="1"> <thead> <tr> <th>Offset/Device</th> <th>Offset/Connection</th> <th>Item Name</th> </tr> </thead> <tbody> <tr><td><input type="checkbox"/> 0</td><td>0</td><td></td></tr> <tr><td><input type="checkbox"/> 1</td><td>1</td><td></td></tr> <tr><td><input type="checkbox"/> 2</td><td>2</td><td></td></tr> <tr><td><input type="checkbox"/> 3</td><td>3</td><td></td></tr> <tr><td><input type="checkbox"/> 4</td><td>4</td><td></td></tr> <tr><td><input type="checkbox"/> 5</td><td>5</td><td></td></tr> <tr><td><input type="checkbox"/> 6</td><td>6</td><td></td></tr> <tr><td><input type="checkbox"/> 7</td><td>7</td><td></td></tr> <tr><td><input type="checkbox"/> 8</td><td>8</td><td></td></tr> <tr><td><input type="checkbox"/> 9</td><td>9</td><td></td></tr> <tr><td><input checked="" type="checkbox"/> 10</td><td>10</td><td></td></tr> <tr><td><input checked="" type="checkbox"/> 11</td><td>11</td><td></td></tr> <tr><td><input type="checkbox"/> 12</td><td>12</td><td></td></tr> <tr><td><input type="checkbox"/> 13</td><td>13</td><td></td></tr> <tr><td><input type="checkbox"/> 14</td><td>14</td><td></td></tr> <tr><td><input type="checkbox"/> 15</td><td>15</td><td></td></tr> <tr><td><input type="checkbox"/> 16</td><td>16</td><td></td></tr> <tr><td><input type="checkbox"/> 17</td><td>17</td><td></td></tr> <tr><td><input type="checkbox"/> 18</td><td>18</td><td></td></tr> </tbody> </table>	Offset/Device	Offset/Connection	Item Name	<input type="checkbox"/> 0	0		<input type="checkbox"/> 1	1		<input type="checkbox"/> 2	2		<input type="checkbox"/> 3	3		<input type="checkbox"/> 4	4		<input type="checkbox"/> 5	5		<input type="checkbox"/> 6	6		<input type="checkbox"/> 7	7		<input type="checkbox"/> 8	8		<input type="checkbox"/> 9	9		<input checked="" type="checkbox"/> 10	10		<input checked="" type="checkbox"/> 11	11		<input type="checkbox"/> 12	12		<input type="checkbox"/> 13	13		<input type="checkbox"/> 14	14		<input type="checkbox"/> 15	15		<input type="checkbox"/> 16	16		<input type="checkbox"/> 17	17		<input type="checkbox"/> 18	18	
Offset/Device	Offset/Connection	Item Name																																																											
<input type="checkbox"/> 0	0																																																												
<input type="checkbox"/> 1	1																																																												
<input type="checkbox"/> 2	2																																																												
<input type="checkbox"/> 3	3																																																												
<input type="checkbox"/> 4	4																																																												
<input type="checkbox"/> 5	5																																																												
<input type="checkbox"/> 6	6																																																												
<input type="checkbox"/> 7	7																																																												
<input type="checkbox"/> 8	8																																																												
<input type="checkbox"/> 9	9																																																												
<input checked="" type="checkbox"/> 10	10																																																												
<input checked="" type="checkbox"/> 11	11																																																												
<input type="checkbox"/> 12	12																																																												
<input type="checkbox"/> 13	13																																																												
<input type="checkbox"/> 14	14																																																												
<input type="checkbox"/> 15	15																																																												
<input type="checkbox"/> 16	16																																																												
<input type="checkbox"/> 17	17																																																												
<input type="checkbox"/> 18	18																																																												
4	<p>Click the Define Item(s) button. The Item Name Definition dialog opens:</p>  <p>The screenshot shows the 'Item Name Definition' dialog box with the following options:</p> <ul style="list-style-type: none"> New Item(s) Data Type: <ul style="list-style-type: none"> <input checked="" type="radio"/> Byte (8 bits) <input type="radio"/> Dword (32 bits) <input type="radio"/> Word (16 bits) <input type="radio"/> IEEE float Define Selected Area As: <ul style="list-style-type: none"> <input checked="" type="radio"/> One or Several Single Items <input type="radio"/> One Item of Array Type <p>The input field contains: AVI1270_CH1_inputdata_IB*</p>																																																												

Step	Action																																																												
5	<p>Select Word (16 bits) as the New Item(s) Data Type, then click OK. A new item is created:</p>  <p>The screenshot shows the 'Items Declaration' dialog box with the following details:</p> <ul style="list-style-type: none"> Tab: Discrete Input Items Table: <table border="1" data-bbox="367 316 864 738"> <thead> <tr> <th>Offset/Device</th> <th>Offset/Connection</th> <th>Item Name</th> </tr> </thead> <tbody> <tr><td><input type="checkbox"/> 0</td><td>0</td><td></td></tr> <tr><td><input type="checkbox"/> 1</td><td>1</td><td></td></tr> <tr><td><input type="checkbox"/> 2</td><td>2</td><td></td></tr> <tr><td><input type="checkbox"/> 3</td><td>3</td><td></td></tr> <tr><td><input type="checkbox"/> 4</td><td>4</td><td></td></tr> <tr><td><input type="checkbox"/> 5</td><td>5</td><td></td></tr> <tr><td><input type="checkbox"/> 6</td><td>6</td><td></td></tr> <tr><td><input type="checkbox"/> 7</td><td>7</td><td></td></tr> <tr><td><input type="checkbox"/> 8</td><td>8</td><td></td></tr> <tr><td><input type="checkbox"/> 9</td><td>9</td><td></td></tr> <tr><td><input checked="" type="checkbox"/> 10</td><td>10</td><td>AVI1270CH1_inputdata_IW10</td></tr> <tr><td><input checked="" type="checkbox"/> 11</td><td>11</td><td></td></tr> <tr><td><input type="checkbox"/> 12</td><td>12</td><td></td></tr> <tr><td><input type="checkbox"/> 13</td><td>13</td><td></td></tr> <tr><td><input type="checkbox"/> 14</td><td>14</td><td></td></tr> <tr><td><input type="checkbox"/> 15</td><td>15</td><td></td></tr> <tr><td><input type="checkbox"/> 16</td><td>16</td><td></td></tr> <tr><td><input type="checkbox"/> 17</td><td>17</td><td></td></tr> <tr><td><input type="checkbox"/> 18</td><td>18</td><td></td></tr> </tbody> </table> Default Items Name Root: AVI1270_CH1_inputd Buttons: Define Item(s), Delete Item(s), OK, Cancel, Help 	Offset/Device	Offset/Connection	Item Name	<input type="checkbox"/> 0	0		<input type="checkbox"/> 1	1		<input type="checkbox"/> 2	2		<input type="checkbox"/> 3	3		<input type="checkbox"/> 4	4		<input type="checkbox"/> 5	5		<input type="checkbox"/> 6	6		<input type="checkbox"/> 7	7		<input type="checkbox"/> 8	8		<input type="checkbox"/> 9	9		<input checked="" type="checkbox"/> 10	10	AVI1270CH1_inputdata_IW10	<input checked="" type="checkbox"/> 11	11		<input type="checkbox"/> 12	12		<input type="checkbox"/> 13	13		<input type="checkbox"/> 14	14		<input type="checkbox"/> 15	15		<input type="checkbox"/> 16	16		<input type="checkbox"/> 17	17		<input type="checkbox"/> 18	18	
Offset/Device	Offset/Connection	Item Name																																																											
<input type="checkbox"/> 0	0																																																												
<input type="checkbox"/> 1	1																																																												
<input type="checkbox"/> 2	2																																																												
<input type="checkbox"/> 3	3																																																												
<input type="checkbox"/> 4	4																																																												
<input type="checkbox"/> 5	5																																																												
<input type="checkbox"/> 6	6																																																												
<input type="checkbox"/> 7	7																																																												
<input type="checkbox"/> 8	8																																																												
<input type="checkbox"/> 9	9																																																												
<input checked="" type="checkbox"/> 10	10	AVI1270CH1_inputdata_IW10																																																											
<input checked="" type="checkbox"/> 11	11																																																												
<input type="checkbox"/> 12	12																																																												
<input type="checkbox"/> 13	13																																																												
<input type="checkbox"/> 14	14																																																												
<input type="checkbox"/> 15	15																																																												
<input type="checkbox"/> 16	16																																																												
<input type="checkbox"/> 17	17																																																												
<input type="checkbox"/> 18	18																																																												
6	<p>Repeat steps 2 - 5 for each group of numeric input item you need to create. In this example, that includes items for each of the following groups:</p> <ul style="list-style-type: none"> ● Byte: 12, Default Items Name Root: AVI1270_CH1_inputstatus ● Word: 14-15, Default Items Name Root: AVI1270_CH2_inputdata ● Byte: 16, Default Items Name Root: AVI1270_CH2_inputstatus ● Byte: 17, Default Items Name Root: AVO1250_CH1_outputstatus ● Byte: 18, Default Items Name Root: AVO1250_CH2_outputstatus 																																																												
7	<p>Click on the Numeric Output Items tab to open that page.</p>																																																												

Creating Numeric Output Items



To create numeric output items for the STB NIC 2212, example, beginning with a output data word for the STB AVO 1250 module:

Step	Action
1	<p>The Numeric Output Items opens:</p>  <p>Note: In this example, both the Offset/Device and Offset/Connection columns represent the byte address. All items you create will be 16-bit words comprising 2 bytes.</p>
2	<p>In the Default Items name Root input box type: AVO1250_CH1_outputdata.</p>

Step	Action
3	<p>In the Items List, select bytes (or rows) 10 and 11:</p> 
4	<p>Click the Define Item(s) button. The Item Name Definition dialog opens:</p> 
5	Repeat steps 2 - 5 for the AVO 1250 channel 2 output data at bytes 4 and 5.
6	Click OK to close the Items Declaration window.
7	Select File → Save to save your edits.

Viewing Input and Output Item Addresses

The final step in this example is to view the address the Control Expert EtherNet/IP configuration tool assigns to each newly created input and output item. To do this:

Step	Action																																																																																																																																										
1	<p>In the Devices window of the Control Expert EtherNet/IP configuration tool, the item at Position 000 should still be selected. If not, select it, as shown below:</p>  <p>The automatically configured input and output items appear on the right side of the screen in the I/O area (as depicted in the next step, below).</p>																																																																																																																																										
2	<p>If necessary, use the horizontal scroll bar to scroll to the far right of the input or output area and display the Address column, which identifies the location of the input or output in the 140 NOC 771 00:</p>  <table border="1"> <thead> <tr> <th>Input Item Name</th> <th>Data Type</th> <th>Offset/Device</th> <th>Offset/Connection</th> <th>Position in Byte</th> <th>Address</th> </tr> </thead> <tbody> <tr><td>NICstatus_DX0</td><td>Input bit</td><td>0</td><td>0</td><td>0</td><td>%MW8.0</td></tr> <tr><td>NICstatus_DX1</td><td>Input bit</td><td>0</td><td>0</td><td>1</td><td>%MW8.1</td></tr> <tr><td>NICstatus_DX2</td><td>Input bit</td><td>0</td><td>0</td><td>2</td><td>%MW8.2</td></tr> <tr><td>NICstatus_DX3</td><td>Input bit</td><td>0</td><td>0</td><td>3</td><td>%MW8.3</td></tr> <tr><td>NICstatus_DX4</td><td>Input bit</td><td>0</td><td>0</td><td>4</td><td>%MW8.4</td></tr> <tr><td>NICstatus_DX5</td><td>Input bit</td><td>0</td><td>0</td><td>5</td><td>%MW8.5</td></tr> <tr><td>NICstatus_DX6</td><td>Input bit</td><td>0</td><td>0</td><td>6</td><td>%MW8.6</td></tr> </tbody> </table> <table border="1"> <thead> <tr> <th>Output Item Name</th> <th>Data Type</th> <th>Offset/Device</th> <th>Offset/Connection</th> <th>Position in Byte</th> <th>Address</th> </tr> </thead> <tbody> <tr><td>DDO3200_outputdata_QX0</td><td>Output bit</td><td>0</td><td>0</td><td>0</td><td>%MW0.0</td></tr> <tr><td>DDO3200_outputdata_QX1</td><td>Output bit</td><td>0</td><td>0</td><td>1</td><td>%MW0.1</td></tr> <tr><td>DDO3410_outputdata_QX2</td><td>Output bit</td><td>0</td><td>0</td><td>2</td><td>%MW0.2</td></tr> <tr><td>DDO3410_outputdata_QX3</td><td>Output bit</td><td>0</td><td>0</td><td>3</td><td>%MW0.3</td></tr> <tr><td>DDO3410_outputdata_QX4</td><td>Output bit</td><td>0</td><td>0</td><td>4</td><td>%MW0.4</td></tr> <tr><td>DDO3410_outputdata_QX5</td><td>Output bit</td><td>0</td><td>0</td><td>5</td><td>%MW0.5</td></tr> <tr><td>DDO3600_outputdata_QX8</td><td>Output bit</td><td>1</td><td>1</td><td>0</td><td>%MW0.8</td></tr> <tr><td>DDO3600_outputdata_QX9</td><td>Output bit</td><td>1</td><td>1</td><td>1</td><td>%MW0.9</td></tr> <tr><td>DDO3600_outputdata_QX10</td><td>Output bit</td><td>1</td><td>1</td><td>2</td><td>%MW0.10</td></tr> <tr><td>DDO3600_outputdata_QX11</td><td>Output bit</td><td>1</td><td>1</td><td>3</td><td>%MW0.11</td></tr> <tr><td>DDO3600_outputdata_QX12</td><td>Output bit</td><td>1</td><td>1</td><td>4</td><td>%MW0.12</td></tr> <tr><td>DDO3600_outputdata_QX13</td><td>Output bit</td><td>1</td><td>1</td><td>5</td><td>%MW0.13</td></tr> <tr><td>AVO1250_CH1_outputdata_</td><td>Output word</td><td>2</td><td>2</td><td></td><td>%MW1</td></tr> <tr><td>AVO1250_CH2_outputdata_</td><td>Output word</td><td>4</td><td>4</td><td></td><td>%MW2</td></tr> </tbody> </table>	Input Item Name	Data Type	Offset/Device	Offset/Connection	Position in Byte	Address	NICstatus_DX0	Input bit	0	0	0	%MW8.0	NICstatus_DX1	Input bit	0	0	1	%MW8.1	NICstatus_DX2	Input bit	0	0	2	%MW8.2	NICstatus_DX3	Input bit	0	0	3	%MW8.3	NICstatus_DX4	Input bit	0	0	4	%MW8.4	NICstatus_DX5	Input bit	0	0	5	%MW8.5	NICstatus_DX6	Input bit	0	0	6	%MW8.6	Output Item Name	Data Type	Offset/Device	Offset/Connection	Position in Byte	Address	DDO3200_outputdata_QX0	Output bit	0	0	0	%MW0.0	DDO3200_outputdata_QX1	Output bit	0	0	1	%MW0.1	DDO3410_outputdata_QX2	Output bit	0	0	2	%MW0.2	DDO3410_outputdata_QX3	Output bit	0	0	3	%MW0.3	DDO3410_outputdata_QX4	Output bit	0	0	4	%MW0.4	DDO3410_outputdata_QX5	Output bit	0	0	5	%MW0.5	DDO3600_outputdata_QX8	Output bit	1	1	0	%MW0.8	DDO3600_outputdata_QX9	Output bit	1	1	1	%MW0.9	DDO3600_outputdata_QX10	Output bit	1	1	2	%MW0.10	DDO3600_outputdata_QX11	Output bit	1	1	3	%MW0.11	DDO3600_outputdata_QX12	Output bit	1	1	4	%MW0.12	DDO3600_outputdata_QX13	Output bit	1	1	5	%MW0.13	AVO1250_CH1_outputdata_	Output word	2	2		%MW1	AVO1250_CH2_outputdata_	Output word	4	4		%MW2
Input Item Name	Data Type	Offset/Device	Offset/Connection	Position in Byte	Address																																																																																																																																						
NICstatus_DX0	Input bit	0	0	0	%MW8.0																																																																																																																																						
NICstatus_DX1	Input bit	0	0	1	%MW8.1																																																																																																																																						
NICstatus_DX2	Input bit	0	0	2	%MW8.2																																																																																																																																						
NICstatus_DX3	Input bit	0	0	3	%MW8.3																																																																																																																																						
NICstatus_DX4	Input bit	0	0	4	%MW8.4																																																																																																																																						
NICstatus_DX5	Input bit	0	0	5	%MW8.5																																																																																																																																						
NICstatus_DX6	Input bit	0	0	6	%MW8.6																																																																																																																																						
Output Item Name	Data Type	Offset/Device	Offset/Connection	Position in Byte	Address																																																																																																																																						
DDO3200_outputdata_QX0	Output bit	0	0	0	%MW0.0																																																																																																																																						
DDO3200_outputdata_QX1	Output bit	0	0	1	%MW0.1																																																																																																																																						
DDO3410_outputdata_QX2	Output bit	0	0	2	%MW0.2																																																																																																																																						
DDO3410_outputdata_QX3	Output bit	0	0	3	%MW0.3																																																																																																																																						
DDO3410_outputdata_QX4	Output bit	0	0	4	%MW0.4																																																																																																																																						
DDO3410_outputdata_QX5	Output bit	0	0	5	%MW0.5																																																																																																																																						
DDO3600_outputdata_QX8	Output bit	1	1	0	%MW0.8																																																																																																																																						
DDO3600_outputdata_QX9	Output bit	1	1	1	%MW0.9																																																																																																																																						
DDO3600_outputdata_QX10	Output bit	1	1	2	%MW0.10																																																																																																																																						
DDO3600_outputdata_QX11	Output bit	1	1	3	%MW0.11																																																																																																																																						
DDO3600_outputdata_QX12	Output bit	1	1	4	%MW0.12																																																																																																																																						
DDO3600_outputdata_QX13	Output bit	1	1	5	%MW0.13																																																																																																																																						
AVO1250_CH1_outputdata_	Output word	2	2		%MW1																																																																																																																																						
AVO1250_CH2_outputdata_	Output word	4	4		%MW2																																																																																																																																						

Section 3.4

Connecting to Third Party Devices

Overview

The EtherNet/IP communication module can connect to and communicate with EtherNet/IP devices made by third party manufacturers. This section describes how to set up communications with the Rockwell Automation 1734-AENT remote device and its I/O.

What Is in This Section?

This section contains the following topics:

Topic	Page
Adding a Third Party Device to the Sample Network	115
Add an EDS File	116
Automatically Detect and Add the 1734-AENT PointIO Adapter	119
Configuring 1734-AENT PointIO Adapter Properties	120
Viewing 1734-AENT PointIO Adapter I/O Addresses	124

Adding a Third Party Device to the Sample Network


Overview

The next task is to extend the sample network by adding the following third party devices:

- 1734-AENT PointIO adapter with IP address of 192.168.001.011
- 1734-IB4/C 4pt DC input module
- 1734-OB2E 2pt DC output module

Network Topology

The modified network topology looks like this:



To re-create this example, be sure to:

- use the IP addresses for your own configuration's:
 - PC
 - 140 NOC 771 00 EtherNet/IP communication module
 - STB NIC 2212 EtherNet/IP network interface module
 - 1734-AENT PointIO adapter
- check all wiring

NOTE: Control Expert software running in the PC is used to configure the CPU 651 60 controller. In this example, the PC is indirectly wired to the CPU's Ethernet port via the Ethernet switch. Alternatively, you could bypass the switch and directly wire the PC to either the CPU's Modbus or USB ports.

Add an EDS File

Overview

Before you can add a third party device to your configuration, be sure the EDS file for that device is included in the Control Expert EtherNet/IP configuration tool's **Device Library**.


Use the EDS management wizard to add one or more EDS files to the **Device Library**. The wizard presents a series of instruction screens that:


- simplify the process of adding EDS files to the **Device Library**, and
- provide a redundancy check that insures the same version of an EDS file cannot be added more than once

Note: Click **Devices** → **Options...** to open the **Display Options** window, where you can turn on or off the display of messages indicating the EDS file you are adding is a duplicate, or a different version of an EDS file already included in the **Device Library**.

Adding EDS Files

To add one or more EDS files to the **Device Library**:

Step	Action
1	<p>Do one of the following:</p> <ul style="list-style-type: none"> • in the Device Library, click the Add button , or • in the Library menu, click Add <p>Page 1 of the wizard opens.</p>
2	<p>Click Next. Page 2 of the wizard opens:</p>  <p>In the Select the Location of the EDS File(s) section, select either:</p> <ul style="list-style-type: none"> • Add File(s), to add one or more EDS files you will individually select, or • Add all the EDS Files from the Directory, to add all files from a folder you will select. <ul style="list-style-type: none"> ○ Select Look in Subfolders to also add EDS files in subfolders beneath the folder you select
3	<p>In the Select the Location of the EDS File(s) section, select either:</p> <ul style="list-style-type: none"> • Add File(s), to add one or more EDS files you will individually select, or • Add all the EDS Files from the Directory, to add all files from a folder you will select. <ul style="list-style-type: none"> ○ Select Look in Subfolders to also add EDS files in subfolders beneath the folder you select

Step	Action
4	<p>Click the Browse button. The Open dialog opens:</p>  <p>The screenshot shows an 'Open' dialog box with the title bar 'Open'. The 'Look in:' field shows 'ETHERNETIP_IP_EDS'. The file list contains several files with names like 'temp', '004D00800010101.eds', '004D00C007A0101.eds', etc. At the bottom, there are 'File name:' and 'Files of type:' fields, and 'Open' and 'Cancel' buttons.</p>
5	<p>Use the Open dialog to navigate to and select:</p> <ul style="list-style-type: none"> ● one or more EDS files, or ● a folder containing EDS files
6	<p>Click Open. The dialog closes and your selection appears in the Directory or File Name field.</p>
7	<p>Choose the naming convention rule for the EDS DTM name creation. The new naming convention is based on Model Name / Product Name and Revision. A random character is automatically suffixed when Model Name / Product Name and Revision of an EDS file of the library are identical. The new naming convention is irrespective of the order in which EDS files are added to device library. By default, the Naming Convention check box is selected and the new naming rule applies. NOTE: To keep backward compatibility with Control Expert versions, unchecked the Naming Convention check box and the naming rule is based on Model Name / Product Name.</p>
8	<p>Click Next. The wizard compares the selected EDS files against existing files in the Device Library.</p>
9	<p>(Conditional) If one or more selected EDS files are duplicates and if notice of redundant files is enabled in the Display Options dialog, the configuration tool displays a File Already Exists message. Close the message.</p>
10	<p>Page 3 of the wizard opens indicating the Status of each device you selected</p> <ul style="list-style-type: none"> ● a green check mark indicates the EDS file can be added ● a blue informational icon indicates a redundant file ● a red check mark indicates an invalid EDS file <p>(Optional) Select a file in the list, then click View Selected File to open it.</p>
11	<p>Click Next to add the non-duplicate files. Page 4 of the wizard opens, indicating the action is complete.</p>
12	<p>Click Finish to close the wizard. The device(s) you added can now be inserted into your EtherNet/IP configuration.</p>

Automatically Detect and Add the 1734-AENT PointIO Adapter


Overview

Use the Control Expert EtherNet/IP configuration tool to automatically detect the 1734-AENT PointIO adapter. After it is detected, you can add it to your project.

NOTE: The 1734-AENT must be active online with a valid IP address before you can detect and add it to your project.

Detecting and Adding Network Devices

To automatically detect the 1734-AENT, then add it to your project, follow these steps:

Step	Action
1	Launch the configuration tool from the Configuration page of the EtherNet/IP communication module's Properties window.
2	In the configuration tool, begin on-line operations by clicking the Go Online button  .
3	Click on the Configuration tab to enable automatic network detection: 
4	Click the Read Network Configuration toolbar button  . The configuration tool searches the network for EtherNet/IP devices, classifies them using the device EDS file, then lists the EtherNet/IP devices it detects. 
5	Select the 1734-AENT PointIO Adapter in Network Detection window.
6	Click the Insert in Configuration button  . The Properties window opens, where you can configure the 1734-AENT PointIO adapter.

Configuring 1734-AENT PointIO Adapter Properties


Overview


The 1734-AENT PointIO adapter module properties window presents the following tabbed pages. Only some of these pages need to be edited for this example:



In this page...	Do the following...
General	<ul style="list-style-type: none">● input device name● configure IP address● add the device to the project configuration
Chassis	Add 2 I/O modules to the chassis: <ul style="list-style-type: none">● 1734-IB4/C 4pt DC input module● 1734-OB2E 2pt DC output module
Connections	Accept the default settings.
Online Parameters	Accept the default settings, if any.
Module Informations	(Read-only page - no configuration required)
Port Configuration	(Read-only page - no configuration required)
EDS File	(Read-only page - no configuration required)

Configuring the 1734-AENT

The following settings are used in the sample configuration:

Step	Action								
1	<p>Click on the General page:</p> 								
2	<p>In the General page, edit the following settings:</p> <table border="1" data-bbox="351 1149 1100 1344"> <tbody> <tr> <td>Device Name</td> <td>1734_AENT</td> </tr> <tr> <td>Number</td> <td>The sequence of the device in the Devices window. for this example, type in 003.</td> </tr> <tr> <td>Active Configuration</td> <td>Be sure this checkbox is selected.</td> </tr> <tr> <td>IP Address</td> <td>192.168.001.011</td> </tr> </tbody> </table>	Device Name	1734_AENT	Number	The sequence of the device in the Devices window. for this example, type in 003 .	Active Configuration	Be sure this checkbox is selected.	IP Address	192.168.001.011
Device Name	1734_AENT								
Number	The sequence of the device in the Devices window. for this example, type in 003 .								
Active Configuration	Be sure this checkbox is selected.								
IP Address	192.168.001.011								

Step	Action										
3	<p>Click on the Chassis page:</p> 										
4	<p>In the Chassis page, do the following:</p> <table border="1" data-bbox="316 683 1070 1070"> <tbody> <tr> <td data-bbox="316 683 395 797">a</td> <td data-bbox="395 683 1070 797"> <p>Select 1734 Chassis 3 in the Chassis Type Available in the Device Library list. The Available Modules for the Chassis list is populated and two [Empty] rows appear in the Configured Modules list.</p> </td> </tr> <tr> <td data-bbox="316 797 395 862">b</td> <td data-bbox="395 797 1070 862"> <p>Select 1734-IB4/C 4pt DC Input in the Available Modules for the Chassis list.</p> </td> </tr> <tr> <td data-bbox="316 862 395 935">c</td> <td data-bbox="395 862 1070 935"> <p>Click the Insert button . The module appears in position 01 in the Configured Modules list.</p> </td> </tr> <tr> <td data-bbox="316 935 395 1000">d</td> <td data-bbox="395 935 1070 1000"> <p>Select 1734-OB2E/C 2pt DC Output in the Available Modules for the Chassis list.</p> </td> </tr> <tr> <td data-bbox="316 1000 395 1070">e</td> <td data-bbox="395 1000 1070 1070"> <p>Click the Insert button . The module appears in position 02 in the Configured Modules list.</p> </td> </tr> </tbody> </table>	a	<p>Select 1734 Chassis 3 in the Chassis Type Available in the Device Library list. The Available Modules for the Chassis list is populated and two [Empty] rows appear in the Configured Modules list.</p>	b	<p>Select 1734-IB4/C 4pt DC Input in the Available Modules for the Chassis list.</p>	c	<p>Click the Insert button . The module appears in position 01 in the Configured Modules list.</p>	d	<p>Select 1734-OB2E/C 2pt DC Output in the Available Modules for the Chassis list.</p>	e	<p>Click the Insert button . The module appears in position 02 in the Configured Modules list.</p>
a	<p>Select 1734 Chassis 3 in the Chassis Type Available in the Device Library list. The Available Modules for the Chassis list is populated and two [Empty] rows appear in the Configured Modules list.</p>										
b	<p>Select 1734-IB4/C 4pt DC Input in the Available Modules for the Chassis list.</p>										
c	<p>Click the Insert button . The module appears in position 01 in the Configured Modules list.</p>										
d	<p>Select 1734-OB2E/C 2pt DC Output in the Available Modules for the Chassis list.</p>										
e	<p>Click the Insert button . The module appears in position 02 in the Configured Modules list.</p>										

Step	Action
5	<p>The configured Chassis page looks like this:</p> 
6	<p>Click OK to save your settings and close the properties window. A node is added to the project configuration in the Devices window:</p>  <p>The next step is to view the device's inputs and outputs.</p>

Viewing 1734-AENT PointIO Adapter I/O Addresses

Overview


Because the Device Library includes EDS files for the 1734-AENT PointIO adapter and its discrete input and output modules, the Control Expert EtherNet/IP configuration tool automatically:



- creates a rack optimized CIP connection from the 140 NOC 771 00 EtherNet/IP communication module to the 1734-AENT PointIO adapter, and
- configures each input and output item by assigning:
 - an item name
 - an address location
 - a size allotment based on its data type

NOTE: In this example, the configuration tool created a rack optimized connection, which is more efficient. A rack optimized connection can be used only with discrete (digital) I/O modules. For analog I/O modules, each analog module NOC 771 00 using a separate connection.

Viewing the CIP Connection and I/O

To view the automatically created CIP connection and the I/O items in the Control Expert EtherNet/IP configuration tool:

Step	Action																																																				
1	<p>In the Devices window, select the 1734-AENT:</p> 																																																				
2	<p>In the Devices menu, select Properties. The Properties window opens for the 1734-AENT.</p>																																																				
3	<p>In the Connections tab, under the top-most Rack Optimization connection, select General. The rack optimized connection properties are displayed in the Connection Parameters list:</p>  <table border="1" data-bbox="665 698 1077 1015"> <thead> <tr> <th>Name:</th> <th>Value:</th> <th>Unit:</th> <th>...</th> </tr> </thead> <tbody> <tr> <td colspan="4">Connection Bit Health Offset###</td> </tr> <tr> <td>Request Packet Interval</td> <td>30</td> <td>ms</td> <td></td> </tr> <tr> <td>Time-out Multiplier</td> <td>x4</td> <td></td> <td></td> </tr> <tr> <td colspan="4">Input - T->O</td> </tr> <tr> <td>Input Mode</td> <td>Multicast</td> <td></td> <td></td> </tr> <tr> <td>Input Type</td> <td>Fixed</td> <td></td> <td></td> </tr> <tr> <td>Priority</td> <td>Scheduled</td> <td></td> <td></td> </tr> <tr> <td>Trigger Type</td> <td>Cyclic</td> <td></td> <td></td> </tr> <tr> <td colspan="4">Output - O->T</td> </tr> <tr> <td>Output Mode</td> <td>Point to Point</td> <td></td> <td></td> </tr> <tr> <td>Output Type</td> <td>Fixed</td> <td></td> <td></td> </tr> <tr> <td>Priority</td> <td>Scheduled</td> <td></td> <td></td> </tr> </tbody> </table>	Name:	Value:	Unit:	...	Connection Bit Health Offset###				Request Packet Interval	30	ms		Time-out Multiplier	x4			Input - T->O				Input Mode	Multicast			Input Type	Fixed			Priority	Scheduled			Trigger Type	Cyclic			Output - O->T				Output Mode	Point to Point			Output Type	Fixed			Priority	Scheduled		
Name:	Value:	Unit:	...																																																		
Connection Bit Health Offset###																																																					
Request Packet Interval	30	ms																																																			
Time-out Multiplier	x4																																																				
Input - T->O																																																					
Input Mode	Multicast																																																				
Input Type	Fixed																																																				
Priority	Scheduled																																																				
Trigger Type	Cyclic																																																				
Output - O->T																																																					
Output Mode	Point to Point																																																				
Output Type	Fixed																																																				
Priority	Scheduled																																																				

Step	Action																																																																														
4	<p>In the Devices window, navigate to and select the first Rack Optimized connection item at Position 000, as shown below:</p>  <p>The automatically configured input and output items appear on the right side of the screen in the I/O area (as depicted in the next step, below).</p>																																																																														
5	<p>If necessary, use the horizontal scroll bar to scroll to the far right of the input or output area and display the Address column, which identifies the location of the input or output in the 140 NOC 771 00:</p>  <table border="1" data-bbox="326 816 1081 1019"> <thead> <tr> <th>Input Item Name</th> <th>Data Type</th> <th>Offset/Device</th> <th>Offset/Connection</th> <th>Position in Byte</th> <th>Address</th> </tr> </thead> <tbody> <tr> <td>Slot00_Target_Error_Co</td> <td>Input dword</td> <td>0</td> <td>0</td> <td></td> <td>%MW18</td> </tr> <tr> <td>Slot00_Target_Error_Co</td> <td>Input dword</td> <td>4</td> <td>4</td> <td></td> <td>%MW20</td> </tr> <tr> <td>Slot01_Input_Value_0</td> <td>Input bit</td> <td>9</td> <td>9</td> <td>0</td> <td>%MW22.8</td> </tr> <tr> <td>Slot01_Input_Value_1</td> <td>Input bit</td> <td>9</td> <td>9</td> <td>1</td> <td>%MW22.9</td> </tr> <tr> <td>Slot01_Input_Value_2</td> <td>Input bit</td> <td>9</td> <td>9</td> <td>2</td> <td>%MW22.10</td> </tr> <tr> <td>Slot01_Input_Value_3</td> <td>Input bit</td> <td>9</td> <td>9</td> <td>3</td> <td>%MW22.11</td> </tr> <tr> <td>Slot02_Status_Output_0</td> <td>Input bit</td> <td>10</td> <td>10</td> <td>0</td> <td>%MW23.0</td> </tr> <tr> <td>Slot02_Status_Output_1</td> <td>Input bit</td> <td>10</td> <td>10</td> <td>1</td> <td>%MW23.1</td> </tr> </tbody> </table> <table border="1" data-bbox="326 1027 1081 1133"> <thead> <tr> <th>Output Item Name</th> <th>Data Type</th> <th>Offset/Device</th> <th>Offset/Connection</th> <th>Position in Byte</th> <th>Address</th> </tr> </thead> <tbody> <tr> <td>Slot00_Reserved</td> <td>Array of 2 output words</td> <td>0</td> <td>0</td> <td></td> <td>%MW10</td> </tr> <tr> <td>Slot01_Input_Value_</td> <td>Input bit</td> <td>9</td> <td>9</td> <td>0</td> <td>%MW15.0</td> </tr> <tr> <td>Slot01_Input_Value_</td> <td>Input bit</td> <td>9</td> <td>9</td> <td></td> <td>%MW15.1</td> </tr> </tbody> </table>	Input Item Name	Data Type	Offset/Device	Offset/Connection	Position in Byte	Address	Slot00_Target_Error_Co	Input dword	0	0		%MW18	Slot00_Target_Error_Co	Input dword	4	4		%MW20	Slot01_Input_Value_0	Input bit	9	9	0	%MW22.8	Slot01_Input_Value_1	Input bit	9	9	1	%MW22.9	Slot01_Input_Value_2	Input bit	9	9	2	%MW22.10	Slot01_Input_Value_3	Input bit	9	9	3	%MW22.11	Slot02_Status_Output_0	Input bit	10	10	0	%MW23.0	Slot02_Status_Output_1	Input bit	10	10	1	%MW23.1	Output Item Name	Data Type	Offset/Device	Offset/Connection	Position in Byte	Address	Slot00_Reserved	Array of 2 output words	0	0		%MW10	Slot01_Input_Value_	Input bit	9	9	0	%MW15.0	Slot01_Input_Value_	Input bit	9	9		%MW15.1
Input Item Name	Data Type	Offset/Device	Offset/Connection	Position in Byte	Address																																																																										
Slot00_Target_Error_Co	Input dword	0	0		%MW18																																																																										
Slot00_Target_Error_Co	Input dword	4	4		%MW20																																																																										
Slot01_Input_Value_0	Input bit	9	9	0	%MW22.8																																																																										
Slot01_Input_Value_1	Input bit	9	9	1	%MW22.9																																																																										
Slot01_Input_Value_2	Input bit	9	9	2	%MW22.10																																																																										
Slot01_Input_Value_3	Input bit	9	9	3	%MW22.11																																																																										
Slot02_Status_Output_0	Input bit	10	10	0	%MW23.0																																																																										
Slot02_Status_Output_1	Input bit	10	10	1	%MW23.1																																																																										
Output Item Name	Data Type	Offset/Device	Offset/Connection	Position in Byte	Address																																																																										
Slot00_Reserved	Array of 2 output words	0	0		%MW10																																																																										
Slot01_Input_Value_	Input bit	9	9	0	%MW15.0																																																																										
Slot01_Input_Value_	Input bit	9	9		%MW15.1																																																																										

Chapter 4

Optimizing Performance

Overview

This chapter describes how to optimize performance of your EtherNet/IP network.

What Is in This Chapter?

This chapter contains the following sections:

Section	Topic	Page
4.1	Selecting a Switch	128
4.2	Control Application Design	139
4.3	Projecting Ethernet Network Performance	145

Section 4.1

Selecting a Switch

Overview

This section describes how to select an Ethernet switch for your network.

What Is in This Section?

This section contains the following topics:

Topic	Page
Role of a Switch in an Ethernet Network	129
Transmission Speed, Duplex and Auto-Negotiation	130
Quality of Service (QoS)	131
IGMP Snooping	132
Rapid Spanning Tree Protocol (RSTP)	133
Virtual Local Area Network (VLAN)	134
Port Mirroring	136
Virtual Local Area Network (VLAN)	137
Simple Network Management Protocol (SNMP) Agent	138

Role of a Switch in an Ethernet Network

Overview

Schneider Electric recommends the use of managed switches—not unmanaged switches or hubs—in process control networks. A managed switch provides more functionality than an unmanaged switch, including the ability to:

- turn switch ports on or off
- configure port speed and duplex settings
- control and monitor message traffic within segments
- prioritize message traffic

Recommended Switch Features

When acquiring an Ethernet switch for your process control network, confirm that the switch includes the following features:

- Multiple speed (10/100/1000 Mbps)
- Full duplex
- QoS
- IGMP snooping
- RSTP
- VLAN support
- Port mirroring
- SNMP agent

Transmission Speed, Duplex and Auto-Negotiation

Introduction

Most Ethernet switches support multiple transmission speeds, full- and half-duplex communication, and offer auto-negotiation capability. Hubs, by contrast, are not designed to support full duplex transmissions.

Duplex

Full duplex enables a switch port to both transmit and receive messages simultaneously, over two dedicated communication channels. Half duplex, by contrast, permits a port to transmit or receive messages in only one direction at a time. Signal collisions are possible in half duplex communications—because messages are transmitted and received over a single channel. Half duplex communications can cause poor performance and message loss.

Auto-Negotiation

Auto-negotiation permits a switch port—connected to a remote device that also supports auto-negotiation—to automatically configure itself for the maximum speed and duplex configuration supported by both devices. However, it may be necessary to manually configure the speed and duplex settings of the switch port, if its peer device does not possess auto-negotiation capability.

Recommendation

Schneider Electric recommends that you employ only switches that support:

- both auto-negotiation and manual configuration of speed and duplex settings
- multiple speeds: 10/100/1000 Mbps
- both full duplex and half duplex

Quality of Service (QoS)

Introduction

A switch that supports QoS packet tagging can be configured to deliver higher priority messages before messages with a lower (or no) priority. This enhances system determinism and increases the timely delivery of prioritized messages.

In the absence of QoS tagging, the switch delivers various application messages on a first-in first-out basis. This can result in poor system performance caused by the long forwarding delay—and late delivery—of high priority application messages, which may be handled after lower priority messages.

Types of QoS

The tagging types are based on the switch configuration:

Tagging type	Priority mapping rule	Description
Explicit (QoS tag in Ethernet packet)	DSCP or TOS field in IP header	Each IP based Ethernet packet contains a value in the DSCP or TOS field in its IP header, indicating the QoS priority. The switch forwards packets based on this priority.
	VLAN tag in Ethernet header	Each Ethernet packet contains a value in the priority field in the VLAN tag in its Ethernet header, indicating the QoS priority. The switch forwards packets based on this priority.
Implicit	Port based	Switch ports are mapped to different QoS priorities. For example, switch port 1 is mapped to QoS priority 1, switch port 2 is mapped to QoS priority 2, etc.

Recommendation

Schneider Electric recommends the use of devices—including switches—that support explicit QoS tagging.

NOTE: Some switches that support QoS tagging have this feature disabled by default. Confirm that QoS is enabled when deploying each switch.

IGMP Snooping

Multicast Messaging

Internet Group Management Protocol (IGMP) is an essential feature of multicast messaging. IGMP instructs routers and switches to forward Ethernet multicast packets to only those device ports that have requested these packets.

In the absence of IGMP snooping, a switch forwards multicast packets out of all its ports, resulting in greater network traffic, wasted network bandwidth, and degraded network performance.

Configure one Ethernet network switch as the IGMP querier. This switch periodically polls the field devices connected to the network, which causes all connected devices to issue an *IGMP Multicast Group Join* message. The group message is received by all network switches, which update their multicast addressing information databases in response.

Similarly, when an Ethernet device transmits an *IGMP Multicast Group Leave* message, all network switches update their multicast addressing information databases by removing the device from their databases.

Multicast messaging reduces network traffic by:

- requiring that a message be sent only once
- sending the message only to devices for which the message is intended

Recommendation

Schneider Electric recommend the following:

- employ switches that support IGMP V2 or higher
- because IGMP snooping may be disabled by default, enable IGMP snooping for each network switch
- confirm that one switch is configured as the IGMP querier

Rapid Spanning Tree Protocol (RSTP)

RSTP

Rapid Spanning Tree Protocol (RSTP) is an OSI layer 2 protocol defined by IEEE 802.1D 2004 that performs the following functions:

- it creates a loop-free logical network path for Ethernet devices that are part of a topology that includes redundant physical paths
- it automatically restores network communication—by activating redundant links—in the event the network experiences a broken link

RSTP software, operating simultaneously in every network switch, obtains information from each switch which enables the software to create a hierarchical logical network topology. RSTP is a flexible protocol that can be implemented on many physical topologies, including ring, mesh, or a combination of ring and mesh.

Recommendation

Schneider Electric recommends the following practices:

- Use RSTP instead of STP: RSTP provides a faster recovery time than STP
NOTE: Recovery time is the time that elapses between the moment a broken link is detected to the moment network service is restored. Recovery time depends on:
 - the number of switches in the topology: the more switches, the longer the recovery time
 - the processing speed of the switches in the topology: the slower the speed, the longer the recovery time
 - the bandwidth, traffic load, and topology pattern
- If the switch is part of a topology with redundant physical paths: enable RSTP.
- If the switch is part of a topology that does not include redundant physical paths: disable RSTP—in this case, disabling RSTP improves network performance.

Virtual Local Area Network (VLAN)

Introduction

Use VLANs to divide a larger network into smaller virtual groups of devices, and to split a switch into many virtual network switches. VLANs permit the creation of logically separate groups of network devices, without having to physically re-wire those devices.

When a switch receives a message directed to a specific VLAN, it forwards that message only to the switch ports connected to devices that are members of that VLAN. The switch does not send the message to other ports.

A VLAN reduces network traffic, blocks multicast and broadcast traffic from other VLANs, provides separation between VLANs, and improves system performance.


VLAN Types

Depending upon the switch features, there many different ways to define and implement VLANs:

Tagging type	Mapping rule	Description
Explicit (VLAN tag in Ethernet packet)	Tag based	Each VLAN group is assigned a unique VLAN ID, which is included in each Ethernet packet. The switch forwards packets based on VLAN ID.
Implicit (no VLAN tag in Ethernet packet)	Port based	Switch ports are assigned to different VLANs, when the switch is configured (see example, below.)
	MAC based	A switch maps VLAN group membership—and forwards Ethernet frames—based on device MAC address.
	Protocol based	A switch maps VLAN group membership—and forwards Ethernet frames—based on message protocol.
	IP-subnet based	A switch maps VLAN group membership—and forwards Ethernet frames—based on IP subnet portion of the target address.

Example

In the port-based VLAN example, below, switch ports 1, 2, and 3 are assigned to VLAN A, while switch ports 4, 5, and 6 are assigned to VLAN B:




NOTE: A single port can be a member of multiple VLANs.

Port Mirroring

Introduction

Port mirroring lets you troubleshoot switch port transmissions by copying the traffic that passes through one port (the source or mirrored port) and sending the copied transmission to a second port (the destination or mirror) port, where the packets can be examined.

In the following example, the data packets transmitted over port 1 are copied and sent to port 6. To troubleshoot port 1, a PC with packet sniffing software is used to analyze the traffic on port 6 and thereby troubleshoot port 1.



A target device of port 1 transmissions

B PC with packet sniffing software connected to port 6, which mirrors port 1 transmissions

Port mirroring does not affect the normal forwarding behavior of the mirrored port. In many switches, you can configure port mirroring so that you can forward and examine:

- only the incoming packets of a single mirrored port
- only the outgoing packets of a single mirrored port
- both the incoming and outgoing packets of a single mirrored port
- the packets of several mirrored ports—or the whole switch

A packet sniffer's troubleshooting features should include:

- analyzing network performance
- monitoring network activity

Recommendation

Schneider Electric recommends implementing port mirroring as follows:

- Use a destination or mirror port only for port mirroring and not for any other purpose. Connect only the PC with packet sniffer to the mirroring port.
- When configuring the switch, confirm that port mirroring is designed to forward packets—e.g., incoming, outgoing, or both—to meet your requirements.
- A packet sniffer's troubleshooting features should include the capabilities of analyzing network performance and monitoring network activity.

Virtual Local Area Network (VLAN)


A VLAN is a group of Ethernet devices—which may be physically located on different network segments—that are grouped together and communicate as if they were located on the same LAN segment. All devices on a VLAN use the same IP subnet.

In a port-based—or static—VLAN, an administrator configures VLAN membership by assigning individual switch ports to the VLAN. Any device connected to that port is effectively added to the VLAN.

NOTE: A single port can be a member of multiple VLANs.

VLANs permit the creation of logically separate groups of network devices, without having to physically re-wire those devices. When a switch receives a message directed to a specific VLAN, it forwards that message only to the switch ports that are members of that VLAN. The switch does not send the message to its ports that are not members of that VLAN.

In the example, below, switch ports 1, 2, and 3 are assigned to VLAN A, while switch ports 4, 5, and 6 are assigned to VLAN B:



Simple Network Management Protocol (SNMP) Agent

An *SNMP agent* is a software component that responds to queries about the management data of the switch, and reports events to another device acting as an SNMP manager.

The management data for a switch can include:

- operational state information (interface status, mode of operation, etc.)
- configuration parameters (IP address, features enabled / disabled, timer values, etc.)
- performance statistics (frame counters, event logs, etc.)

If a switch is equipped with SNMP agent software, a designated SNMP manager can:

- retrieve management data about the switch
- control the switch by editing its configuration settings
- receive traps—or notices of events—affecting the state of the switch

Section 4.2

Control Application Design

Overview

In a control system, control and automation are achieved by processing and delivering various application service messages.

Understanding messages, allocating network bandwidth among messages, and determining the time required for a message to traverse the network are all major performance considerations of your control application design.

What Is in This Section?

This section contains the following topics:

Topic	Page
Message Types	140
TCP Connections	142
CIP Connections and Messages	143
Messaging Performance	144

Message Types

Overview

Two types of industrial Ethernet message types are supported by the Ethernet communication module:

Message Type	Includes...
Explicit	<ul style="list-style-type: none">● Non-time critical management data● Read/write application data
Implicit	<ul style="list-style-type: none">● Real-time I/O data● Real-time control data● Real-time synchronization data

Explicit Messages

Explicit messages transmit information used for device configuration and diagnostics, and for data collection. In explicit messaging, the client issues a request; the server receives, processes, and sends a response back to the client.

You can specify a response timeout value, indicating how long the client waits for a response from the server. If the client does not receive a response from the server within the response timeout period, the client reissues its request. The length of the response timeout will vary depending on the requirements of your application.

Examples of explicit messages include: SNMP messages, FTP messages, CIP establish connection messages, EtherNet/IP query and response messages, and DHCP messages.

The characteristics of explicit messaging are:

- point-to-point client-server mode
- variable size
- variable frequency
- long response time
- long connection timeout

Explicit messages can be sent as either connected or unconnected, depending on the frequency of your need for data, and on the level of service required:

Message type	Characteristics
Connected	<ul style="list-style-type: none"> ● Begins when an originating device initiates a connection by sending a request to a target device. ● The connection is established when the originator receives a successful response from the target. ● A CIP connected message has a higher priority and provides better service, but requires a greater amount of resources from both the target and originator devices. ● Used for recurring requests, and for high priority parameter monitoring. ● Typically use short response timeout settings.
Unconnected	<ul style="list-style-type: none"> ● Less resource intensive. ● Used for less frequent requests, and for lower priority parameter monitoring. ● Typically use very long response timeout settings.

NOTE: The response timeout can be configured using the **EM Request Timeout** parameter (located in the **Channel Properties** → **EtherNet/IP** page).

Implicit Messages

Implicit messages consist of packets of data that are time critical. Implicit messages are used for real-time control and synchronization. Examples of implicit messages include: real-time I/O data, motion control data, functional diagnostic data, real-time synchronization data, and network topology management data.

Implicit messages require determinism and high performance in message processing and delivery.

The characteristics of implicit messaging are:

- producer/consumer mode (EtherNet/IP) or client/server mode (Modbus TCP)
- small, fixed data size
- fixed frequency
- short response time
- short connection timeout

TCP Connections

Overview

EtherNet/IP uses TCP connections as a pipeline for CIP connections. Both connected and unconnected messaging use the TCP connection.

TCP Connection Limits

The 140 NOC 771 00 EtherNet/IP communication module can provide up to 67 TCP connections, as follows:

Connection type	Maximum number of connections
I/O adapter	64 ¹
I/O scanner	
Explicit message client	
Explicit message server	3
Total TCP connections:	67
¹ 64 connections can be used for any combination of: <ul style="list-style-type: none"> ● I/O adapter connections ● I/O scanner connections ● explicit messages (as client) 	

A single TCP connection can support multiple CIP connections.

NOTE: TCP connections dedicated to other services, for example FTP, are not included in the above numbers.

CIP Connections and Messages

Overview

EtherNet/IP uses CIP connections to transmit messages between objects running in connected devices. There are different types of CIP connections.

Connection Types

CIP connection types include:

CIP connection type...	Supports...
Rack optimized	<p>The grouping of data from multiple, I/O modules in the same rack transmitted over a single connection.</p> <p>Note: A rack optimized connection:</p> <ul style="list-style-type: none"> • can transmit only device status and data • applies only to digital I/O modules <p>A CIP connection is consumed by each I/O module, in addition to the rack optimized connection.</p>
Direct	<p>A link between a controller and a single device.</p> <p>Note: A connection to an analog I/O module must be via a direct connection.</p>

Connection Limits

The 140 NOC 771 00 EtherNet/IP communication module can provide up to 198 concurrent CIP connections, as follows:

Connection type	Maximum number of connections
I/O adapter	128 ¹
I/O scanner	
Explicit message client	64
Explicit message server	6
Total TCP connections:	198
¹ 128 CIP connections can be used for any combination of: <ul style="list-style-type: none"> • I/O adapter connections • I/O scanner connections 	

NOTE: Up to 16 simultaneous explicit messaging connections can be active per scan.

Messaging Performance

Maximum Messaging Load

The Ethernet communication module supports the following maximum messaging loads:

Message Type	Maximum Messaging Load
Implicit (EtherNet/IP plus Modbus TCP)	12000 packets per second, with no simultaneous explicit messages
Explicit (EtherNet/IP plus Modbus TCP)	120 packets per second, with a maximum of 6000 simultaneous implicit messages

Section 4.3

Projecting Ethernet Network Performance

Overview

This section presents an example of how to calculate the impact of your project on Ethernet network performance.

What Is in This Section?

This section contains the following topics:

Topic	Page
Allocating Network Bandwidth	146
Network Load and Bandwidth Calculation Example	148

Allocating Network Bandwidth

Introduction

Maximum network bandwidth equals your network speed, for example 100 Mbps. When designing your control network, allocate network bandwidth among the control application messages required by your application.

NOTE: Schneider Electric recommends you reserve at least the following amounts for processing explicit messaging:

- 10% of network bandwidth
- 10% of CPU processing capacity for each network device

Message Load and Message Bandwidth

Message Load—in packets per second (PPS)—represents the number of packets in a single message that are received and sent within one second. *Message Load* can be estimated as follows:

Message Load =

$$(\text{number of packets per connection}) \times (\text{number of connections}) / \text{RPI}$$

The *number of packets per connection* value depends on the capacity of the device, and can be either:

- 1: for connections that support uni-directional communication
- 2: for connections that support input and output (for producer/consumer mode) or request and response (for client/server mode) per one time bi-directional exchange, or

The connection can be used for either explicit or implicit messaging. For UDP-based explicit messaging, assume that each client represents one connection, and that messages are transmitted cyclically.

Message Bandwidth (in bits) can be calculated as follows:

Message Bandwidth = message packet size (bits) x Message Load

Based on the portion of network bandwidth you want to allocate to a particular message, you can use the *Message Load* and *Message Bandwidth* formulae to calculate the fastest RPI for the message.

Device Load and Device Bandwidth

Device Load—measured in number of packets—represents the load contributed by messages received and sent by a device within one second. *Device Load* is the sum of the *Message Load* values for every message handled by the device.

If the *Device Load* exceeds the device's processing capability, performance of both the device and the network is degraded.

NOTE: Schneider Electric recommends that *Device Load* not exceed 90% of CPU processing capacity of each device.

Device Bandwidth—measured in bits—is the sum of the *Message Bandwidth* values for messages handled by the device

In your control application design, determine whether the I/O scanner device can handle the load contributed by every I/O adapter device. To do this, perform the following steps:

- 1 Calculate the implicit messaging load and bandwidth for each remote device.
- 2 Sum the load and bandwidth estimates for every remote device.
- 3 Compare the total implicit messaging load and bandwidth against the maximum implicit messaging capacity of the device acting as I/O scanner.

If the projected total load or bandwidth for a communication module acting as an I/O scanner exceeds its implicit messaging load or bandwidth limits, consider one or more of the following corrective actions:

- If the I/O adapter supports rack optimized connections, and if a single rack of digital I/O uses multiple direct connections, replace the direct connections with a single rack optimized connection, if possible.
- Increase the RPI setting for a device where possible.
- Add another communication module to act as an I/O scanner, and re-design the network in order to share the load.

Network Load and Network Bandwidth

Network Load—measured in number of packets—can be estimated as the sum of the *Device Load* of the adapter devices, or of the scanner devices.

Network Bandwidth—measured in bits—can be estimated as the sum of the *Device Bandwidth* of the adapter devices, or of the scanner devices.

NOTE: Schneider Electric recommends that *Network Load* not exceed 90% of maximum network bandwidth.

If necessary, you may need to optimize your control application design by:

- adjusting device RPI settings
- changing connection types (e.g., from direct to rack optimized)
- modify the configuration
- change the network topology

Network Load and Bandwidth Calculation Example

Network Devices

This example estimates the performance for an Ethernet network composed of the following devices:


- a PLC that controls 3 remote I/O stations (A, B, and C)
- 140 NOC 771 00 Ethernet communication module, acting as the local I/O scanner, installed in the PLC rack
- an 8-port Ethernet managed switch
- a PC running used to obtain diagnostic data via explicit messages running the following software:
 - Control Expert
 - the Control Expert Ethernet Configuration Tool
- 4 remote devices, acting as:
 - an I/O adapter (A) for a rack of I/O modules
 - a second I/O adapter (B) for a rack of I/O modules
 - a remote I/O drive (C)
 - a remote I/O scanner (D)

Control Expert software running in the PC is used to configure the CPU controller.

For programming purposes you need a connection to the PLC either through the CPU's Ethernet port or other supported programming paths.

Network Diagram

The proposed network diagram looks like this:



Network Load and Bandwidth Limits

When performing calculations, keep in mind that the Ethernet module and remote devices cannot exceed their implicit messaging and bandwidth limits:

Device	Load Limits	Bandwidth Limits
Ethernet Communication Module	12000 pps	80 Mbps
I/O Adapter (A)	8000 pps	70 Mbps
I/O Adapter (B)	8000 pps	70 Mbps
I/O Drive (C)	8000 pps	70 Mbps
I/O Scanner (D)	12000 pps	80 Mbps
Switch	16000 pps	90 Mbps

Remote Device Connections and RPI

For the purpose of this example, it is assumed that the remote devices require the following numbers of CIP connections, and are configured for the stated requested packet interval (RPI) settings:

Device	CIP I/O Connections	RPI Setting	I/O Packet Size
I/O Adapter (A)	5	20 ms	8000 bits
I/O Adapter (B)	2	30 ms	4096 bits
I/O Drive (C)	2	30 ms	8000 bits
I/O Scanner (D)	2	50 ms	8000 bits

For the purposes of this example, it is also assumed that every connection is bi-directional.

I/O Scanner Calculations

The Ethernet communication module, acting as local I/O scanner, has to handle the implicit messaging load contributed by the remote devices. Your task is to:

- 1 estimate the implicit messaging load and bandwidth contributed by each remote device
- 2 sum the load and bandwidth values for each remote device
- 3 compare the total load and bandwidth against the maximum implicit messaging capacity of the local I/O scanner

Recall that the implicit messaging load calculation formula for a single remote device is:

$$\text{Load} = (\text{number of packets per connection}) \times (\text{number of connections}) / \text{RPI}$$

Because every connection is assumed to be bi-directional, the *number of packets per connection* value is 2. Consequently, the estimated implicit messaging load contributed by each device, and the total implicit messaging load the local I/O scanner has to handle can be estimated as follows:

Load:

Device	Number of packets per connection	X	Number of connections	+	RPI	=	Load
I/O Adapter (A)	2	X	5	÷	20 ms	=	500 pps
I/O Adapter (B)	2	X	2	÷	30 ms	=	134 pps
I/O Drive (C)	2	X	2	÷	30 ms	=	134 pps
I/O Scanner (D)	2	X	2	÷	50 ms	=	80 pps
Total						=	848 pps
Switch						=	848 pps

Bandwidth:

Device	Packet size	X	Load	=	Bandwidth
I/O Adapter (A)	8000 bits	X	500 pps	=	4 Mbps
I/O Adapter (B)	4096 bits	X	134 pps	=	0.554 Mbps
I/O Drive (C)	8000 bits	X	134 pps	=	1.07 Mbps
I/O Scanner (D)	8000 bits	X	80 pps	=	0.64 Mbps
Total				=	6.26 Mbps
Switch				=	6.26 Mbps

Conclusion

The projected total load for the module—848 pps—is within the device implicit messaging limit of 12000 data packets per second. The projected total bandwidth for the communication module—6.26 Mbps—is also within the device implicit messaging bandwidth limit of 80 Mbps. The projected total load and bandwidth for the remote devices (including the switch) are also within their 90% load and bandwidth limits:

Device	90% of Load Limit	90% of Bandwidth Limit
Ethernet Communication Module	10800 pps	72 Mbps
I/O Adapter (A)	7200 pps	63 Mbps
I/O Adapter (B)	7200 pps	63 Mbps
I/O Drive (C)	7200 pps	63 Mbps
I/O Scanner (D)	10800 pps	72 Mbps

NOTE: Although message load contributed by explicit messaging are not included in the above calculations, such load contributions are presumed to be less than 10% of the device load and bandwidth.

Chapter 5

Explicit Messaging in Control Expert

Overview

This chapter describes how to execute explicit messages in Control Expert using either:

- the MBP_MSTR function block
- the **Online Action** window of the Control Expert EtherNet/IP configuration tool

Control Expert supports both connected and unconnected explicit messaging.

NOTE: There can be only one concurrent explicit message, connected or unconnected, from an EtherNet/IP communication module to the same remote EtherNet/IP device.

What Is in This Chapter?

This chapter contains the following topics:

Topic	Page
Explicit Messaging Services	154
Configuring Explicit Messaging Using MBP_MSTR	156
MBP_MSTR Example - Get_Attributes_Single	159
MBP_MSTR Example - Reset	164
Explicit Messaging Error Codes	169
Explicit Messaging - Online Action: Get_Attributes_Single	172
Explicit Messaging - Online Action: Reset	174

Explicit Messaging Services

Overview

Every explicit message performs a service. Each service is associated with a service code (or number). You will need to identify the explicit messaging service by its name, decimal number, or hexadecimal number.

You can execute explicit messages using either a Control Expert function block or the Control Expert EtherNet/IP configuration tool.

All services are available using the MBP_MSTR Control Expert function block.

NOTE: All configuration edits made to an EtherNet/IP module via explicit messaging, including explicit messages executed by an MBP_MSTR block or by the Control Expert EtherNet/IP configuration tool's Online Action window, are not included in the operating parameters the CPU sends the module on startup.

Services

You can use Control Expert to construct a request that executes any service supported by the target device that is compliant with the EtherNet/IP protocol.

The services supported by Control Expert include the following standard explicit messaging services:

Service Code		Description	Available in...	
Hex	Dec		Function Block	EIP config tool
1	1	Get_Attributes_All	X	X
2	2	Set_Attributes_All	X	X
3	3	Get_Attribute_List	X	—
4	4	Set_Attribute_List	X	—
5	5	Reset	X	X
6	6	Start	X	X
7	7	Stop	X	X
8	8	Create	X	X
9	9	Delete	X	X
A	10	Multiple_Service_Packet	X	—
D	13	Apply_Attributes	X	X
E	14	Get_Attribute_Single	X	X
10	16	Set_Attribute_Single	X	X
11	17	Find_Next_Object_Instance	X	X
14	20	Error Response (DeviceNet only)	—	—

"X" indicates the service is available. "—" indicates the service is not available.

Service Code		Description	Available in...	
Hex	Dec		Function Block	EIP config tool
15	21	Restore	X	X
16	22	Save	X	X
17	23	No Operation (NOP)	X	X
18	24	Get_Member	X	X
19	25	Set_Member	X	X
1A	26	Insert_Member	X	X
1B	27	Remove_Member	X	X
1C	28	GroupSync	X	—

"X" indicates the service is available. "—" indicates the service is not available.

Configuring Explicit Messaging Using MBP_MSTR

Overview

Use the MBP_MSTR function block to configure EtherNet/IP connected and unconnected explicit messages. The MBP_MSTR block can send requests and receive responses up to 511 bytes long.

The operation begins when the input to the ENABLE pin is turned ON. The operation ends if the ABORT pin is turned ON, or if the ENABLE pin is turned OFF.


The CONTROL and DATABUF output parameters define the operation. Refer to Configuring the Control Block (*see page 157*) and Configuring the Data Buffer (*see page 158*), below, for details.

NOTE: The DATABUF parameter varies in size, depending upon its content. To avoid overwriting the request, the data buffer must be large enough to simultaneously contain both the request and response data.

The ACTIVE output turns ON during operation; the ERROR output turns ON if the operation aborts without success; the SUCCESS output turns ON upon the successful completion of the operation.

EN and ENO can be configured as additional parameters.

Representation in FBD



Input Parameters

Parameter	Data type	Description
ENABLE	BOOL	When ON, the explicit message operation (specified in the first element of the CONTROL pin) is executing.
ABORT	BOOL	When ON, the operation is aborted.

Output Parameters

Parameter	Data type	Description
ACTIVE	BOOL	ON when the operation is active. OFF at all other times.
ERROR	BOOL	ON when the operation is aborted without success. OFF before operation, during operation, and if operation succeeds.
SUCCESS	BOOL	ON when the operation concludes successfully. OFF before operation, during operation, and if operation fails.
CONTROL	WORD	This parameter contains the control block. See Configuring the Control Block, below, for a description of this parameter. Note: This parameter must be assigned to a located variable.
DATABUF	WORD	This parameter contains the data buffer. See Configuring the Data Buffer, below, for a description of this parameter. Note: This parameter must be assigned to a located variable.

Configuring the Control Block

The Control Block parameter consists of 9 contiguous words, as described below:

Register	Function	Description
CONTROL [1]	Operation	Low byte = 14 (CIP Explicit Message) High byte = <ul style="list-style-type: none"> ● 0: unconnected (16#000E) ● 1: connected (16#010E)
CONTROL [2]	Error status	Holds the error code (read-only).
CONTROL [3]	Data buffer length	Data buffer length, in words
CONTROL [4]	Response offset	Offset for the beginning of the response in the data buffer, in 16-bit words Note: To avoid overwriting the request, the response offset value must be greater than the request length CONTROL [6].
CONTROL [5]	Slot	Low byte = 0 (not used) High byte = slot location on backplane
CONTROL [6]	Device ID	The number assigned to the device in the Devices window of the Control Expert EtherNet/IP configuration tool
CONTROL [7]	Request length	Length of the CIP request, in bytes
CONTROL [8]	Response length	Length of the response received, in bytes Read only, set after completion
CONTROL [9]	(Reserved)	—

Configuring the Data Buffer

The data buffer varies in size. It consists of contiguous registers that include, in sequence, both the CIP request and the CIP response.

Data Buffer: Variable size: set in CONTROL[2]	CIP Request: Request size: set in CONTROL[6]
	CIP Response: Starting position: set in CONTROL[3] Response size: reported in CONTROL[7] Note: If the response offset is smaller than the request size, response data will overwrite part of the request.

The format of the data buffer's CIP request and CIP response is described, below.

NOTE: Both the request and response must be structured in little endian order.

Request:

Byte offset	Field	Data type	Description
0	Service	Byte	Service of the explicit message
1	Request_Path_Size	Byte	The number of words in the Request_Path field
2	Request_Path	Padded EPATH	This byte array describes the path of the request, including class ID, instance ID, etc., for this transaction
...	Request_Data	Byte array	Service specific data to be delivered in the explicit message request—if none, this field is empty

Response:

Byte offset	Field	Data type	Description
0	Reply Service	Byte	Service of the explicit message + 16#80
1	Reserved	Byte	0
2	General Status	Byte	EtherNet/IP General Status
3	Size of Additional Status	Byte	Additional Status array size in words
4	Additional Status	Word array	Additional status
...	Response Data	Byte array	Response data from request, or additional error data if General Status indicates an error

MBP_MSTR Example - Get_Attributes_Single


Overview

The following unconnected explicit messaging example shows you how to use the MBP_MSTR function block to retrieve diagnostic information for an Advantys STB island from an STB NIC 2212 EtherNet/IP network interface module, using the Get_Attributes_Single service.

You can perform the same explicit messaging service using the *Online Action* window of the Control Expert EtherNet/IP configuration tool (*see page 172*).

Implementing the MBP_MSTR Function Block

To implement the MBP_MSTR function block, you need to create and assign variables, and connect it to an AND block, as follows:



Input Variables

Variables need to be created and assigned to input pins. For the purpose of this example, variables have been created—and named—as described below. (You can, of course, use different variable names in your explicit messaging configurations.)

Input pin	Variable	Data type
ENABLE	send_request	BOOL
ABORT	abort_request	BOOL

Output Variables

Variables also need to be created and assigned to output pins. (The names assigned to output variables apply only to this example, and can be changed in your explicit messaging configurations.)

Output pin	Variable	Data type
ACTIVE	EM_active	BOOL
ERROR	EM_error	BOOL
SUCCESS	EM_success	BOOL
CONTROL	EM_control	Array of 9 WORDS
DATABUF	EM_data	Array of 100 WORDS

NOTE: To simplify configuration, you can assign the `CONTROL` and `DATABUF` output pins to a byte array consisting of located variables. When configured in this manner, you will not need to be aware of the location of data within a word (for example, high versus low byte, and big or little endian format).

Control Array

The control array parameter (`EM_control`) consists of 9 contiguous words. You need to configure only some control words; other control words are read-only and are written to by the operation. In this example, the control array defines the operation as an unconnected explicit message, and identifies the target device:

Register	Description	Configure	Setting (hex)
CONTROL [0]	Operation: Low byte = 0E (CIP explicit message) High byte = <ul style="list-style-type: none"> ● 00 (unconnected), or ● 01 (connected) 	Yes	16#000E (unconnected)
CONTROL [1]	Error status: read-only (written by operation)	No	—
CONTROL [2]	Data buffer length = 100 words	Yes	16#0064
CONTROL [3]	Response offset: offset—in words—for the beginning of the explicit message response in the databuffer	Yes	16#0004
CONTROL [4]	Slot of the 140 NOC 771 00 module: Low byte = 0 (not used) High byte = slot location	Yes	16#0400
CONTROL [5]	Device number: from the Devices window of the Control Expert EtherNet/IP configuration tool	Yes	16#0001
CONTROL [6]	CIP request length (in bytes)	Yes	16#0008

Register	Description	Configure	Setting (hex)
CONTROL [7]	Length of received response (written by operation)	No	—
CONTROL [8]	(Reserved)	No	—

CIP Request

The CIP request is located at the beginning of the databuffer and is followed by the CIP response. In this example, the CIP request calls for the return of a single attribute value (diagnostic data), and describes the request path through the target device's object structure leading to the target attribute:

Request word	High byte		Low byte	
	Description	Value (hex)	Description	Value (hex)
1	Request path size (in words)	16#03	EM Service: Get_Attributes_Single	16#0E
2	Request path: class assembly object	16#04	Request path: logical class segment	16#20
3	Request path: instance	16#64	Request path: logical instance segment	16#24
4	Request path: attribute	16#03	Request path: logical attribute segment	16#30

Combining the high and low bytes, above, the CIP request would look like this:


Request word	Value
1	16#030E
2	16#0420
3	16#6424
4	16#0330


Viewing the Response

Use a Control Expert Animation table to display the EM_data variable array. Note that the EM_data variable array consists of the entire data buffer, which includes the:

- CIP request (4 words) located in EM_data(1-4)
- CIP service type (1 word) located in EM_data(5)
- CIP request status (1 word) located in EM_data(6)
- CIP response (in this case, 10 words) located in EM_data(7-16)

To display the CIP response, follow these steps:

Step	Action	
1	In Control Expert, select Tools → Project Browser to open the Project Browser.	
2	In the Project Browser, select the Animation Tables folder, then click the right mouse button. A pop-up menu appears.	
3	Select New Animation Table in the pop-up menu. A new animation table and its properties dialog both open.	
4	In the Properties dialog, edit the following values:	
	Name	Type in a table name. For this example: EM_data .
	Functional module	Accept the default <None> .
	Comment	Leave blank.
	Number of animated characters	Type in 100 , representing the size of the data buffer in words.
5	<p>The completed Properties dialog looks like this:</p>  <p>Click OK to close the dialog.</p>	

Step	Action
6	In the animation table's Name column, type in the name of the variable assigned to the databuffer: EM_data and hit Enter . The animation table displays the EM_data variable.
7	<p>Expand the EM_data variable to display its word array, where you can view the CIP response at words EM_data(7-16):</p>  <p>Note: Each word presents 2 bytes of data in little endian format, where the least significant byte is stored in the smallest memory address. For example, '0E' in word[1] is the lower byte, and '03' is the upper byte.</p>

MBP_MSTR Example - Reset


Overview

The following unconnected explicit messaging example shows you how to use the MBP_MSTR function block to perform a warm reboot of an STB NIC 2212 EtherNet/IP network interface module, using the Reset service.

You can perform the same explicit messaging service using the *Online Action* window of the Control Expert EtherNet/IP configuration tool (*see page 172*).

Implementing the MBP_MSTR Function Block

To implement the MBP_MSTR function block, you need to create and assign variables, and connect it to an AND block, as follows:



Input Variables

Variables must be created and assigned to input pins as follows:

Input pin	Variable	Data type
ENABLE	send_request	BOOL
ABORT	abort_request	BOOL

Output Variables

Variables must be created and assigned to output pins as follows:

Output pin	Variable	Data type
ACTIVE	EM_active	BOOL
ERROR	EM_error	BOOL
SUCCESS	EM_success	BOOL
CONTROL	EM_control	Array of 9 WORDS
DATABUF	EM_data	Array of 5 WORDS

NOTE: To simplify configuration, you can assign the `CONTROL` and `DATABUF` output pins to a byte array consisting of located variables. When configured in this manner, you will not need to be aware of the location of data within a word (for example, high versus low byte, and big or little endian format).

Control Array

The control array parameter (`EM_control`) consists of 9 contiguous words. You need to configure only some control words; other control words are read-only and are written to by the operation. In this example, the control array defines the operation as an unconnected explicit message, and identifies the target device:

Register	Description	Configure	Setting (hex)
CONTROL [0]	Operation: Low byte = 0E (CIP explicit message) High byte = 00 (unconnected)	Yes	16#000E
CONTROL [1]	Error status: read-only (written by operation)	No	—
CONTROL [2]	Data buffer length = 5 words	Yes	16#0005
CONTROL [3]	Response offset: offset—in words—for the beginning of the explicit message response in the databuffer	Yes	16#0005
CONTROL [4]	Slot of the 140 NOC 771 00 module: Low byte = 0 (not used) High byte = slot location	Yes	16#0400
CONTROL [5]	Device number: from the Devices window of the Control Expert EtherNet/IP configuration tool	Yes	16#0001
CONTROL [6]	CIP request length (in bytes)	Yes	16#0008
CONTROL [7]	Length of received response (written by operation)	No	—
CONTROL [8]	<i>(Reserved)</i>	No	—

CIP Request

The CIP request is located at the beginning of the databuffer. In this example, the request calls for a device reset procedure, and describes the request path through the target device's object structure leading to a target object that performs the requested procedure:

Request word	High byte		Low byte	
	Description	Value (hex)	Description	Value (hex)
1	Request path size (in words)	16#03	EM Service: Reset	16#05
2	Request path: class assembly object	16#01	Request path: logical class segment	16#20
3	Request path: instance	16#01	Request path: logical instance segment	16#24
4	Request path: attribute	16#00	Request path: logical attribute segment	16#30

Combining the high and low bytes, above, the CIP request would look like this:

Request word	Value
1	16#0305
2	16#0120
3	16#0124
4	16#0030


Viewing the Response

Use a Control Expert Animation table to display the EM_data variable array. Because the Reset explicit messaging command returns no data, the EM_data variable includes no CIP response component. The EM_data variable array includes only the:

- CIP request (4 words) located in EM_data(1-4)
- CIP service type (1 word) located in EM_data(5)
- CIP request status (1 word) located in EM_data(6)

To display the contents of the EM_data variable array, follow these steps:

Step	Action								
1	In Control Expert, select Tools → Project Browser to open the Project Browser.								
2	In the Project Browser, select the Animation Tables folder, then click the right mouse button. A pop-up menu appears.								
3	Select New Animation Table in the pop-up menu. A new animation table and its properties dialog both open.								
4	In the Properties dialog, edit the following values: <table border="1" data-bbox="349 678 1259 852"> <tr> <td><i>Name</i></td> <td>Type in a table name. For this example: EM_data.</td> </tr> <tr> <td><i>Functional module</i></td> <td>Accept the default <None>.</td> </tr> <tr> <td><i>Comment</i></td> <td>Leave blank.</td> </tr> <tr> <td><i>Number of animated characters</i></td> <td>Type in 100, representing the size of the data buffer in words.</td> </tr> </table>	<i>Name</i>	Type in a table name. For this example: EM_data .	<i>Functional module</i>	Accept the default <None> .	<i>Comment</i>	Leave blank.	<i>Number of animated characters</i>	Type in 100 , representing the size of the data buffer in words.
<i>Name</i>	Type in a table name. For this example: EM_data .								
<i>Functional module</i>	Accept the default <None> .								
<i>Comment</i>	Leave blank.								
<i>Number of animated characters</i>	Type in 100 , representing the size of the data buffer in words.								
5	The completed Properties dialog looks like this: <div data-bbox="358 894 875 1247" data-label="Image"> </div> <p>Click OK to close the dialog.</p>								

Step	Action																																
6	In the animation table's <i>Name</i> column, type in the name of the variable assigned to the databuffer: EM_data and hit Enter . The animation table displays the EM_data variable.																																
7	<p>Expand the EM_data variable to display its word array, where you can view the CIP response at words EM_data(7-16):</p>  <table border="1" data-bbox="330 329 1081 605"> <thead> <tr> <th>Name</th> <th>Value</th> <th>Type</th> <th>Comment</th> </tr> </thead> <tbody> <tr> <td>EM_data</td> <td></td> <td>ARRAY(1...100)...</td> <td></td> </tr> <tr> <td>EM_data[1]</td> <td>16#0305</td> <td>WORD</td> <td></td> </tr> <tr> <td>EM_data[2]</td> <td>16#0120</td> <td>WORD</td> <td></td> </tr> <tr> <td>EM_data[3]</td> <td>16#0124</td> <td>WORD</td> <td></td> </tr> <tr> <td>EM_data[4]</td> <td>16#0030</td> <td>WORD</td> <td></td> </tr> <tr> <td>EM_data[5]</td> <td>16#0085</td> <td>WORD</td> <td></td> </tr> <tr> <td>EM_data[6]</td> <td>16#0000</td> <td>WORD</td> <td></td> </tr> </tbody> </table> <p>Note: Each word presents 2 bytes of data in little endian format, where the least significant byte is stored in the smallest memory address. For example, '05' in word[1] is the lower byte, and '03' is the upper byte.</p>	Name	Value	Type	Comment	EM_data		ARRAY(1...100)...		EM_data[1]	16#0305	WORD		EM_data[2]	16#0120	WORD		EM_data[3]	16#0124	WORD		EM_data[4]	16#0030	WORD		EM_data[5]	16#0085	WORD		EM_data[6]	16#0000	WORD	
Name	Value	Type	Comment																														
EM_data		ARRAY(1...100)...																															
EM_data[1]	16#0305	WORD																															
EM_data[2]	16#0120	WORD																															
EM_data[3]	16#0124	WORD																															
EM_data[4]	16#0030	WORD																															
EM_data[5]	16#0085	WORD																															
EM_data[6]	16#0000	WORD																															

Explicit Messaging Error Codes

If a MBP_MSTR function block fails to execute an explicit message, Control Expert displays a hexadecimal error code. The error code can describe either:

- an EtherNet/IP error triggered by the failure of the MBP_MSTR block used to execute an explicit message
- legacy TCP/IP and Ethernet errors

For a list of legacy TCP/IP and Ethernet error codes, refer to the list of error codes in Appendix A (*see page 215*).

EtherNet/IP Error Codes

If an MBP_MSTR function block fails to execute an explicit message, the Control Expert may display one of the following hexadecimal error codes:

Error Code	Description
16#200F	The space allocated for the CIP response is too small
16#800D	Timeout on the explicit message request
16#8012	Bad device: the device is not configured or the equipment number is too high (>63)
16#8015	Either: <ul style="list-style-type: none"> • Nor resources to handle the message, or • Internal error: no buffer available, no link available, impossible to send to the TCP task
16#8018	Either: <ul style="list-style-type: none"> • Another explicit message for this device is in progress, or • TCP connection or encapsulation session in progress
16#8030	Timeout on the Forward_Open request
Note: The following 16#81xx errors are Forward_Open response errors that originate at the remote target and are received via the CIP connection.	
16#8100	Connection in use or duplicate Forward_Open
16#8103	Transport class and trigger combination not supported
16#8106	Ownership conflict
16#8107	Target connection not found
16#8108	Invalid network connection parameter
16#8109	Invalid connection size
16#8110	Target for connection not configured
16#8111	RPI not supported
16#8113	Out of connections
16#8114	Vendor ID or product code mismatch

Error Code	Description
16#8115	Product type mismatch
16#8116	Revision mismatch
16#8117	Invalid produced or consumed application path
16#8118	Invalid or inconsistent configuration application path
16#8119	Non-Listen Only connection not opened
16#811A	Target object out of connections
16#811B	RPI is smaller than the production inhibit time
16#8123	Connection timed out
16#8124	Unconnected request timed out
16#8125	Parameter error in unconnected request and service
16#8126	Message too large for unconnected_send service
16#8127	Unconnected acknowledge without reply
16#8131	No buffer memory available
16#8132	Network bandwidth not available for data
16#8133	No consumed connection ID filter available
16#8134	Not configured to send scheduled priority data
16#8135	Schedule signature mismatch
16#8136	Schedule signature validation not possible
16#8141	Port not available
16#8142	Link address not valid
16#8145	Invalid segment in connection path
16#8146	Error in Forward_Close service connection path
16#8147	Scheduling not specified
16#8148	Link address to self invalid
16#8149	Secondary resources unavailable
16#814A	Rack connection already established
16#814B	Module connection already established
16#814C	Miscellaneous
16#814D	Redundant connection mismatch
16#814E	No more user-configurable link consumer resources: the configured number of resources for a producing application has reached the limit
16#814F	No more user-configurable link consumer resources: there are no consumers configured for a producing application to use
16#8160	Vendor specific
16#8170	No target application data available

Error Code	Description
16#8171	No originator application data available
16#8173	Not configured for off-subnet multicast
16#81A0	Error in data assignment
16#81B0	Optional object state error
16#81C0	Optional device state error
Note: All 16#82xx errors are register session response errors.	
16#8200	Target device does not have sufficient resources
16#8208	Target device does not recognize message encapsulation header
16#820F	Reserved or unknown error from target

Explicit Messaging - Online Action: Get_Attributes_Single

Overview

The following example shows you how to use the **Online Action** window in the Control Expert EtherNet/IP configuration tool to execute an unconnected explicit message that retrieves Advantys STB island diagnostic information from an STB NIC 2212 EtherNet/IP network interface module, using the `Get_Attributes_Single` service.

You can perform the same explicit messaging service using the `MBP_MSTR` function block (*see page 159*).

Configuring the Explicit Message

To configure, then execute, an unconnected explicit message that will retrieve diagnostic data from the STB NIC 2212 EtherNet/IP module, follow these steps:

Step	Action														
1	Launch the EtherNet/IP configuration tool from the Configuration page of the EtherNet/IP communication module's Properties window.														
2	In the EtherNet/IP configuration tool, begin on-line operations by clicking the Go Online button  .														
3	Click on the Network Detection tab to enable online actions 														
4	Open the Online Action window by selecting Network → Online Action .														
5	In the Explicit Messaging page, complete the following fields: <table border="1" data-bbox="312 1065 1225 1479"> <tbody> <tr> <td>IP Address</td> <td>Type in the IP address of the STB NIC 2212. In this example, the IP address is: 192.168.001.011.</td> </tr> <tr> <td>Class</td> <td>Type in the number that identifies the object class. In this example, the number representing the assembly class object is 4.</td> </tr> <tr> <td>Instance</td> <td>Type in the number that identifies the instance of the assembly class object. In this example, the number is 100.</td> </tr> <tr> <td>Attribute</td> <td>Place a check mark in the checkbox to enable this field, then type in the number identifying the attribute containing diagnostic data. In this example, the number is 3.</td> </tr> <tr> <td>Name</td> <td>Select the name of the explicit messaging service. In this example, select Get_Attributes_Single.</td> </tr> <tr> <td>Messaging</td> <td>Select the type of explicit message. In this example, select Unconnected.</td> </tr> <tr> <td colspan="2">(The explicit messaging configuration is displayed, below.)</td> </tr> </tbody> </table>	IP Address	Type in the IP address of the STB NIC 2212. In this example, the IP address is: 192.168.001.011 .	Class	Type in the number that identifies the object class. In this example, the number representing the assembly class object is 4 .	Instance	Type in the number that identifies the instance of the assembly class object. In this example, the number is 100 .	Attribute	Place a check mark in the checkbox to enable this field, then type in the number identifying the attribute containing diagnostic data. In this example, the number is 3 .	Name	Select the name of the explicit messaging service. In this example, select Get_Attributes_Single .	Messaging	Select the type of explicit message. In this example, select Unconnected .	(The explicit messaging configuration is displayed, below.)	
IP Address	Type in the IP address of the STB NIC 2212. In this example, the IP address is: 192.168.001.011 .														
Class	Type in the number that identifies the object class. In this example, the number representing the assembly class object is 4 .														
Instance	Type in the number that identifies the instance of the assembly class object. In this example, the number is 100 .														
Attribute	Place a check mark in the checkbox to enable this field, then type in the number identifying the attribute containing diagnostic data. In this example, the number is 3 .														
Name	Select the name of the explicit messaging service. In this example, select Get_Attributes_Single .														
Messaging	Select the type of explicit message. In this example, select Unconnected .														
(The explicit messaging configuration is displayed, below.)															

Explicit Messaging - Online Action: Reset

Overview


The following example shows you how to use the **Online Action** window in the Control Expert EtherNet/IP configuration tool to execute an unconnected explicit message that performs a warm reset of the STB NIC 2212 EtherNet/IP network interface module, using the Reset service.

You can perform the same explicit messaging service using the MBP_MSTR function block (*see page 164*).

Configuring the Explicit Message

To configure, then execute, an unconnected explicit message that will retrieve diagnostic data from the STB NIC 2212 EtherNet/IP module, follow these steps:

Step	Action												
1	Launch the EtherNet/IP configuration tool from the Configuration page of the EtherNet/IP communication module's Properties window.												
2	In the EtherNet/IP configuration tool, begin on-line operations by clicking the Go Online button  .												
3	Click on the Network Detection tab to enable online actions 												
4	Open the Online Action window by selecting Network → Online Action .												
5	In the Explicit Messaging page, complete the following fields: <table border="1" data-bbox="312 1036 1227 1388"> <tr> <td>IP Address</td> <td>Type in the IP address of the STB NIC 2212. In this example, the IP address is: 192.168.001.011.</td> </tr> <tr> <td>Class</td> <td>Type in the number that identifies the object class. In this example, the number representing the assembly class object is 1.</td> </tr> <tr> <td>Instance</td> <td>Type in the number that identifies the instance of the assembly class object. In this example, the number is 1.</td> </tr> <tr> <td>Attribute</td> <td>Place a check mark in the checkbox to enable this field, then type in the number identifying the attribute associated with the reset function. In this example, the number is 0.</td> </tr> <tr> <td>Name</td> <td>Select the name of the explicit messaging service. In this example, select Reset.</td> </tr> <tr> <td>Messaging</td> <td>Select the type of explicit message. In this example, select Unconnected.</td> </tr> </table> <p>(The explicit messaging configuration is displayed, below.)</p>	IP Address	Type in the IP address of the STB NIC 2212. In this example, the IP address is: 192.168.001.011 .	Class	Type in the number that identifies the object class. In this example, the number representing the assembly class object is 1 .	Instance	Type in the number that identifies the instance of the assembly class object. In this example, the number is 1 .	Attribute	Place a check mark in the checkbox to enable this field, then type in the number identifying the attribute associated with the reset function. In this example, the number is 0 .	Name	Select the name of the explicit messaging service. In this example, select Reset .	Messaging	Select the type of explicit message. In this example, select Unconnected .
IP Address	Type in the IP address of the STB NIC 2212. In this example, the IP address is: 192.168.001.011 .												
Class	Type in the number that identifies the object class. In this example, the number representing the assembly class object is 1 .												
Instance	Type in the number that identifies the instance of the assembly class object. In this example, the number is 1 .												
Attribute	Place a check mark in the checkbox to enable this field, then type in the number identifying the attribute associated with the reset function. In this example, the number is 0 .												
Name	Select the name of the explicit messaging service. In this example, select Reset .												
Messaging	Select the type of explicit message. In this example, select Unconnected .												
6	To execute the unconnected explicit message, click Send to Device .												


Step	Action
7	<p>The Status area displays the success or failure of the explicit messaging procedure:</p>  <p>Note: Because the service returns no data, the Receive area displays no message output.</p>
8	Click OK to close the window.

Chapter 6

CIP Objects

Overview

The EtherNet/IP communication module stores data and offers services in a CIP object hierarchy, consisting of the following nested levels:



When the module's local slave service is activated, remote devices can send explicit messages to the module's object hierarchy and perform services that:

- access module data, or
- execute module commands

The local slave function is activated by selecting **Active Configuration** in the **General Configuration** page of the **Local Slave** window (*see page 64*).

This chapter describes the CIP objects the EtherNet/IP communication module can expose to remote devices.

What Is in This Chapter?

This chapter contains the following topics:

Topic	Page
Adapter Diagnostic Object	178
Assembly Object	183
Connection Manager Object	185
Ethernet Link Object	187
Identity Object	191
Module Diagnostic Object	193
Scanner Diagnostic Object	195
TCP/IP Interface Object	200

Adapter Diagnostic Object

Overview

The Adapter Diagnostic CIP object consists of the attributes and services described below.

Attributes

The Adapter Diagnostic CIP object consists of the following attributes:

1. Class attributes:

ID (hex)	Description	GET	SET
01	Revision	X	—
02	Max Instance	X	—
X = supported — = not supported			

2. Instance attributes:

ID (hex)	Description	Type	GET	SET	Value
01	Control Bits	WORD	X	X	0: Deactivate checking time for production and consumption (default) 1: Activate
02	ST_DIAG_CNT	STRUCT	X	X	
	wErrFrameCnt	UINT			Incremented each time a frame isn't sent by missing resources or is impossible to send.
	wErrTimeOutCnt	UINT			Incremented when a connection is timed out.
	wErrRefusedCnt	UINT			Incremented when a connection is refused by the remote station.
	dwErrProdCnt	UDINT			Incremented at each production.
	dwErrConsCnt	UDINT			Incremented at each consumption.
	dwErrProdByteCnt	UDINT			Total bytes produced.
	dwErrConsByteCnt	UDINT			Total bytes consumed.
03	Input Status	WORD	X	—	See Status descriptions, below.
04	Output Status	WORD	X	—	See Status descriptions, below.
X = supported — = not supported					

ID (hex)	Description	Type	GET	SET	Value
05	ST_LINK	STRUCT	X	—	
	CIP Status	UINT			See Status descriptions, below.
	Extended Status	UINT			See Status descriptions, below.
	Production Connection ID	DWORD			Connection ID
	Consumed Connection ID	DWORD			Connection ID
	OtoT API	UDINT			API of the Connection
	TtoO API	UDINT			API of the Connection
	OtoT RPI	UDINT			RPI of the Connection
	TtoO RPI	UDINT			RPI of the Connection
06	ST SOCK_PARAM	STRUCT	X	—	
	IpSockId	DWORD			Internal identifier
	IpForeign	DWORD			IP of the remote station
	wPortForeign	UINT			Port number of the remote station
	IpLocal	DWORD			IP of the local station
	wPortLocal	UINT			Port number of the local station
07	ST_PRODUCTION	STRUCT	X	—	
	bValid	WORD			0: data of the struct production is not valid 1: data of the struct production is valid
	dwCurrentTime	UDINT			(Internal Use—number of ticks before next production)
	dwProductionTime	UDINT			(Internal Use—number of ticks between production)
	SequenceNumber	UDINT			Number of the dwquence in the production
	stCheckTime	STRUCT			
	dwLastTime	UDINT			(Internal Use)
	dwMaxTime	UDINT			Maximum time between 2 productions
	dwMinTime	UDINT			Minimum time between 2 productions
	dwRPI	UDINT			API of the connection
	wOverRun	UINT			Number of times the production was too long
	wUnderRun	UINT			Number of times the production was too short
	dwCurrentTime	UDINT			(Internal Use)
X = supported — = not supported					

ID (hex)	Description	Type	GET	SET	Value
08	ST_CONSUMPTION	STRUCT	X	—	
	bValid	WORD			0: data of the struct consumption is not valid 1: data of the struct consumption is valid
	dwCurrentTime	UDINT			(Internal Use—number of ticks before the timeout)
	dwConsumptionTime	UDINT			(Internal Use—number of ticks in the timeout)
	SequenceNumber	UDINT			Number of the sequence in the consumption
	stCheckTime	STRUCT			
	dwLastTime	UDINT			(Internal Use)
	dwMaxTime	UDINT			Maximum time between 2 consumptions
	dwMinTime	UDINT			Minimum time between 2 consumptions
	dwRPI	UDINT			API of the connection
	wOverRun	UINT			Number of times the consumption was too long
	wUnderRun	UINT			Number of times the consumption was too short
	dwCurrentTime	UDINT			(Internal Use)
09	Connection Entry List	STRUCT	X	—	Status of the CCO object. See Status descriptions, below.
	byGeneralStatus	BYTE			
	byReserved	BYTE			
	Extended Status	WORD			
X = supported — = not supported					

Adapter Status

Adapter status values include the following:

Status	Description	CIP Status	Extended	Explanation
0	OK	0	0	The I/O data are correctly exchanged.
33	No connection	0	0	No connection.
		0xFB	0xFB01	Connection in timeout.
		0xFB	0xFB07	Optimization error / unknown MAC Address.
		0xFB	0xFB0B	Timeout on consumption.
		0xFB	0xFB0C	Connection closed by a Fw_Close.
		0xFB	0xFB0E	Module in STOP.
		0xFD		Error from encapsulation layer.
		0xFE		Error on TCP connection.
		0x02	0	No more resources to handle the connection.
		0x20	0	Connections refused by bad format or parameters.
53	IDLE	0	0	An IDLE notification is received.
54	Connection in progress	0	0	The connection is established, but I/O data is not yet consumed.

Services

The CIP Adapter Diagnostic object performs the following services upon the listed object types:

ID (hex)	Description	Class	Instance	Notes		
01	Get_Attributes_All	X	X			
61	Get_Output	—	X	Returns the status and values of the output:		
				Offset	Type	Description
				0	UINT	Status
				2	USINT[0...409]	Output Data
62	Get_Input	—	X	Returns the status and values of the input:		
				Offset	Type	Description
				0	UINT	Status
				2	USINT[0...409]	Input Data
63	Set_DiagCounters	—	X	Sets the values of the structure: <ul style="list-style-type: none"> ● ST_DIAG_CNT to 0, and ● ST_CHECK_TIME (production and consumption) to 0 (but not fields dwLastTime and dwCurrentTime) the structure ST_DIAG_CNT to 0.		
X = supported — = not supported						

Assembly Object

Overview

The Assembly CIP object consists of the attributes and services described below.

Attributes

The Assembly CIP object consists of the following attributes:

1. Class attributes:

ID (hex)	Description	GET	SET
01	Revision	X	—
02	Max Instance	X	—
X = supported — = not supported			

2. Instance attributes:

ID (hex)	Description	Type	GET	SET
03	Data	Array of BYTE	X	X
X = supported — = not supported				

Services

The CIP Assembly object performs the following services upon the listed object types:

ID (hex)	Description	Class	Instance	Notes
01	Get_Attributes_All	X	X	—
0E	Get_Attributes_Single	X	X	—
10	Set_Attributes_Single	—	X	Returns these values: 0E=attribute not settable: assembly is not o->T type 0F=permission denied: assembly is being used by an active connection 13=config too small: the Set_Attributes_Single command contains partial data 15=too big data: the Set_Attributes_Single command contains too much data
X = supported — = not supported				

Connection Manager Object

Overview

The Connection Manager CIP object consists of the attributes and services described below.

Attributes

The Connection Manager CIP object consists of the following attributes:

1. Class attributes:

ID (hex)	Description	GET	SET
01	Revision	X	—
02	Max Instance	X	—
X = supported — = not supported			

2. Instance attributes:

ID (hex)	Description	Type	GET	SET	Value
01	Open Requests	UINT	X	X	Number of Forward Open service requests received
02	Open Format Rejects	UINT	X	X	Number of Forward Open service requests that were rejected due to bad format
03	Open Resource Rejects	UINT	X	X	Number of Forward Open service requests that were rejected due to lack of resources
04	Open Other Rejects	UINT	X	X	Number of Forward Open service requests that were rejected for reasons other than bad format or lack of resources
05	Close Requests	UINT	X	X	Number of Forward Close service requests received
06	Close Format Requests	UINT	X	X	Number of Forward Close service requests that were rejected due to bad format
07	Close Other Requests	UINT	X	X	Number of Forward Close service requests that were rejected for reasons other than bad format
X = supported — = not supported					

ID (hex)	Description	Type	GET	SET	Value
08	Connection Timeouts	UINT	X	X	Total number of connection timeouts that occurred in connections controlled by this connections manager
09	Connection Entry List	STRUCT	X	—	List of connections—always 0
11	CPU_Utilization	UINT	X	—	CPU Utilization in tenths of a percent—always 0
12	MaxBuffSize	UDINT	X	—	Amount of buffer space originally available—always 0
13	BufSize Remaining	UDINT	X	—	Amount of buffer space now available—always 0
X = supported — = not supported					

Services

The CIP Connection Manager object performs the following services upon the listed object types:

ID (hex)	Description	Class	Instance	Notes
01	Get_Attributes_All	X	X	—
0E	Get_Attributes_Single	X	X	—
4E	Forward Close	—	X	Managed internally by the EtherNet/IP stack—no link to CPU exists
52	Unconnected Send	—	X	
54	Forward Open	—	X	
X = supported — = not supported				

Ethernet Link Object

Overview

The Ethernet Link CIP object consists of the attributes and services described below.

Attributes

The Ethernet Link CIP object consists of the following attributes:

1. Class attributes:

ID (hex)	Description	GET	SET
01	Revision	X	—
02	Max Instance	X	—
X = supported — = not supported			

2. Instance attributes:

ID (hex)	Description	Type	GET	SET	Value
01	Interface Speed	UDINT	X	—	Valid values include: 0, 10000000, 100000000
02	Interface Flags	DWORD	X	—	Bit 0: Link Status 0 = Inactive 1 = Active Bit 1: Duplex Mode 0 = half duplex 1 = full duplex Bits 2-4: Negotiation Status 3 = successfully negotiated speed and duplex 4 = forced speed and link Bit 5: Manual Setting Requires Reset 0 = automatic 1 = device need reset Bit 6: Local Hardware Fault 0 = no fault 1 = fault detected
03	Physical Address	ARRAY of 6 USINT	X	—	Module MAC Address
X = supported — = not supported					

ID (hex)	Description	Type	GET	SET	Value
04	Interface Counters	STRUCT	X	—	
	In octets	UDINT			Octets received on the interface
	In Ucast Packets	UDINT			Unicast packets received on the interface
	In NUcast Packets	UDINT			Non-unicast packets received on the interface
	In Discards	UDINT			Inbound packets received on the interface, but discarded
	In Errors	UDINT			Inbound packets that contain errors (does not include In Discards)
	In Unknown Protos	UDINT			Inbound packets with unknown protocol
	Out Octets	UDINT			Octets sent on the interface
	Out Ucast Packets	UDINT			Unicast packets sent on the interface
	Out NUcast Packets	UDINT			Non-unicast packets sent on the interface
	Out Discards	UDINT			Outbound packets discarded
	Out Errors	UDINT			Outbound packets that contain errors
X = supported — = not supported					

ID (hex)	Description	Type	GET	SET	Value
05	Media Counters	STRUCT	X	—	
	Alignment Errors	UDINT			Frames that are not an integral number of octets in length
	FCS Errors	UDINT			Frames received that do not pass the FCS check
	Single Collisions	UDINT			Successfully transmitted frames that experienced exactly one collision
	Multiple Collisions	UDINT			Successfully transmitted frames that experienced more than one collision
	SQE Test Errors	UDINT			Number of times the SQE test error is generated
	Deferred Transmissions	UDINT			Frames for which first transmission attempt is delayed because the medium is busy
	Late Collisions	UDINT			Number of times a collision is detected later than 512 bittimes into the transmission of a packet
	Excessive Collisions	UDINT			Frames for which transmission fails due to excessive collisions
	MAC Transmit Errors	UDINT			Frames for which transmission fails due to internal MAC sublayer transmit error
	Carrier Sense Errors	UDINT			Times that the carrier sense condition was lost or never asserted when attempting to transmit a frame
	Frame Too Long	UDINT			Frames received that exceed the maximum permitted frame size
MAC Receive Errors	UDINT			Frames for which reception on an interface fails due to an internal MAC sublayer receive error	
X = supported — = not supported					

ID (hex)	Description	Type	GET	SET	Value
06	Interface Control	STRUCT	X	X	API of the connection
	Control Bits	WORD			Bit 0: Auto-negotiation 0 = Disabled 1 = Enabled Note: When auto-negotiation is enabled, the error 0x0C (Object State Conflict) is returned when attempting to set either: <ul style="list-style-type: none"> • Forced Interface Speed, or • Forced Duplex Mode
	Forced Interface Speed	UINT			Bit 1: Forced Duplex Mode (if auto-negotiation bit = 0) 0 = half duplex 1 = full duplex Valid values include: 10000000, 100000000 Note: Attempting to set any other value returns the error 0x09 (Invalid Attribute Value)
X = supported — = not supported					

Services

The CIP Ethernet Link object performs the following services upon the listed object types:

ID (hex)	Description	Class	Instance
01	Get_Attributes_All	X	X
05	Set_Attribute_Single	—	X
0E	Get_Attribute_Single	X	X
X = supported — = not supported			

Identity Object

Overview

The Identity CIP object consists of the attributes and services described below.

Attributes

The Identity CIP object consists of the following attributes:

1. Class attributes:

ID (hex)	Description	GET	SET
01	Revision	X	—
02	Max Instance	X	—
X = supported — = not supported			

2. Instance attributes:

ID (hex)	Description	Type	GET	SET
01	Vendor ID	UINT	X	—
02	Device Type	UINT	X	—
03	Product Code	UINT	X	—
04	Revision	STRUCT	X	—
	Major	USINT		
	Minor	USINT		
05	Status bit 2: 0x01=the module is configured bits 4-7: 0x03=no I/O connections established 0x06=at least 1 I/O connection in run mode 0x07=at least 1 I/O connection established, all in IDLE mode	Word	X	—
06	Serial Number	UDINT	X	—
07	Product Name	STRING	X	—
X = supported — = not supported				

Services

The CIP Identity object performs the following services upon the listed object types:

ID (hex)	Description	Class	Instance	Notes
01	Get_Attributes_All	X	X	Applies to all class and all instance attributes
0E	Get_Attributes_Single	X	X	Applies to all class and all instance attributes
05	Reset	—	X	Two types: 00=power cycle 01=return to factory defaults and power cycle
X = supported — = not supported				

Module Diagnostic Object

Overview

The Module Diagnostic CIP object consists of the attributes and services described below.

Attributes

The Module Diagnostic CIP object consists of the following attributes:

1. Class attributes:

ID (hex)	Description	GET	SET
01	Revision	X	—
02	Max Instance	X	—
X = supported — = not supported			

2. Instance attributes:

ID (hex)	Description	Type	GET	SET	Value
01	Module Status	WORD	X	—	01=started 02=stopped 03=running
02	CNF Version	WORD	X	—	0x0100
03	CRC	UDINT	X	—	—
04	I/O Connection Status	STRUCT	X	—	—
	Size Table	WORD			size (16 bytes)
	Table	WORD[]			table of I/O status (8 WORDS) 1=INPUT and OUTPUT status of I/O connection are OK 0=at least 1 INPUT or OUTPUT status of I/O connection is not OK
05	Cco Mode	WORD	X	X	01=activate status to CCO in the module 02=block access to CCO
X = supported — = not supported					

Services

The CIP Module Diagnostic object performs the following services upon the listed object types:

ID (hex)	Description	Class	Instance	Notes
01	Get_Attributes_All	X	X	—
0E	Set_Attributes_Single	—	X	—
X = supported — = not supported				

Scanner Diagnostic Object

Overview

The Scanner Diagnostic CIP object consists of the attributes and services described below.

Attributes

The Scanner Diagnostic CIP object consists of the following attributes:

1. Class attributes:

ID (hex)	Description	GET	SET
01	Revision	X	—
02	Max Instance	X	—
X = supported — = not supported			

2. Instance attributes:

ID (hex)	Description	Type	GET	SET	Value
01	Control Bits	WORD	X	X	0: Deactivate checking time for production and consumption (default) 1: Activate
02	ST_DIAG_CNT	STRUCT	X	X	
	wErrFrameCnt	UINT			Incremented each time a frame isn't sent by missing resources or is impossible to send.
	wErrTimeOutCnt	UINT			Incremented when a connection is timed out.
	wErrRefusedCnt	UINT			Incremented when a connection is refused by the remote station.
	dwErrProdCnt	UDINT			Incremented at each production.
	dwErrConsCnt	UDINT			Incremented at each consumption.
	dwErrProdByteCnt	UDINT			Total bytes produced.
	dwErrConsByteCnt	UDINT			Total bytes consumed.
03	Input Status	WORD	X	—	See Status descriptions, below.
04	Output Status	WORD	X	—	See Status descriptions, below.
X = supported — = not supported					

ID (hex)	Description	Type	GET	SET	Value
05	ST_LINK	STRUCT	X	—	
	CIP Status	UINT			See Status descriptions, below.
	Extended Status	UINT			See Status descriptions, below.
	Production Connection ID	DWORD			Connection ID
	Consumed Connection ID	DWORD			Connection ID
	OtoT API	UDINT			API of the Connection
	TtoO API	UDINT			API of the Connection
	OtoT RPI	UDINT			RPI of the Connection
	TtoO RPI	UDINT			RPI of the Connection
06	ST SOCK_PARAM	STRUCT	X	—	
	IpSockId	DWORD			Internal identifier
	IpForeign	DWORD			IP of the remote station
	wPortForeign	UINT			Port number of the remote station
	IpLocal	DWORD			IP of the local station
	wPortLocal	UINT			Port number of the local station
07	ST_PRODUCTION	STRUCT	X	—	
	bValid	WORD			0: data of the struct production is not valid 1: data of the struct production is valid
	dwCurrentTime	UDINT			(Internal Use—number of ticks before next production)
	dwProductionTime	UDINT			(Internal Use—number of ticks between production)
	SequenceNumber	UDINT			Number of the dwquence in the production
	stCheckTime	STRUCT			
	dwLastTime	UDINT			(Internal Use)
	dwMaxTime	UDINT			Maximum time between 2 productions
	dwMinTime	UDINT			Minimum time between 2 productions
	dwRPI	UDINT			API of the connection
	wOverRun	UINT			Number of times the production was too long
	wUnderRun	UINT			Number of times the production was too short
	dwCurrentTime	UDINT			(Internal Use)
X = supported — = not supported					

ID (hex)	Description	Type	GET	SET	Value
08	ST_CONSUMPTION	STRUCT	X	—	
	bValid	WORD			0: data of the struct consumption is not valid 1: data of the struct consumption is valid
	dwCurrentTime	UDINT			(Internal Use—number of ticks before timeout)
	dwConsumptionTime	UDINT			(Internal Use—number of ticks of the timeout)
	SequenceNumber	UDINT			Number of the sequence in the consumption
	stCheckTime	STRUCT			
	dwLastTime	UDINT			(Internal Use)
	dwMaxTime	UDINT			Maximum time between 2 consumptions
	dwMinTime	UDINT			Minimum time between 2 consumptions
	dwRPI	UDINT			API of the connection
	wOverRun	UINT			Number of times the consumption was too long
	wUnderRun	UINT			Number of times the consumption was too short
dwCurrentTime	UDINT			(Internal Use)	
09	Connection Entry List	STRUCT	X	—	Status of the CCO object. See Status descriptions, below.
	byGeneralStatus	BYTE			
	byReserved	BYTE			
	Extended Status	WORD			
X = supported — = not supported					

Scanner Status

Scanner status values include the following:

Status	Description	CIP Status	Extended	Explanation
0	OK	0	0	The I/O data are correctly exchanged.
33	Timeout	0xFB	0xFB0B	Timeout detected on consumption.
53	IDLE	0	0	An IDLE notification is received.
54	Connection established	0	0	The connection is established, but I/O is not yet consumed.
		0xFB	0xFB08	Impossible to start the production.
		0xFB	0xFB09	Impossible to start the consumption.
		0xFB	0xFB0A	Not enough resources to manage the connection.
58	Not connected (TCP)	0xFE		Error on TCP connection.
65	Not connected (CIP)	0xFB	0xFB01	Timeout for Fw_Open response.
		0xFB	0xFB02	Bad format of the Fw_Open response (so addr).
		0xFB	0xFB03	Bad parameters in the Fw_Open response (OT Net Par).
		0xFB	0xFB04	Bad parameters in the Fw_Open response (TO Net Par).
		0xFB	0xFB05	Fw_Open respons asks for port number other than 2222.
		0xFB	0xFB06	Error joining the UDP multicast group.
		0xFB	0xFB07	Optimization error / unknown MAC Address.
68	Connection establishing	0xD0	0x0001	Connection is closed.
		0xD0	0x0002	Connection is pending.
70	Not connected (EPIC)	0xFD		Error code in register session response.
		0xFD		Error code in the frame.
		0xFD		Encapsulation session un-registered.
77	Scanner stopped	0	0	Connection is stopped.

Services

The CIP Scanner Diagnostic object performs the following services upon the listed object types:

ID (hex)	Description	Class	Instance	Notes		
01	Get_Attributes_All	X	X			
61	Get_Output	—	X	Returns the status and values of the output:		
				Offset	Type	Description
				0	UINT	Status
				2	USINT[0...409]	Output Data
62	Get_Input	—	X	Returns the status and values of the input:		
				Offset	Type	Description
				0	UINT	Status
				2	USINT[0...409]	Input Data
63	Set_DiagCounters	—	X	Sets the value of the structure ST_DIAG_CNT to 0.		
X = supported — = not supported						

TCP/IP Interface Object

Overview

The Identity CIP object consists of the attributes and services described below.

Attributes

The TCP/IP Interface CIP object consists of the following attributes:

1. Class attributes:

ID (hex)	Description	GET	SET
01	Revision	X	—
02	Max Instance	X	—
X = supported — = not supported			

2. Instance attributes:

ID (hex)	Description	Type	GET	SET	Value
01	Status	DWORD	X	—	always = 0x01
02	Configuration Capability	DWORD	X	—	0x01 = from BootP 0x11 = from flash 0x00 = other
03	Configuration Control	DWORD	X	X	0x01 = out-of-box default
04	Physical Link Object	STRUCT	X	—	
	Path Size	UINT			
	Path	Padded EPATH			
05	Interface Configuration	STRUCT	X	X	0x00 = out-of-box default
	IP Address	UDINT			
	Network Mask	UDINT			
	Gateway Address	UDINT			
	Name Server	UDINT			
	Name Server 2	UDINT			
	Domain Name	STRING			
06	Host Name	STRING	X	—	
X = supported — = not supported					

Services

The CIP TCP/IP Interface object performs the following services upon the listed object types:

ID (hex)	Description	Class	Instance	Notes
01	Get_Attributes_All	X	X	—
0E	Get_Attributes_Single	X	X	—
05	Get_Attributes_Single	—	X	—
X = supported — = not supported				

Chapter 7

Diagnostics

Overview

This chapter describes the diagnostic features of the EtherNet/IP communication module and the Control Expert EtherNet/IP configuration software.

What Is in This Chapter?

This chapter contains the following topics:

Topic	Page
LED Indicators for the 140 NOC 771 00 EtherNet/IP Communication Module	204
Diagnostic Testing Using the Control Expert EtherNet/IP Software	206
Ping a Network Device	208
Viewing Output Messages in the Control Expert EtherNet/IP Configuration Tool	209

LED Indicators for the 140 NOC 771 00 EtherNet/IP Communication Module

LED Indicators

The 140 NOC 771 00 displays the following LED indicators:

Active	■
Mod Status	■
Net Status	■
Ready	■
Link	■
TxActive	■
RxActive	■
100Mb	■
Fduplex/Col	■

LED Descriptions

Use the LED display to diagnose the state of the module, as follows:

LED	Color	Description
Active	Green	<ul style="list-style-type: none"> ● Off: Indicates that the module is not communicating with the CPU over the backplane. ● Steady Green: Indicates that the module is communicating with the CPU over the backplane.
Mod Status (Module Status)	Green/ Red	<ul style="list-style-type: none"> ● Off: Power is not being supplied to the module. ● Steady Green: The module is operating normally. ● Flashing Green: The module has not been configured. ● Steady Red: The module has detected a major fault. ● Flashing Red: The module has detected a recoverable fault.
Net Status (Network Status)	Green/ Red	<ul style="list-style-type: none"> ● Off: Power is not being supplied to the module or the module does not have an IP address assigned. ● Steady Green: The module has established at least one CIP connection. ● Flashing Green: The module has obtained an IP address but has not established any CIP connections. ● Steady Red: The module has detected that its IP address is a duplicate IP address. ● Flashing Red: One or more CIP connections has timed out and the connection(s) need to be re-established or the module has been reset.

LED	Color	Description
Ready	Green	<p>Steady Green: Indicates that the module is being configured and is ready to start operating.</p> <p>The Ready LED also provides diagnostic information by using the following sequence of flashes.</p> <ul style="list-style-type: none"> ● Two flashes: The module has an invalid MAC address. ● Three flashes: The Ethernet link is not connected ● Four flashes: The module has detected a duplicate IP address. ● Five flashes: The module is waiting for a served IP configuration. ● Six flashes: The module is using its default IP configuration. ● Seven flashes: The module has detected a configuration error.
Link	Green	<ul style="list-style-type: none"> ● Off: An Ethernet link has not been established. ● Steady Green: The module has an Ethernet link.
TxActive (Transmission Activity)	Green	<ul style="list-style-type: none"> ● Off: There is no transmission activity. ● Flashes Green: Indicates transmission activity.
RxActive (Reception Activity)	Green	<ul style="list-style-type: none"> ● Off: There is no reception activity. ● Flashes Green: Indicates reception activity.
100Mb	Green	<p>Steady Green: The module connected with a 100Mb Ethernet link.</p>
FDuplex/Col (Full Duplex/ Collision)	Green/ Red	<ul style="list-style-type: none"> ● Off: The module is not connected to a full duplex Ethernet link. ● Steady Green: Indicates that the module is connected with a full duplex link (it can transmit and receive at the same time.) ● Flashing Red: A collision has been detected on the Ethernet link.

Diagnostic Testing Using the Control Expert EtherNet/IP Software

Overview

Use the Control Expert EtherNet/IP configuration tool to perform a diagnostic test of the EtherNet/IP module and all other devices in your configuration.


NOTE: Diagnostic testing is performed directly between the Control Expert EtherNet/IP configuration tool software running on your PC and the target EtherNet/IP device.

The software displays the results of the diagnostic test, as follows:

- the task bar's **Module State** indicator reads **Diagnostic**
- the **Devices** window depicts the state of connections for each device using a:
 - green icon, indicating all connections are functioning
 - red icon, indicating at least one connection has failed
 - gray icon, indicating a rack optimized module connection
- a diagnostic tab is added to the properties window for each EtherNet/IP device and I/O module displaying:
 - each connection's status, information, and performance data, and
 - the value of each input and output

Performing a Diagnostic Test

To perform a diagnostic test in the Control Expert EtherNet/IP software:

Step	Action
1	<p>Do one of the following:</p> <ul style="list-style-type: none"> ● click the Diagnostics toolbar button , or ● select Devices → Diagnostic... <p>The configuration tool enters its diagnostic state.</p>
2	<p>The EtherNet/IP module enters a diagnostic state and displays the status of each connected device and module. An example of a diagnostic status display appears, below:</p>  <p>In the above example:</p> <ul style="list-style-type: none"> ● a green icon indicates that all connections are functioning for the device at address [001] ● a red icon indicates at least one connection has failed for the device at address [002] ● red icons indicate that at least one connection has failed for the modules at slots [00] and [01] ● a gray icon indicates a rack optimized connection, exists for the module at slot [02]
3	<p>To exit diagnostic mode, repeat the command in step 2.</p>

Ping a Network Device

Overview

Use the Control Expert EtherNet/IP configuration tool's Ping function to send an ICMP echo request to a target EtherNet/IP device to determine:

- if the target device is present, and if so
- the elapsed time to receive an echo response from the target device

The target device is identified by its IP address setting. The Control Expert EtherNet/IP configuration tool will verify that the target address is not a:

- loopback address (127.000.000.000 to 127.255.255.255)
- multicast address (224.000.000.000 to 239.255.255.255)
- reserved address (240.000.000.000 to 255.255.255.255)
- broadcast address

The ping function can be performed from either the:

- **General** page of a device's properties window
- **Ping** page of the **Online Action** window

Pinging a Network Device

To ping a network device:

Step	Action
1	Be sure the Control Expert EtherNet/IP configuration tool is operating online.
2	Do one of the following: <ul style="list-style-type: none"> • Select Network → Online Action, then click on the Ping page, or • Select a device in the Devices window, then select Devices → Properties
3	If you are working in the Ping page of the Online Action window, type in the IP Address of the target device. Notes: <ul style="list-style-type: none"> • The default is the IP address of the device currently selected in the Network Detection list. • If you are working in the General page of a device's Properties window, the Control Expert EtherNet/IP configuration tool uses the IP address of the device selected in the Devices window.
4	To send... <ul style="list-style-type: none"> • a single ping, de-select the Loop checkbox • a series of pings—1 every 100 ms—select Loop
5	(Optional) Select Stop on Error to stop pinging if an error occurs.
6	Click Ping once to begin pinging.
7	Click Ping a second time to stop looped pinging, where no error has been detected.

Viewing Output Messages in the Control Expert EtherNet/IP Configuration Tool

Overview

Use the Control Expert EtherNet/IP configuration tool's **Output Message** window to diagnose the health of your EtherNet/IP network. This window maintains a log of network events. You can:

- show or hide the window
- display for each item in the window its:
 - date and time
 - level of significance
- copy the contents of the **Output Message** window to your PC's Windows Clipboard
- clear the contents of the window

Show/Hide the Output Message Window

The **Output Message** window is displayed in the Control Expert EtherNet/IP configuration tool by default. To hide the window, select: **File** → **Preferences** → **Output Window**.

To reopen the **Output Message** window, repeat the above command.

Add Date/Time and Level to Output Message Window Items

To show or hide the date and time, or level of significance for **Output Message** window entries:

Step	Action
1	Select File → Message View → Configuration . The Output Message View Configuration dialog opens.
2	Select—or de-select—either or both: <ul style="list-style-type: none"> ● Add Date to Messages ● Add Level to Messages
3	Click OK .

Copy/Clear

To copy the contents of the **Output Message** window to your PC's Windows Clipboard, select: **File** → **Message View** → **Copy**.

To clear the contents of the **Output Message** window select: **File** → **Message View** → **Clear**.

Chapter 8

Replacing the EtherNet/IP Communication Module

Replacing the EtherNet/IP Communication Module

Overview

You can replace the EtherNet/IP communication module at any time using another module with compatible firmware. A module can be replaced when power to the module is either:

- off (cold swap), or
- on (hot swap)


The replacement module obtains its operating parameters over the backplane connection from the CPU. The transfer occurs either immediately (hot swap) or when power is next cycled to the device (cold swap).

NOTE: The operating parameters that the CPU sends to a replacement module do not include any parameter values that were edited in the original module using explicit messaging "SET" commands. Explicit messaging can be performed in the Online Action window of the Control Expert EtherNet/IP configuration tool.

Replacing the Communication Module

Replacing the module involves removing the old module and mounting a new one in its place.

To remove a module:

Step	Action
1	Use a Phillips-head screw driver to detach the safety screw, located at the lower front side of the module, from the backplane.
2	<p>Swing the bottom of the module away and up from the backplane, pivoting it on the hooks holding the module at the top of the backplane, until the module detaches from backplane connector:</p> 
3	Lift the module up and off of the hooks located at the top of the backplane.

To install the replacement module, follow the instructions in the module mounting procedure ([see page 16](#)).

Appendices



Appendix A

Error Codes

TCP/IP Ethernet Error Codes

TCP/IP Ethernet Error Codes

An error in an `MSTR` routine via TCP/IP Ethernet may produce one of the following errors in the `MSTR` control block:

The error code appears as `Mmss`, where:

- **M** is the high code
- **m** is the low code
- **ss** is a subcode

Hexadecimal Error Codes TCP/IP Ethernet

Hexadecimal error codes TCP/IP Ethernet:

Hex. Error Code	Meaning
1001	Abort by user
2001	An operation type that is not supported has been specified in the control block
2002	One or more control block parameters were modified while the <code>MSTR</code> element was active (this only applies to operations which require several cycles for completion). Control block parameters may only be modified in inactive <code>MSTR</code> components.
2003	Invalid value in the length field of the control block
2004	Invalid value in the offset field of the control block
2005	Invalid value in the length and offset fields of the control block
2006	Unauthorized data field on slave
2008	Unauthorized network routing path on slave
200E	The control block is not assigned, or parts of the control block are located outside of the <code>%MW (4x)</code> range.
3000	Generic Modbus failure code
30ss	Exceptional response by Modbus slave (<i>see page 216</i>)
4001	Inconsistent response by Modbus slave

ss Hexadecimal Value in 30ss Error Code

ss hexadecimal value in 30ss error code:

ss hex. Value	Meaning
01	Slave does not support requested operation
02	Non-existing slave registers were requested
03	An unauthorized data value was requested
05	Slave has accepted a lengthy program command
06	Function cannot currently be carried out: lengthy command running
07	Slave has rejected lengthy program command

Hexadecimal Error Codes TCP/IP Ethernet Network

An error on the TCP/IP Ethernet network itself may produce one of the following errors in the CONTROL [1] register of the control block.

Hexadecimal error codes TCP/IP Ethernet network:

Hex. Error Code	Meaning
5004	Interrupted system invocation
5005	I/O error
5006	No such address
5009	The socket descriptor is not valid
500C	Not enough storage space
500D	Authorization denied
5011	Entry exists
5016	An argument is not valid
5017	An internal table has no more space
5020	There is interference on the connection
5023	This operation was blocked and the socket is non-blocking
5024	The socket is non-blocking and the connection cannot be closed down
5025	The socket is non-blocking and a previous connection attempt has not been concluded
5026	Socket operation on a non-socket
5027	The destination address is not valid
5028	Message too long
5029	Wrong type of protocol for the socket
502A	Protocol not available

Hex. Error Code	Meaning
502B	Protocol not supported
502C	Socket type not supported
502D	Operation not supported at socket
502E	Protocol family not supported
502F	Address family not supported
5030	Address is already in use
5031	Address not available
5032	Network is out of order
5033	Network cannot be reached
5034	Network shut down the connection during reset
5035	The connection was terminated by the peer
5036	The connection was reset by the peer
5037	An internal buffer is required, but cannot be assigned
5038	The socket is already connected
5039	The socket is not connected
503A	Cannot transmit after the socket has been shut off
503B	Too many references; cannot splice
503C	Connection timed out
503D	The connection attempt was denied
5040	Host is out of order
5041	The destination host could not be reached from this node
5042	Directory not empty
5046	NI_INIT returned -1
5047	The MTU is not valid
5048	The hardware length is not valid
5049	The route specified cannot be found
504A	Collision when invoking Select; these conditions have already been selected by another job
504B	The job ID is not valid
5050	No Network Resource
5051	Length Error
5052	Addressing Error
5053	Application Error
5054	Client cannot process request

Hex. Error Code	Meaning
5055	No Network Resource
5056	Non-Operational TCP connection
5057	Incoherent configuration
6003	FIN or RST not expected
F001	In reset mode
F002	Component not fully initialized



A

Advanced mode

In Control Expert, Advanced mode is a selection that displays expert-level configuration properties that help define Ethernet connections. Because these properties are designed to be edited only by persons with a solid understanding of communication protocols, they can be hidden or displayed, depending upon the qualifications of the specific user.

C

connected messaging

In EtherNet/IP, connected messaging uses a CIP connection for communication. A connected message is a relationship between two or more application objects on different nodes. The connection establishes a virtual circuit in advance for a particular purpose, such as frequent explicit messages or real-time I/O data transfers.

E

Explicit Messaging

TCP/IP-based messaging for Modbus TCP and EtherNet/IP. It is used for point-to-point, client/server messages that include both data—typically unscheduled information between a client and a server—and routing information. In EtherNet/IP, Explicit Messaging is considered Class 3 type messaging, and can be connection-based or connectionless.

G

gateway

A device that interconnects two different networks—sometimes with different network protocols. When used to connect networks based on different protocols, a gateway converts a datagram from one protocol stack into the other. When used to connect two IP-based networks, a gateway (also called a router) has two separate IP addresses - one on each network.

I

Implicit Messaging

UDP/IP-based class 1 connected messaging for EtherNet/IP. Implicit messaging maintains an open connection for the scheduled transfer of control data between a producer and consumer. Because an open connection is maintained, each message contains primarily data—without the overhead of object information—plus a connection identifier.

R

RPI

(requested packet interval) The time period between cyclic data transmissions requested by the Scanner. EtherNet/IP devices will publish data at the rate specified by the RPI assigned to them by the Scanner. Modbus TCP devices will receive message requests from the Scanner at each RPI.

T

trap

A trap is an event directed by an SNMP agent that indicates either:

- a change has occurred in the status of an agent, or
- an unauthorized SNMP manager device has attempted to get data from, or change data on, an SNMP agent

U

unconnected messaging

In EtherNet/IP, unconnected messaging uses TCP (without a CIP connection) to send explicit messages. More overhead is contained within each unconnected message than for a connected message. The unconnected message is not necessarily provided destination node resources. Unconnected Messaging is used for non-periodic requests.



0-9

- 140 NOC 771 00
 - LED descriptions, *204*
 - LED indicators, *204*
- 1734-AENT
 - configuring, *120*
 - viewing I/O addresses, *124*

A

- adapter diagnostic object, *178*
- Advantys STB island
 - connecting to, *95*
- assembly object, *183*
- auto-negotiation, *130*

B

- BOOTP, *53*

C

- channel properties
 - Ethernet, *43*
 - EtherNet/IP, *44*
 - general, *40*
 - module information, *46*
- CIP objects, *177*
- configuration
 - EtherNet/IP configuration tool, *52*
- connection manager object, *185*
- connections
 - CIP, *143*
 - TCP, *142*
- Control Expert
 - explicit messaging, *156*

D

- detect network devices, *90, 119*

- device bandwidth, *147*
- device library, *73*
- device load, *147*
- devices window, *36*
- DHCP client, *58*
- DHCP server, *57*
- diagnostic test, *206*
- diagnostics
 - ping, *208*

E

- EDS file
 - add, *75, 116*
- ethernet link object, *187*
- explicit message, *140*
- explicit messaging, *156*
 - error codes, *169*
 - Get_Attributes_Single, *159, 172*
 - Reset, *164, 174*
 - services, *154*

F

- full-duplex, *130*

I

- identity object, *191*
- IGMP snooping, *132*
- implicit message, *141*
- IP address, *53*

L

- load
 - example, *148*
 - limits, *144*
- local slave
 - I/O, *62*
 - identifying, *61*

M

MBP_MSTR, *159, 164*
 error codes, *169*
 explicit messaging, *156*
message bandwidth, *146*
message load, *146*
messages
 types, *140*
module addresses
 EtherNet/IP configuration tool, *52*
module diagnostic object, *193*

N

network bandwidth, *147*
network example, *88*
 extended, *115*
network load, *147*

O

output messages, *209*

P

ping, *208*
port mirroring, *136*
project file
 save, *85*

Q

QoS, *131*

R

remote device
 configuring, *80*
replacement, *211*
RSTP, *133*

S

scanner diagnostic object, *195*

SNMP agent, *55, 138*
STB NIC 2212
 configuring adapter, *91*
 configuring I/O items, *99*
switch
 managed, *129*
 recommended features, *129*

T

TCP/IP interface object, *200*
TCP/IP properties, *53*

V

VLAN, *134, 137*