

# SIEMENS

## MICROMASTER Drives 6SE92



### Getting Started

Caution: Before installing and putting this equipment into operation, please read the Operating Instructions Manual for Safety Precautions and Warnings


### SIEMENS MICROMASTER .....

The MICROMASTER products are a range of frequency inverters for controlling the speed of three phase AC induction motors

#### Step 1 Connecting up the MICROMASTER

230V Single Phase

400V Three Phase



Delta connection for 230V 3 phase

Star connection for 400V 3 phase

Note: Motors above 11kW are usually configured 400V Delta / 690V Star. In this case the motor should be connected in Delta.

#### Step 2 Getting the motor going

Press this green button (RUN button) to start the motor.

Forward/reverse

This is the 'STOP' button

While the motor is running, press the 'STOP' button and watch as the motor turns faster and the value in the display increases. It will keep increasing until it reaches 50%.

When the inverter reaches 50Hz output, press the 'DOWN' button and watch the motor speed and display value decrease.

At any time, press the 'STOP' button and watch the motor stop.

#### Step 3 Changing the speed of the motor

The default output frequency of the drive is 5Hz (see **Hints and Tips** to convert this to RPM). This speed will probably be too low for most applications and a speed change may be required. The following steps will allow you to change the preset value of the inverter output to the required speed.

Step / Action	Display
Press the 'P' button to access the parameter settings.	P000
Press the '▲' button 5 times until the display reads P005.	P005
Press the 'P' button to display the current parameter value.	005.0
Press the '▲' button to change the value to 35Hz. (This number can be any number between 0 and 50Hz - default.)	035.0
Press the 'P' button to store the new value.	P005
Press the '▼' button until the display reads P000.	P000
Press the 'P' button to exit the parameterisation procedure. The display will alternate between the output frequency and the frequency set point.	000.0 035.0

The required speed has now been stored.

This method is used to access all parameters.

The drive can now be started by pressing the 'RUN' button. It will ramp up to the frequency held in parameter P005 and remain there. To stop the drive press the 'STOP' button, the drive will then ramp down to 0Hz output.

#### Default Parameters:

Digital input	Terminal	Parameter	Default
1	5	P051 = 1	ON right
2	6	P052 = 2	ON left
3	7	P053 = 6	Fixed Frequency
Output Relay 1	10/11	P061 = 6	Fault Identification

#### Fault Codes:

F001	Overvoltage
F002	Overcurrent
F003	Overload
F005	Inverter overtemperature (internal PTC)
F074	Motor overtemperature by Pt calculation
Other faults, see manual	

For further Technical Support information, and to submit your suggestions for improvements, see our Web Site:

<http://www.con.siemens.co.uk>

Siemens plc  
Automation and Drives  
Varey Road  
Cogleton  
Cheshire CW12 1PH  
Great Britain


G85139-H1750-U150-C1

May 1999  
English  
Order Number: 6SE9286-4BA86

#### Step 4 Controlling the motor speed with a potentiometer

A potentiometer can be used to control the running speed of the inverter. This is achieved by varying the voltage applied to the analogue input. Connect the potentiometer to the control terminals shown below. Starting and stopping of the motor may be achieved by connecting a switch to the digital input terminals shown.

The following parameter settings are required  
 P006 Set to 1 to allow analogue input  
 P007 Set to 0 to enable control via digital input



#### Telling the drive about your motor

To get the best performance from your drive, you should enter information from your motor ratings plate into certain parameters. The following diagram indicates the location of the information and the parameters which should be entered.

Commissioning MICROMASTER Basic																										
Display parameters	Basic parameters	Motor parameters	Frequently used parameters																							
<b>Select display via P001</b>  <b>Display frequency, motor current and motor speed: P001</b> 0 = output frequency 1 = frequency setpoint 2 = motor current 5 = Motor speed (RPM)	<b>Ramp-up time P002</b> 0-650 sec.  <b>Ramp-down time P003</b> 0-650 sec.  <b>Frequency setpoint P006</b> 0 = digital 1 = analog 2 = fixed frequency  <b>Keypad control P007</b> 0 = disable 1 = enable  <b>Parameter protection P009</b> 0 = only P001-P009 can be altered 2, 3 = all can be altered.	<b>Nominal rating plate frequency for motor P081</b> 0-400Hz  <b>Nominal rating plate speed for motor P082</b> 0-9999 RPM  <b>Nominal rating plate current for motor P083</b> 0.1-99.9A  <b>Nominal rating plate voltage for motor P084</b> 0-1000V  <b>Nominal rating plate power for motor P085</b> 0-100kW  <b>Motor current limit P086</b> 0-250%	<b>Minimum motor frequency P012</b> 0-400Hz.  <b>Maximum motor frequency P013</b> 0-400Hz.  <b>Automatic restart after mains failure P015</b> 0 = disable 1 = enable  <b>Start on the fly P016</b> 0 = disable 2 = enable  <b>Analogue input P023</b> 0 = 0-10V 1 = 2-10V  <b>Fixed frequency operation P041-048</b> 0-400Hz  <b>Input terminal function P051-053</b>  <b>Selection relay output P061</b>  <b>DC injection braking P073</b> 0-150%  <b>Pulse frequency P076</b> See Operator Manual  <b>Control mode P077</b> See Operator Manual  <b>Continuous boost P078</b> 0-250%  <b>See Operator Manual for other parameters</b>																							
		<table border="1"> <tr> <td>P081</td> <td>P084</td> </tr> <tr> <td>50Hz</td> <td>3. Mt IEC 36 M/B</td> </tr> <tr> <td>230/400V Δ/Y</td> <td>1LA7053-2AA10</td> </tr> <tr> <td>0.61/0.35A</td> <td>Nr. E510 2053</td> </tr> <tr> <td>0.12kW</td> <td>IP54</td> </tr> <tr> <td>2820 mm</td> <td>80Hz 440V Y</td> </tr> <tr> <td></td> <td>0.34A</td> </tr> <tr> <td></td> <td>0.14kW</td> </tr> <tr> <td></td> <td>3360 /min</td> </tr> <tr> <td></td> <td>S.F. = 1.15</td> </tr> <tr> <td>P083</td> <td>P082</td> <td>P085</td> </tr> </table>		P081	P084	50Hz	3. Mt IEC 36 M/B	230/400V Δ/Y	1LA7053-2AA10	0.61/0.35A	Nr. E510 2053	0.12kW	IP54	2820 mm	80Hz 440V Y		0.34A		0.14kW		3360 /min		S.F. = 1.15	P083	P082	P085
P081	P084																									
50Hz	3. Mt IEC 36 M/B																									
230/400V Δ/Y	1LA7053-2AA10																									
0.61/0.35A	Nr. E510 2053																									
0.12kW	IP54																									
2820 mm	80Hz 440V Y																									
	0.34A																									
	0.14kW																									
	3360 /min																									
	S.F. = 1.15																									
P083	P082	P085																								

#### Hints and Tips

- The direction of rotation of the motor can be reversed during commissioning by changing over two of the output connections on the inverter, or by pressing the Forward/Reverse button.
- Parameters P000 to P009 can always be read or set. Access to all other parameters is controlled by the contents of P009. The factory default value is '0' which only allows access to P000 to P009. Changing its value to '3' allows all parameters to be accessed permanently. See Operator Manual for the function of other values of P009.
- In case there are problems with the parameter settings and wish to start again, change P044 to '1'. This will perform a reset to the default values.
- The value displayed in P000 is the output frequency of the inverter, this is the default setting but it can be changed by altering the value in P001. For example, changing P001 to a value of '5' will cause the inverter to display the RPM of the motor in P000. See the Operator Manual for other settings of P001.
- The default value (0) of parameter P006 ensures that the drive runs at the frequency set in P005. In order to control the output frequency by an analogue input signal, the value of P006 should be set to '1'. For other methods of control using P006, see the Operator Manual.
- An F002 fault is often caused by either too short a ramp up time or too much voltage boost. An increase in the value in P002 will increase the ramp time. Alternatively lower the values in P078 and P079 to reduce the voltage boost. Please note that if P078 falls below '107' (default value) then the motor may under-perform at low frequencies.
- An F001 fault is often caused by attempting to stop the motor too quickly: increasing the value in P003 (ramp-down time) will reduce this possibility.
- If the display flashes during operation, the drive is registering a warning. Check P031 for the cause.